



1002rp Server Maintenance and Diagnostics

CallPilot
Release 4.0

Document Number: 555-7101-206

Document Version: Standard 1.11

January 2007

Copyright © 2007 Nortel Networks.

All Rights Reserved.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

The process of transmitting data and call messaging between the CallPilot server and the switch or system is proprietary to Nortel Networks. Any other use of the data and the transmission process is a violation of the user license unless specifically authorized in writing by Nortel Networks prior to such use. Violations of the license by alternative usage of any portion of this process or the related hardware constitutes grounds for an immediate termination of the license and Nortel Networks reserves the right to seek all allowable remedies for such breach.

Trademarks

*Nortel Networks, the Nortel Networks logo, the Globemark, and Unified Networks, BNR, CallPilot, DMS, DMS-100, DMS-250, DMS-MTX, DMS-SCP, DPN, Dualmode, Helmsman, IVR, MAP, Meridian, Meridian 1, Meridian Link, Meridian Mail, Norstar, SL-1, SL-100, Succession, Supernode, Symposium, Telesis, and Unity are trademarks of Nortel Networks.

3COM is a trademark of 3Com Corporation.

ADOBE is a trademark of Adobe Systems Incorporated.

ATLAS is a trademark of Quantum Corporation.

BLACKBERRY is a trademark of Research in Motion Limited.

CRYSTAL REPORTS is a trademark of Seagate Software Inc.

EUDORA is a trademark of Qualcomm.

eTrust and InoculateIT are trademarks of Computer Associates Think Inc.

DIRECTX, EXCHANGE.NET, FRONTPAGE, INTERNET EXPLORER, LINKEXCHANGE, MICROSOFT, MICROSOFT EXCHANGE SERVER, MS-DOS, NETMEETING, OUTLOOK, POWERPOINT, VISUAL STUDIO, WINDOWS, WINDOWS MEDIA, and WINDOWS NT are trademarks of Microsoft Corporation.

GROUPWISE and NOVELL are trademarks of Novell Inc.

LOGITECH is a trademark of Logitech, Inc.

MCAFEE and NETSHIELD are trademarks of McAfee Associates, Inc.

MYLEX is a trademark of Mylex Corporation.

NETSCAPE COMMUNICATOR is a trademark of Netscape Communications Corporation.

NOTES is a trademark of Lotus Development Corporation.

NORTON ANTIVIRUS and PCANYWHERE are trademarks of Symantec Corporation.

QUICKTIME is a trademark of Apple Computer, In.

RADISYS is a trademark of Radisys Corporation.

SLR4, SLR5, and TANDBERG are trademarks of Tandberg Data ASA.

SYBASE is a trademark of Sybase, Inc.

TEAC is a trademark of TEAC Corporation

US ROBOTICS, the US ROBOTICS logo, and SPORTSTER are trademarks of US Robotics.

WINZIP is a trademark of Nico Mark Computing, Inc.

XEON is a trademark of Intel, Inc.

All other trademarks and registered trademarks are the property of their respective owners.

Information for Japan

Japan Denan statement

The following applies to server models 1005r, 703t, and 1002rp:

 Warning
<p>Please be aware of the following while installing the equipment:</p> <ul style="list-style-type: none"> ● Please use the connecting cables, power cord, and AC adaptors shipped with the equipment or specified by Nortel to be used with the equipment. If you use any other equipment, it may cause failures, malfunctioning or fire. ● Power cords shipped with this equipment must not be used with any other equipment. If the above guidelines are not followed, it may lead to death or severe injury.
 警告
<p>本製品を安全にご使用頂くため、以下のことにご注意ください。</p> <ul style="list-style-type: none"> ● 接続ケーブル、電源コード、ACアダプタなどの部品は、必ず製品に同梱されております。添付品または指定品をご使用ください。添付品・指定品以外の部品をご使用になると故障や動作不良、火災の原因となることがあります。 ● 同梱されております付属の電源コードを他の機器には使用しないでください。上記注意事項を守らないと、死亡や大怪我など人身事故の原因となることがあります。

Japan VCCI statement

The following applies to server models 1005r, 703t, 201i, and 1002rp:

この装置は、情報処理装置等電波障害自主規制協議会 (VCCI) の規定に基づくクラス A 装置です。この装置を家庭環境で使用すると電波妨害を引き起こすこと

があります。この場合には使用者が適切な対策を取るようにより要求されることがあります。

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may occur, in which case, the user may be required to take corrective action.

Publication history

January 2007	CallPilot 4.0, Standard 1.11 of the <i>1002rp Server Maintenance and Diagnostics</i> is issued for general release.
October 2006	CallPilot 4.0, Standard 1.10 of the <i>1002rp Server Maintenance and Diagnostics</i> is issued for general release.
September 2006	CallPilot 4.0, Standard 1.09 of the <i>1002rp Server Maintenance and Diagnostics</i> is issued for general release.
May 2006	CallPilot 4.0, Standard 1.06 of the <i>1002rp Server Maintenance and Diagnostics</i> is issued for general release.
October 2005	CallPilot 4.0, Standard 1.03 of the <i>1002rp Server Maintenance and Diagnostics</i> is issued for general release.
July 2005	CallPilot 4.0, Standard 1.02 of the <i>1002rp Server Maintenance and Diagnostics</i> is issued for general release.
July 2005	CallPilot 4.0, Standard 1.01 of the <i>1002rp Server Maintenance and Diagnostics</i> is issued for general release.
July 2005	CallPilot 4.0, Standard 1.0 of the <i>1002rp Server Maintenance and Diagnostics</i> is issued for general release.
November 2004	Release 3.0, Standard 1.0
April 2004	Release 2.5, Standard 2.0

October 2003

Release 2.5, Standard 1.0

October 2002

Standard 1.0 of *CallPilot Installation and Configuration, 1002rp Server Maintenance and Diagnostics* is issued for general release.

Task List

To run the startup test	25
To run the POST	26
To determine why the server failed to boot to Windows.....	30
To determine why the server failed to boot into CallPilot	30
To use the operating system Event Viewer.....	36
To run the ipconfig command from Windows	41
To run the ping command from Windows.....	43
To run the tracert command from Windows	44
To run the arp command from Windows	46
To run the nbtstat command from Windows.....	48
To run the netstat command from Windows.....	49
To run the chkdsk utility from Windows.....	52
To invoke the Net Stop command from Windows	56
To invoke the Service Control command from Windows.....	57
To invoke the TSTSERIO /P command from Windows.....	60
To invoke the TSTSERIO /S command from Windows.....	61
To invoke the Net Start command from Windows.....	63
To investigate using the Alarm Monitor	69
To investigate using the Event Browser	71
To view the state of a hardware component	80
To start or stop a component	83
To run a diagnostic test.....	86
To view the last diagnostics result	88
To view or work with multimedia channel states	90
To view or work with call channel states	92
To access the Diagnostics Tool	97
To enable startup diagnostics	97
To disable startup diagnostics.....	97
To access the PEP Maintenance utility	99
To view a list of all installed PEPs.....	99
To access the System Monitor	103
To remove the front bezel	113
To remove the server cover	114
To replace the front bezel after maintenance is complete.....	114
To replace the front bezel air filter.....	116
To replace the door air filter	116
To hot-swap a power supply	118

To replace the SCSI power cable.....	121
To hot-swap a cooling fan	128
To replace the fuse.....	131
To replace the alarm board	133
To replace the status display panel.....	138
To replace hot-pluggable SCA SCSI hard drives	144
To replace media drives	146
To remove the media drive carrier from the chassis	149
To replace a media drive.....	151
To configure the tape drive.....	155
To install a new tape drive (no tape drive previously installed)	156
To determine the current RAID firmware version:	161
To replace the LSI1600 card with the LSI320-2 card.	163
To configure an LSI Elite 1600 or LSI320-2 RAID system	165
To perform a consistency check.....	170
To split the RAID	171
To synchronize the RAID after a successful operation	173
To synchronize the RAID after an unsuccessful operation	173
To add two MPB96 boards and two T1 PCI cards	180
To add two MPB96 boards.....	184
To replace an MPB96 board	189
To replace a faulty D/480JCT-2T1 card	195
To test the D/480JCT-2T1 card.....	197
To replace the SBC card.....	205
To upgrade the BIOS	207
To configure the Pentium III SBC.....	209
To add an SDRAM DIMM to the SBC card	210

Contents

1	How to get Help	15
2	About this guide	17
	Maintenance and diagnostics overview	18
3	Troubleshooting your CallPilot system	21
	Startup diagnostics overview	22
	Basic hardware check	23
	Power-On Self-Test diagnostics	24
	Interpreting POST diagnostics	25
	Interpreting startup diagnostics from SCSI BIOS	27
	What to do when the server fails to boot into service.	28
4	Using Windows online diagnostic tools	31
	Overview	32
	Viewing event logs	33
	Using TCP/IP diagnostic tools	38
	Using the chkdsk utility	49
5	Using serial port diagnostic tools	51
	Overview	52
	Shutting down services	53
	Conducting TSTSERIO tests	56
	Conducting TSTSERIO tests with the loopback plug	60
	Restarting services	61
6	Using CallPilot Manager to monitor hardware	63
	Understanding fault management	64
	Alarm Monitor	67
	Event Browser.	69

	Channel and Multimedia Monitors	71
	The Maintenance screen	72
	Viewing component states	76
	Starting and stopping components	79
	Running integrated diagnostics.	83
	Viewing the last diagnostic results	86
	Working with the Multimedia Monitor	88
	Working with the Channel Monitor	90
7	Using CallPilot system utilities	93
	Overview	94
	Diagnostics Tool	95
	PEP Maintenance utility	97
	Session Trace	98
	System Monitor.	101
8	Replacing basic chassis components	109
	Removing the front bezel and server cover	110
	Replacing air filters.	114
	Replacing the power supply	116
	Replacing the SCA SCSI drive cage and fused power cable	119
	Replacing the cooling fan	126
	Replacing the fuse (AC system only).	129
	Replacing the alarm board	131
	Setting jumpers on the alarm board	133
	Replacing the status display panel	136
9	Replacing media drives	139
	Replacing a faulty hard drive	140
	About the media drive bay	144
	Removing the media drive carrier from the chassis	145
	Replacing a tape, CD-ROM or floppy drive.	149
	Installing a tape drive	153
10	RAID operations	157
	Outlining RAID functions	158

Configuring RAID firmware, driver, and power console	159
Replacing the LSI1600 card with LSI320-2	161
Configuring the RAID controller after a hardware change	163
Splitting the RAID drives	167
Synchronizing RAID drives	171
11 Upgrading to High Capacity	173
Board and card configuration for High Capacity	174
Identifying hardware components	176
Upgrading to High Capacity	178
12 Replacing voice processing boards	185
DSP numbering and location	186
Replacing an MPB96 board	187
13 Replacing the D/480JCT-2T1 T1 interface card	191
D/480JCT-2T1 card function	192
14 Maintaining the Pentium III SBC card	199
Overview	200
Replacing the Pentium III SBC card	201
Configuring the 1002rp Pentium III BIOS	205
Replacing inline memory modules	208
Maintaining the onboard video and network cards	210
Index	211

Chapter 1

How to get Help

This section explains how to get help for Nortel products and services.

Getting Help from the Nortel Web site

The best way to get technical support for Nortel products is from the Nortel Technical Support Web site:

<http://www.nortel.com/support>

This site provides quick access to software, documentation, bulletins, and tools to address issues with Nortel products. More specifically, the site enables you to:

- download software, documentation, and product bulletins
- search the Technical Support Web site and the Nortel Knowledge Base for answers to technical issues
- sign up for automatic notification of new software and documentation for Nortel equipment
- open and manage technical support cases

Getting Help over the phone from a Nortel Solutions Center

If you don't find the information you require on the Nortel Technical Support Web site, and have a Nortel support contract, you can also get help over the phone from a Nortel Solutions Center.

In North America, call 1-800-4NORTEL (1-800-466-7835).

Outside North America, go to the following Web site to obtain the phone number for your region:

<http://www.nortel.com/callus>

Getting Help from a specialist by using an Express Routing Code

To access some Nortel Technical Solutions Centers, you can use an Express Routing Code (ERC) to quickly route your call to a specialist in your Nortel product or service. To locate the ERC for your product or service, go to:

<http://www.nortel.com/erc>

Getting Help through a Nortel distributor or reseller

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller.

Chapter 2

About this guide

In this chapter

Maintenance and diagnostics overview

18

Maintenance and diagnostics overview

The maintenance and diagnostic activities discussed in this guide are divided into two groups of activities:

- troubleshooting and diagnostics (identifying the cause of system problems and resolving them)
- performing hardware maintenance

This guide is for administrators, technicians, and engineers responsible for maintaining a CallPilot server. This guide assumes that you have basic computing skills, and are familiar with necessary safety procedures.

If you are not able to resolve your system problem with the resources described in this guide, you can also refer to the following document:

- *Troubleshooting Guide (555-7101-501)*

Note: Nortel continually updates the *Troubleshooting Guide*, which is available from the Partner Information Center (PIC) at <http://www.nortel.com/pic>.

The “Starting up and shutting down the CallPilot server” chapter in the *Installation and Configuration Task List (555-7101-210)* explains how to restart, shut down, and power up the CallPilot server. You may be asked to perform one or more of these tasks while maintaining your server.

When you purchased your CallPilot server, it came preinstalled with the Windows operating system and CallPilot server software. If your CallPilot server no longer functions because of a software problem, you may need to reinstall the CallPilot software or rebuild the system.

Replacement parts

Before replacing any parts on your server, refer to the Nortel product catalog for the part codes.



CAUTION

Risk of system damage

The use of parts that are not supplied by Nortel can cause serious system problems or void your Nortel warranty.

Preparing for maintenance activities


Before you proceed with hardware maintenance activities, review the *1002rp Server Hardware Installation (555-7101-205)* guide for the following information:

- required tools and equipment
- recommended safety precautions for electrostatic discharge, handling cards, and handling your server
- instructions for shutting down your 1002rp server or for taking it out of service

Reference documents



CallPilot Customer Documentation Map



End User Cards

Unified Messaging Quick Reference Card Unified Messaging Wallet Card A-Style Command Comparison Card S-Style Command Comparison Card Menu Interface Quick Reference Card Alternate Command Interface Quick Reference Card
--

End User Guides

Multimedia Messaging User Guide Speech Activated Messaging User Guide Desktop Messaging User Guide for Microsoft Outlook Desktop Messaging User Guide for Lotus Notes Desktop Messaging User Guide for Novell Groupwise Desktop Messaging User Guide for Internet Clients MyCallPilot User Guide
--

Chapter 3

Troubleshooting your CallPilot system

In this chapter

Startup diagnostics overview	22
Basic hardware check	23
Power-On Self-Test diagnostics	24
Interpreting POST diagnostics	25
Interpreting startup diagnostics from SCSI BIOS	27
What to do when the server fails to boot into service	28

Startup diagnostics overview

This section contains procedures for interpreting the startup diagnostics on the 1002rp server.

Types of startup diagnostics

The following types of startup diagnostics are available on the server:

- basic hardware check (for example LEDs)
- Power-On Self-Test (POST) diagnostics
- SCSI controller diagnostics or RAID controller diagnostics

These diagnostics are available at initial system startup, or after any 1002rp server reset.

Basic hardware check

This section describes some basic checks that you can do when you start up the server.

To run the startup test

- 1 Power on the server and observe the front panel display.
Result: All LEDs on the panel illuminate for a few seconds. The green power LED remains illuminated.
- 2 Observe the following server actions:
 - Cooling fans on the front panel start up, and the red fault LED next to each fan extinguishes.
 - Drives spin up, and the amber hard drive activity LEDs over the front panel display extinguish, and then flash with activity.
 - LEDs illuminate temporarily as the system checks the floppy drive, tape drive, and CD-ROM drive.
 - The LED on each power supply lights up red as supply fans spin up and components charge. LEDs turn green when the attached power supply is fully operational.
- 3 Check the monitor for any error messages as the server counts RAM and completes a POST.
See “Power-On Self-Test diagnostics” on page 24 for more details on POST.

Power-On Self-Test diagnostics

The Power-On Self-Test (POST) is a system diagnostic program (stored in the BIOS) that runs each time the 1002rp server is started. The function of the POST is to test system components and then display status messages.

To run the POST

- 1 Power up the CallPilot server and monitor.

Result: After a few seconds, POST begins to run.

After the memory test, various screen prompts and messages appear. The screen prompts may be accompanied by a single beep.

- 2 Observe the screen for any error messages and listen for POST beep codes. When POST completes, the server beeps once.

If the server halts before POST is finished, the server emits a beep code indicating that a fatal system error requires immediate attention. See “Interpreting POST diagnostics” on page 25 for details.

If POST can display a message on the monitor, the server emits two beeps as the message appears.

Record the message that appears on the monitor and the beep code that you hear. This information is useful if you need assistance from your technical support representative.

Interpreting POST diagnostics

This section provides an explanation of the POST diagnostic codes.

POST beep codes

If an error occurs before video initialization, POST emits beep codes that indicate errors in hardware, software, or firmware.

A beep code is a series of separate tones, each equal in length. Record the beep code sequence before calling Nortel technical support.

ATTENTION

Some POST beep codes are fatal and may require that you replace the Single Board Card (SBC). See the table below for more information about beep codes.

Table 1: POST beep codes

Beep count	Error message	Description
1	Refresh Failure	The memory refresh circuitry of the processor board is faulty.
2	Parity Error	A parity error was detected in the base memory (the first block of 64 kbytes) of the system.
3	Base 64KB Memory Failure	A memory failure occurred within the first 64 kbytes of memory.
4	Timer Not Operational	A memory failure occurred within the first 64 kbytes of memory, or Timer #1 on the processor board failed to function properly.

Beep count	Error message	Description
5	Processor Error	The Central Processing Unit (CPU) on the processor board failed to function properly.
6	8042 - Gate A20 Failure	The keyboard controller (8042) contains the Gate A20 switch, which allows the CPU to operate in protected mode. This error message means that the BIOS cannot switch the CPU into protected mode.
7	Processor Exception Interrupt Error	The CPU on the processor board generated an exception interrupt.
8	Display Memory Read/Write Error	The system video adapter is either missing or its memory is faulty. Note: This is not a fatal error.
9	ROM Checksum Error	The ROM checksum value does not match the value encoded in the BIOS.
10	CMOS Shutdown Register Read/Write Error	The shutdown register for the CMOS RAM failed.
11	Cache Memory Bad: Do Not Enable Cache	The cache memory test failed. Cache memory is disabled. Note: Do not press Ctrl+Alt+Shift<+> to enable cache memory.

Interpreting startup diagnostics from SCSI BIOS

The results from the SCSI controller diagnostics appear after the POST results.

Applicable cards

Results of the startup diagnostics appear only if you have the following cards installed on your system:

- Adaptec SCSI controller
The adapter is integrated in the SBC and can be disabled.
- LSI Elite 1600 controller

What to do when the server fails to boot into service

This section suggests tasks you can perform to determine why the server fails the bootup cycle.

To determine why the server failed to boot to Windows

- 1 Make a note of any diagnostic codes.
- 2 Try restarting the server by pressing the power button on the server.
- 3 During the boot sequence, view the diagnostic codes on the monitor for failures.
- 4 Refer to the *Troubleshooting Guide* (555-7101-501) for other suggestions. If you still cannot determine the cause of the startup failure, call your Nortel technical support representative.

To determine why the server failed to boot into CallPilot

If the system-ready indicator indicates that the system is not booting into CallPilot, follow these steps:

- 1 Make a note of any diagnostic codes.
- 2 Try restarting the server by pressing the power button on the server.
- 3 During the boot sequence, view the diagnostic codes on the monitor for failures.
- 4 View the event logs. For instructions, see “Viewing event logs” on page 33.

- 5 Refer to the *Troubleshooting Guide* (555-7101-501) for other suggestions. If you still cannot determine the cause of the startup failure, call your Nortel technical support representative.

Chapter 4

Using Windows online diagnostic tools

In this chapter

Overview	32
Viewing event logs	33
Using TCP/IP diagnostic tools	38
Using the chkdsk utility	49

Overview

This section describes how to access the run-time online diagnostic tools provided by the Windows server software. Use the following tools when a serious problem prevents the use of the CallPilot diagnostic tools that are available in CallPilot Manager.

- Windows Event Viewer
- TCP/IP diagnostics
- chkdsk utility



CAUTION

Risk of software corruption

Do not run any utilities that are not documented in this guide.

Viewing event logs

When the server startup cycle is complete, and if the CallPilot server has been configured, messages in dialog boxes on the monitor indicate that CallPilot is ready to accept calls.

If one or more messages appear on the monitor, the message may contain information about an event, or a fault may have occurred. To determine what happened, you can use the following diagnostic tools:

- Windows Event Viewer on the 1002rp server
- CallPilot Event Browser or Alarm Monitor in CallPilot Manager

Note: The Event Browser and Alarm Monitor include online Help for events, which may help you to resolve the problem. If you cannot log on to the CallPilot system using a web browser due to server problems, then use the Windows Event Viewer.

Types of event logs

Three types of event logs are available from the Windows Event Viewer, as follows:


Log type	Description
System	Logs events by Windows components, including RRAS or other Windows services.
Security	Logs security events, such as logons, logoffs, and illegal access. This option is available only to users with Administrative access.
Applications	Logs events by application, such as database file errors.

To use the operating system Event Viewer

- 1 Click Start → Programs → Administrative Tools → Event Viewer.


Result: The Event Viewer window appears.

Figure 1: Event Viewer




- 2 To view a log, click the type of the log in the left pane of the window. The following illustration shows an example of the Application Log.

Figure 2: Application log



The following illustration shows an example of a System log.

Figure 3: System log



Note: The Security log, which is available only to administrators, is not shown.

- 3 Look for error codes flagged with or that have occurred since the last startup.

Note: Each error is date- and time-stamped. indicates major or critical errors. indicates minor errors, and indicates information.

- 4 To determine the cause of the error, select and then double-click the error.

Result: A description of the error appears in an Event detail dialog box. Use the description to help determine how to resolve errors.

Note: If the error persists or the error description does not suggest a solution, contact your Nortel support representative.

- 5 Click the icon Close or OK.

Result: The event log reappears.

- 6 Click File → Exit.

Result: The Event Viewer closes.

Using TCP/IP diagnostic tools

This section describes the following TCP/IP diagnostic tools which are available for the network adapter:

- ipconfig
- ping
- tracert
- arp
- nbtstat
- netstat

These utilities help you to verify network connectivity, test the network interface, and isolate any configuration problems.

The ipconfig command

The ipconfig command displays IP configuration information.

ipconfig default

If you run the command without flags, it displays the IP address, subnet mask, and default gateway for each adapter bound to TCP/IP.

ipconfig command syntax

The ipconfig command uses the following syntax:

```
ipconfig /[ ]
```

The following flags are available for the ipconfig command.

Table 2: ipconfig command extensions

Flag	Description
/?	Displays Help information.
/all	Displays full configuration information.
/release	Releases the IP address for the specified adapter.
/renew	Renews the IP address for the specified adapter.

To run the ipconfig command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
- 2 At the Command prompt, type **ipconfig** <parameters>.
Example: ipconfig /all
- 3 Press Enter.
Result: The system runs the ipconfig utility.
- 4 Type **Exit** to exit the Command Prompt window and return to Windows.

The ping command

The ping command sends an echo request to a specified host. Use this command to verify network connectivity to the remote device.

Ping command syntax

The ping command uses the following syntax:

```
ping [-t] [-a] [-n count] [-l size] [-f] [-i TTL]
      [-v TOS] [-r count] [-s count]
      [[-j host-list] | [-k host-list]]
      [-w timeout] destination-list
```

Table 3: ping command extensions

Parameter	Description
-t	Pings the specified host until interrupted.
-a	Resolves addresses to host names.
-n count	Specifies the number of echo requests to send.
-l size	Sends buffer size.
-f	Sets Don't Fragment flag in packet.
-i TTL	Specifies the Time To Live
-v TOS	Specifies the Type Of Service
-r count	Specifies the number of Record route for count hops
-s count	Specifies the number of Time stamp for count hops
-j host-list	Specifies the Loose source route along host list
-k host-list	Specifies the Strict source route along host list
-w timeout	Specifies the Timeout in milliseconds to wait for each reply

To run the ping command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.

Result: The Command Prompt window appears.

- 2 At the Command prompt, type **ping <destination IP address>** (for example, ping 200.286.32.0), or **ping <computer name>**.

- 3 Press Enter.

Result: The system displays the ping results.

- 4 Type **Exit** to exit the Command Prompt window and return to Windows.

The tracert command

This utility determines the route taken to a destination.

How tracert works

The tracert utility follows several steps to complete its task:

- Tracert sends Internet Control Message Protocol (ICMP) echo packets with varying Time-To-Live (TTL) values to the destination.
- Each router along the path must decrease the TTL on a packet by at least 1 before forwarding it, so the TTL is effectively a hop count.
- When the TTL on a packet reaches 0, the router sends back an ICMP Time Exceeded message to the source system.
- Tracert determines the route by sending the first echo packet with a TTL of 1, and incrementing the TTL by 1 on each subsequent transmission until the target responds, or the maximum TTL is reached.
- Tracert then examines the ICMP Time Exceeded messages sent back by intermediate routers.

Tracert syntax

The tracert command uses the following syntax:

```
tracert [-d] [-h maximum_hops] [-j host_list]
        [-w timeout] [target_name]
```

Tracert parameters

the following table shows the tracert parameters.

Table 4: Tracert parameters

Parameter	Description
-d	Specifies not to resolve addresses to hostnames.
-h maximum_hops	Specifies the maximum number of hops to search for the target.
-j host-list	Specifies a loose source route along the host list.
-w timeout	Waits the number of milliseconds specified by the timeout for each reply.
target_name	Specifies the name of the target host.

To run the tracert command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.

Result: The Command Prompt window appears.

- 2 At the Command prompt, type the following command:

```
tracert [-d] [-h maximum_hops] [-j host_list] [-w timeout]
[target_name]
```

Example: tracert 200.286.0.32

- 3 Press Enter.

Result: The system runs the `tracert` utility.

- 4 Type **Exit** to exit the Command Prompt window and return to Windows.

The arp command

The `arp` command displays and modifies the IP-to-physical address translation tables used by Address Resolution Protocol (ARP).

ARP command syntax

The ARP command uses the following syntax:

```
arp -s inet_addr eth_addr [if_addr]
```

```
arp -d inet_addr [if_addr]
```

```
arp -a [inet_addr] [-N if_addr]
```

ARP command parameters

Table 5: ARP command parameters

Parameter	Description
-a	Displays current arp entries by interrogating the current protocol data. If <code>inet_addr</code> is specified, the IP and physical addresses for only the specified computer appear. If more than one network interface uses arp, entries for each arp table appear.
-g	Same as -a.
<code>inet_addr</code>	Specifies an Internet address.
<code>if_addr</code>	Specifies the Internet address of the interface where the address translation table should be modified. If not present, the first applicable interface is used.
<code>eth_addr</code>	Specifies a physical address.

Parameter	Description
-N if_addr	Displays the arp entries for the network interface specified by if_addr.
-d	Deletes the host specified by inet_addr.
-s	Adds the host and associates the Internet address inet_addr with the physical address eth_addr. The physical address is given as six hexadecimal bytes separated by hyphens. The entry is permanent.

To run the arp command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
- 2 At the Command prompt, type **arp** with the required parameters (for example, arp -g 200.286.0.32).
- 3 Press Enter.
Result: The system runs the arp command.
- 4 Type **Exit** to exit the Command Prompt window and return to Windows.

The nbtstat command

The nbtstat command displays protocol statistics and current TCP/IP connections using NBT.

Nbtstat command syntax

The nbtstat command uses the following syntax:

```
nbtstat [-a remotename] [-A IP address] [-c] [-n]
        [-R] [-r] [-S] [-s] [interval]
```

nbtstat command parameters**Table 6: nbtstat command parameters**

Parameter	Description
-a remotename	Lists the remote computer name table using its name.
-A IP address	Lists the remote computer name table using its IP address.
-c	Lists the contents of the NetBIOS name cache giving the IP address of each name.
-n	Lists local NetBIOS names. Registered indicates that the name is registered by broadcast (Bnode) or WINS (other node types).
-R	Reloads the LMHOSTS file after purging all names from the NetBIOS name cache.
-r	Lists name resolution statistics for Windows networking name resolution. On a Windows computer configured to use WINS, this option returns the number of names resolved and registered through broadcast or through WINS.
-S	Displays both client and server sessions, lists the remote hosts by IP address only.
-s	Displays both client and server sessions and attempts to convert the remote host IP address to a name using the HOSTS file.
interval	Displays selected statistics, pausing interval seconds between each display. Press Ctrl+C to stop displaying statistics. Without this parameter, nbtstat prints the current configuration information once.

To run the nbtstat command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.

Result: The Command Prompt window appears.

- 2 At the Command prompt, type **nbtstat** with the required parameters.

- 3 Press Enter.

Result: The system runs the nbtstat utility.

- 4 Type **Exit** to exit the Command Prompt window and return to Windows.

The netstat command

The netstat command displays current TCP/IP network connections and protocol statistics.

Netstat command syntax

The netstat command uses the following syntax:

```
netstat [-a] [-e] [-n] [-s] [-p proto] [-r] [interval]
```

netstat command parameters

Table 7: netstat command parameters

Parameter	Description
-a	Displays all connections and listening ports.
-e	Displays Ethernet statistics. This can be combined with the -s option.
-n	Displays addresses and port numbers in numeric form.
-s	Displays statistics for each protocol.
-p proto	Shows connections for the protocol specified by proto. Proto can be TCP or UDP. If used with the -s option, proto can be TCP, UDP, or IP.
-r	Displays the contents of the routing table.
interval	Redisplay selected statistics, pausing between each display. Press Ctrl+C to stop redisplaying.

To run the netstat command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
- 2 At the Command prompt, type **netstat** with the required parameters.

3 Press Enter.

Result: The system runs the netstat utility.

4 Type **Exit** to exit the Command Prompt window and return to Windows.

Using the chkdsk utility

The chkdsk utility checks a specified disk on the server and displays a status report. You can run the utility on drives C, D, E, or F. It is an online utility, but it reduces system performance while it is running.

The chkdsk utility checks for errors at the Windows file system level. CallPilot can be affected by errors at both the Windows and CallPilot file system levels. The chkdsk utility will not detect CallPilot file system level errors.

Note: A version of this utility, called autocheck, automatically runs during Windows startup. Output from this utility appears on the blue startup screen.

Chkdsk utility syntax

The chkdsk utility uses the following syntax:

```
chkdsk [drive:][path]filename] [/F] [/V] [/R]
```

Chksdsk utility parameters

Table 8: Chksdsk utility parameters

Parameter	Description
drive:	Drive letter of the drive that you want to check.
filename	Names of files to check for fragmentation.
/F	Optional parameter to fix errors on the disk.
/V	Optional parameter to display the full pathname of every file on the disk.
/R	Optional parameter to locate bad sectors and to recover readable information.

To run the chkdsk utility from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.

Result: The Command Prompt window appears.

- 2 At the Command prompt, type **chkdsk <drive letter:>** (for example, chkdsk c:).

- 3 Press Enter.

Result: The system runs the chkdsk utility.

- 4 Type **Exit** to exit the Command Prompt window and return to Windows.

Chapter 5

Using serial port diagnostic tools

In this chapter

Overview	52
Shutting down services	53
Conducting TSTSERIO tests	56
Conducting TSTSERIO tests with the loopback plug	60
Restarting services	61

Overview

You may want to test the serial ports when remote access does not work.

This chapter describes how to run serial port diagnostics on the CallPilot server using the TSTSERIO command. Direct the TSTSERIO command to serial ports on the server after services on these ports have been shut down manually, as described in this chapter.

Shutting down services

This section describes how to shut down a service using a specific serial port. Use the following procedures before you invoke the TSTSERIO local loopback tests.



CAUTION**Risk of communications loss**

By stopping the services on COM1 or COM2, you lose the support access feature.



CAUTION**Risk of stopping call processing**

By stopping the services on COM2, you stop call processing on CallPilot.

Services to stop for COM1 testing

- Routing and Remote Access

Services to stop for COM2 testing

- CallPilot SLEE Service
- CallPilot MWI Service
- CallPilot Access Protocol Emulator
- CallPilot Blue Call Router
- CallPilot Call Channel Router
- CallPilot Time Service
- Routing and Remote Access

Net Stop command

Use the Net Stop command to stop a specified service on a serial port.

Net stop command syntax

The Net Stop command uses the following syntax:

```
net stop <service_name>
```

ATTENTION

You must restart the services that you shut down through the Net Start command after you run the diagnostic. For details, see “Restarting services” on page 61.

To invoke the Net Stop command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
- 2 At the Command prompt, type **net stop “*service_name*”**, and then press Enter.
Note: The quotation marks are required, as in the example above.
Result: The system runs the Net Stop command utility.
- 3 Type **Exit**, and then press Enter to exit the Command Prompt window.

Service Control (SC) command

Use the Service Control command to stop a specified service on a serial port.

Service Control command syntax

The Service Control command uses the following syntax:

```
sc <service_name>
```

ATTENTION

You must restart the services that you shut down through the Service Control command after you run the diagnostic. For details, see “Restarting services” on page 61.

To invoke the Service Control command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
- 2 At the Command prompt, type **sc stop “service_name”**, and then press Enter.
Note: The quotation marks are required, as in the example above.
Result: The system runs the Service Control command utility.
- 3 Type **Exit**, and then press Enter to exit the Command Prompt window.

Conducting TTSERIO tests

The TTSERIO command performs local loopback tests of the serial communication ports from the server run-time environment.

Note: Before conducting these tests, shut down the appropriate services. See “Shutting down services” on page 53.



CAUTION

Risk of communications loss

By stopping the services on COM1 or COM2, you lose the support access feature.



CAUTION

Risk of stopping call processing

By stopping the services on COM2, you stop call processing on CallPilot.

TTSERIO command syntax

The syntax for the TTSERIO command is as follows:

```
TTSERIO [/?] /P:comport [/S:substname] [/L:loops]
```

TTSERIO command parameters

Table 9: TTSERIO command parameters

Flag	Requirement	Description
?	n/a	Displays Help.

Flag	Requirement	Description
/P:comport	Required	Specifies the symbolic port name assigned to the port you want to test.
/S:substname	Optional	Specifies a TSTSERIO subtest. See the following table for a description of the available subtests.
/L:loops	Optional	Specifies the number of times (up to a maximum of 65 535) to execute the requested test. The default number of tests is 1. A value of 0 infinitely loops until you enter Ctrl+C.

TSTSERIO internal loopback diagnostic subtests

The following internal loopback subtests are available for the TSTSERIO command. For each of these tests, the communications resource must be available.

Table 10: TSTSERIO internal loopback subtests

Subtest name	Description
idat	Internal data bus loopback
imsr	Internal modem status register
baud	Internal data bus loopback at various baud rates
word	Test 5-, 6-, 7-, and 8-bit data lengths
stop	Test 1, 1.5, and 2 stop bits
pari	Test odd/even parity
fifo	Test that device can operate in fifo mode

To invoke the TSTSERIO /P command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.

Result: The Command Prompt window appears.

- 2 At the Command prompt, type **tstserio** with the required parameters, and then press Enter.

For example, type **TSTSERIO /P com1** or **TSTSERIO /P com 2**, and then press Enter.

- 3 Type **Exit**, and then press Enter to exit the Command Prompt window.

TSTSERIO external loopback plug subtests

The following external loopback subtests are available for the TSTSERIO command. For each of these tests, an external loopback connector must be used. For more information, see “Conducting TSTSERIO tests with the loopback plug” on page 60

Table 11: TSTSERIO external loopback plug subtests.

Subtest name	Description
edat	External data bus loopback. This test requires an external loopback connector.
emsr	External modem status register. This test requires an external loopback connector.
eint	Test ability of device to generate interrupts. This test requires an external loopback connector.

To invoke the TTSERIO /S command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
- 2 At the Command prompt, type **ttserio** with the required parameters, and then press Enter.
For example, type **TTSERIO /P com1 /S extr**, and then press Enter.
- 3 Type **Exit**, and then press Enter to exit the Command Prompt window.

Conducting TSTSERIO tests with the loopback plug

The TSTSERIO command requires an external loopback connector plug for its edata, emsr, and eint subtests.

9-pin connector plug

The standard serial loopback connector is a female 9-pin D-sub connector. This connector has the following pins wired together:

- CTS (pin 8) wired to RTS (pin 7)
- SIN (pin 2) wired to SOUT (pin 3)
- DTR (pin 4) wired to DSR (pin 6)

Once the plug is installed on the serial port, TSTSERIO can be invoked according to the procedure outlined in the previous section.

Restarting services

This section describes how to restart the services for COM1 or COM2 after invoking the TSTSERIO local loopback tests.

Services to restart after COM1 testing

- Routing and Remote Access

Services to restart after COM2 testing

- CallPilot SLEE Service
- CallPilot MWI Service
- CallPilot Access Protocol Emulator
- CallPilot Blue Call Router
- CallPilot Call Channel Router
- CallPilot Time Service
- Routing and Remote Access

Net Start command

Use the Net Start command to restart a specified service on a serial port. The syntax for the Net Start command is as follows:

```
net start <service name>
```

To invoke the Net Start command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
- 2 At the Command prompt, type **net start** “*service_name*”, and then press Enter.
Note: The quotation marks are required, as in the example above.
- 3 Type **Exit**, and then press Enter to exit the Command Prompt window.

Service Control Start command

Use the Service Control Start command to restart a specified service on a serial port. The syntax for the Service Control Start command is as follows:

```
sc <service name>
```

To invoke the Service Control Start command from Windows

- 1 Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
- 2 At the Command prompt, type **sc start** “*service_name*”, and then press Enter.
Note: The quotation marks are required, as in the example above.
- 3 Type **Exit**, and then press Enter to exit the Command Prompt window.

Chapter 6

Using CallPilot Manager to monitor hardware

In this chapter

Understanding fault management	64
Alarm Monitor	67
Event Browser	69
Channel and Multimedia Monitors	71
The Maintenance screen	72
Viewing component states	76
Starting and stopping components	79
Running integrated diagnostics	83
Viewing the last diagnostic results	86
Working with the Multimedia Monitor	88
Working with the Channel Monitor	90

Understanding fault management

Fault management is a term that describes how the CallPilot server detects and notifies you of potential or real hardware problems (faults). The server processes events to detect hardware problems and raises alarms to notify you when these problems occur.

Event processing

An event is any change in system configuration or operational state. An event is also any action taken by the system that requires user notification. Events can be as insignificant as a user logon attempt or as serious as a faulty MPB96 card switching to disabled status.

All events are reported to the fault management server, a subsystem within the CallPilot server. The fault management server enables the CallPilot server to listen and respond to its clients. The interaction is called event processing and is the means by which the server detects hardware faults.

Alarm notification

Alarms are warnings generated by events. Alarms communicate the same information as events. However, alarms are reported in the Alarm Monitor instead of the Event Browser, and are managed differently than events.

When an alarm appears in the Alarm Monitor, you must investigate the problem, isolate it, and then fix the cause of the problem. When you fix the problem, the alarm is cleared from the Alarm Monitor.

Component dependencies

The status of some components are dependent on the operational status of other components. If a component fails or is stopped, the dependent components go out of service.

Note: Based on the CallPilot server type, and the type of switch connected to CallPilot, some of these components may not appear on your system.

Component	Dependent components
Media Bus	All MPBs, all multimedia channels, and all call channels.
MPB board	All multimedia and call channels associated with the MPB board.
Time Switch	All multimedia and call channels associated with the same MPB as the time switch.
MPB96	All multimedia channels on the MPB96 card.
DS30X	All DS30X channels associated with the DS30X link.
T1 board	Telephony Interface. All DS0 (zero) channels associated with the telephony interface.

Detecting hardware problems

Typically, you first become aware of a hardware problem when an alarm is raised. All hardware faults produce an alarm (or series of alarms, depending on the problem) in the Alarm Monitor.

Other indications of a hardware problem include the following:

- user complaints

- call processing difficulties, such as busy signals, static, dropped calls, connection problems, and cross talk (hearing other conversations)
- system administrator logon difficulties
- alert icons on the Maintenance screen

Alarm Monitor

Use the Alarm Monitor to investigate one or more raised alarms.

About alarms

Alarms are warnings generated by events. Alarms communicate the same information as events. However, alarms are reported in the Alarm Monitor instead of the Event Browser, and are managed differently than events:

- Alarms appear in the Alarm Monitor only for Minor, Major, and Critical events (not Information events). All events can be reported in the Event Browser (depending on filtering criteria defined in the Event Browser).
- The first time an event occurs, it generates an alarm that appears in the Alarm Monitor. If the same event continues to occur, a new alarm is not generated. Instead, the time and date assigned to the original generated alarm is updated.
- Alarms can be cleared from the Alarm Monitor, but the event that generated the alarm is not cleared from the event log or the Event Browser.


Each alarm in the Alarm Monitor has Help text that often provides a solution to the problem. If the solution is not apparent, use the Event Browser or the Maintenance screen to further investigate the problem.

To investigate using the Alarm Monitor

- 1 Run CallPilot Manager and log in.
- 2 In CallPilot Manager, click System → Alarm Monitor.

Result: The Alarm Monitor screen appears.

Figure 4: Alarm Monitor screen



- 3 Click the Event Code for the first Critical or Major alarm.

Result: A description of the event appears in a new web browser window.

- 4 Review the description and recovery action.
- 5 Repeat steps 3 and 4 for more alarms, if necessary.
- 6 If the solution to the problem is not apparent, obtain the return code of the first event and continue the investigation by using the Event Browser (see “Event Browser” on page 69).

Event Browser

Use the Event Browser to investigate a series of events that occurred around the time an alarm was raised. The event listing can help you determine the root cause of a problem.

About events

The Event Browser displays events that have been recorded in the server log. Each event identifies the time the event occurred, the object that generated the event, and the cause of the event.


Events are classified as Information, Minor, Major, or Critical. By default, the Event Browser displays only the latest 100 critical events.

To investigate using the Event Browser

- 1 Run CallPilot Manager and log in.
- 2 In CallPilot Manager, click System → Event Browser.

Result: The Event Browser screen appears.

Figure 5: Event browser screen



- 3 Click an event that appears to be related to the problem, or an event that occurred near the time the alarm was raised.

Result: A description of the event appears in a new web browser window.

- 4 View the description and recovery action.
- 5 Repeat steps 3 and 4 for more events, if necessary.
- 6 If the solution to the problem is not apparent, contact your Nortel technical support representative.

Note: For information on how to use the Event Browser refer to the CallPilot Manager online Help.

Channel and Multimedia Monitors

The Channel Monitor shows the status of call channels. The call channels are the connections between the server and the switch that carry the call signals to CallPilot.

The Multimedia Monitor shows the status of multimedia channels. The multimedia channels are the DSP ports that process the calls. They are the voice, fax, and speech recognition channels.

Disabling call channels

If you must take the CallPilot system out of service to perform software or hardware maintenance, Nortel recommends that you disable all call channels first. There are two ways to disable the call channels:

- **Courtesy stop the channels (preferred method).**
When you courtesy stop call channels, CallPilot waits until the channels are no longer active before disabling them, instead of suddenly terminating active calls.
- **Stop the channels.**
When you stop channels, you suddenly disable them and terminate all active calls.

The Maintenance screen

Use the Maintenance screen in CallPilot Manager to do the following:

- Obtain general information about components.
- View component states.
- Start and stop components.
- Run integrated diagnostic tests.
- View the results of the last diagnostic test run against a component.


What the Maintenance screen provides

The Maintenance screen identifies the server platform and switch connectivity type. It also provides a tree that, when expanded, lists the physical and logical hardware components down the left side of the screen. To list the server hardware components, click the plus sign (+) at the top of the tree. To list the subcomponents for each component, click the plus sign (+) beside the component.

Note: The components that are listed on the Maintenance screen are based on the CallPilot server type and the switch that is connected to CallPilot. The examples in this chapter are for illustration purposes and may not appear exactly the same on your system.

Figure 6 on page 73 shows a partially expanded tree for the 1002rp server.

Figure 6: Partially expanded tree for 1002rp



When you click a component, the screen refreshes to show the details about that component. Details are divided into the sections described in the following table.

Table 12: Component sections

Section	Description
General	<p>This section shows general technical information about the selected component. This typically includes the following details:</p> <ul style="list-style-type: none"> ■ the name, class, type, series, or version of a component ■ various capabilities of a component (for example, whether a component is removable) <p>Note: This section does not appear for all components.</p>
Maintenance	<p>This section shows the state of the selected component. Use this section to start and stop a component before running a diagnostic test.</p> <p>This section appears only for components on which you are allowed to perform maintenance administration.</p> <p>For more information about working with component states, see the following sections:</p> <ul style="list-style-type: none"> ■ “Viewing component states” on page 76 ■ “Starting and stopping components” on page 79
Diagnostics	<p>Use the Diagnostics section to run one or more diagnostic tests, or to view the results of the last diagnostic tests that were run on the selected component.</p> <p>This section appears only for components on which you are allowed to run diagnostics.</p> <p>For more information about running diagnostics, see the following sections:</p> <ul style="list-style-type: none"> ■ “Running integrated diagnostics” on page 83 ■ “Viewing the last diagnostic results” on page 86

Maintenance activities for each component

The following table identifies the maintenance activities you can perform for each component that is listed in the component tree.

Table 13: Maintenance activities

Component	Start, stop?	Courtesy stop?	Diagnostics available?	Replaceable ?
Media Bus	Yes	No	No	No
MPB96 board	Yes	No	Yes	Yes
Time Switch	No	No	No	No
MPCs (embedded on MPB boards)	Yes	No	Yes	embedded: No
Multimedia channels	Yes	Yes	No	No
Call channels	Yes	Yes	No	No
DS30X link	Yes	No	No	No

Note: The MGate card and DS30X cable are replaceable. If you are having problems with the DS30X link, determine if either one or both of these items are causing the problem and need to be replaced.

Viewing component states

View a component state to determine the general condition of the component, including whether the component is disabled or off duty. The component state is shown in the Maintenance section of the Maintenance screen.

Component states

You can determine the state of a component by looking at the State box in the Maintenance section.

State	Description
Active	The component is working and currently involved in processing a call.
Disabled	The diagnostic failed.
Idle	The component is working but not currently involved in processing a call.
InTest	A diagnostic is running on the resource or device.
Loading	The component has been started, which takes it out of the Off Duty state. This state occurs quickly and is immediately followed by Idle.
Local (Red) Alarm	A Receive Loss of Synchronization error occurred on incoming data over a T1 link and lasted more than 2.5 seconds. This condition will exist until synchronization is recovered and remains recovered for 12 seconds.
No resources	The hardware required for the component to operate is not installed or is not operating properly.

State	Description
Not Configured	The device is not configured in CallPilot. For example, a DSP is not being used because it was not allocated in the Configuration Wizard.
Off Duty	The component has been stopped.
Remote Off Duty	The component has been taken out of service at the switch.
Remote (Yellow) Alarm	A red alarm exists at the receiving device. This alarm is sent by the receiving T1 device to CallPilot, and it remains in effect until the red alarm is cleared at the receiving device.
Shutting Down	The component is in the process of stopping. This state occurs quickly and is immediately followed by Off Duty.
Uninitiated	The call processing component has not initialized the resource.

Alert icons

If one of the following icons appears next to a component in the tree, then the component or one of its subcomponents is experiencing a problem.:

Icon	Description
	A problem exists with a subcomponent of the selected component. Expand the tree to locate the subcomponent with the problem.
	A problem exists with the selected component.

To view the state of a hardware component

- 1 Run CallPilot Manager and log in.
- 2 In CallPilot Manager, click Maintenance → Maintenance Admin.
Result: The Maintenance screen appears.
- 3 Click the plus sign (+) beside the CallPilot server to expand the component tree.
- 4 Continue clicking the plus sign (+) until the component with which you want to work is visible.
- 5 Click the hardware component with which you want to work.
Result: The Maintenance screen refreshes to show details about the component.
- 6 Scroll down to the Maintenance section.
- 7 View the state of the selected component in the State box.

Starting and stopping components

When you stop a component, you take it out of service and prevent it from operating. You must stop a component before you can replace it (if the component is replaceable) or run a diagnostic test on it.

To bring an out-of-service component back into service, you must start it.

Start and stop components from the Maintenance section on the Maintenance screen.

ATTENTION

Nortel recommends that, if possible, you courtesy stop a component. Courtesy stop is available only at the individual channel level.

To courtesy stop CallPilot, use the following:

- Multimedia Monitor - to courtesy stop a range of multimedia channels
- Channel Monitor - to courtesy stop a range of call (DS30X, also known as DS0) channels

Stop versus courtesy stop

The following two methods of taking a component out of service allow you to choose how active calls are affected.

Courtesy stop

A courtesy stop takes the component out of service only after the component has finished processing an active call.

- If the component is currently processing a call, the call is not dropped; the component remains active until the call is finished.
- If the component is not currently in use, it is taken out of service immediately.

Courtesy stop is the preferred method for taking a component out of service.

Stop

A stop takes the component out of service immediately, regardless of whether the component is currently processing calls. All active calls are dropped. Typically, you perform a stop only when severe problems that are affecting a large number of incoming calls occur or if your organization determines a special need for it.

Components that can be started and stopped

Only the following components can be started and stopped.

Note: If you want to start or stop more than one or two multimedia (DSP) or call (DS30X) channels, use the Multimedia Monitor or Channel Monitor.

Component	Effect of stopping
Media Bus	Takes all call processing resources out of service.

Component	Effect of stopping
MPB board	Takes all call processing resources on the selected board out of service.
Time Switch	You cannot perform maintenance administration on the time switch.
Multimedia Channel	Takes the selected Multimedia Channel out of service.
Channels	Takes the selected DS30X channel out of service.
DS30X link	Takes the selected DS30X link out of service.

To start or stop a component

- 1 Run CallPilot Manager and log in.
- 2 In CallPilot Manager, click Maintenance → Maintenance Admin.
Result: The Maintenance screen appears.
- 3 Click the plus sign (+) beside the CallPilot server to expand the component tree.
- 4 Continue clicking the plus sign (+) until the component with which you want to work is visible.
- 5 Click the hardware component that you want to start or stop.

Result: The Maintenance screen refreshes to show details about the component.

- 6 Scroll down to the Maintenance section.
- 7 Click Courtesy Stop, or Start as required.

Button	Description
Start	If the selected component is out of service, click this button to put it into service.
Courtesy Stop	Click this button to take the selected component out of service. CallPilot waits for calls to be completed before disabling the component. ATTENTION If you are courtesy stopping all components (that is, you are taking the entire system down), ensure that you inform all administrators, desktop messaging users, and web messaging users so that they can log off their sessions before you proceed. The system asks you to confirm the courtesy stop. If you click OK, the component is put out of service after all calls are finished.
Stop	Click this button to take the selected component out of service immediately. All calls that are in progress are disconnected immediately. ATTENTION If you are stopping all components (that is, you are taking the entire system down), ensure that you inform all administrators, desktop messaging users, and web messaging users so that they can log off their sessions before you proceed.

Running integrated diagnostics

Run diagnostic tests from the Diagnostics section on the Maintenance screen in the following circumstances:

- You want to ensure that a component is operating properly after installing or reinstalling it.
- The CallPilot server is having trouble processing incoming calls and you are hoping that diagnostic results can tell you why.
Problems include static, dropped calls, and cross talk (hearing another conversation).

Before you begin

ATTENTION

Take the component out of service before you run the diagnostic test. See “Starting and stopping components” on page 79.

Components that have diagnostic tests available

The following table identifies the components on which you can run diagnostics.

Component	Diagnostics available?	Replaceable?
Media Bus	No	No
MPB96 board	Yes	Yes
Time Switch	No	No
Multimedia Channels	No	No
Channels	No	No

Component	Diagnostics available?	Replaceable?
DS30X link (cable)	No	Yes

Diagnostic tests available for each component

The diagnostic tests that are available for each component are listed in the Diagnostic section of the Maintenance screen. To view the list of diagnostic tests for a particular component, click the component in the component tree.

If a diagnostic test fails or cannot be run

If a warning message appears, the diagnostic test cannot be run because a prerequisite condition has not been met. If a diagnostic test fails, a message appears in a new browser window (see the example on screen 85).

In both cases, check the Alarm Monitor to determine the reason and the appropriate action to take.

If the Alarm Monitor and Event Browser do not provide a solution to a hardware problem, you may need to replace or service a component. If the problem is with a component that is not replaceable because it is not a physical entity (such as the Time Switch), you must either replace its parent component or contact your Nortel technical support representative, depending on the component.

To run a diagnostic test

ATTENTION

Nortel recommends that you courtesy stop rather than stop a component if possible. For instructions, see “Starting and stopping components” on page 79.

- 1 Run CallPilot Manager and log in.
- 2 In CallPilot Manager, click Maintenance → Maintenance Admin.
Result: The Maintenance screen appears.
- 3 Click the plus sign (+) beside the CallPilot server to expand the component tree.
- 4 Continue clicking the plus sign (+) until the component with which you want to work is visible.
- 5 Click the hardware component for which you want to run diagnostics.
Result: The Maintenance screen refreshes to show details about the component.
- 6 Scroll down to the Maintenance section, and ensure that the component is out of service.
- 7 Scroll down to the Diagnostics section.
- 8 Select the check box for each diagnostic that you want to run.
Note: If you want to run all of the diagnostics, select the Diagnostic Description check box at the top of the list.
- 9 Click Run.
Result: A new web browser window opens to display the progress and results of the diagnostics.
Note: The Diagnostic Results box in the Diagnostics section displays diagnostic results when you click Get Last Result.

Viewing the last diagnostic results

You can review the results of diagnostics by clicking the Get Last Results button for a component.

To view the last diagnostics result

ATTENTION

Nortel recommends that you courtesy stop rather than stop a component if possible. For instructions, see “Starting and stopping components” on page 79.

- 1 Run CallPilot Manager and log in.
- 2 In CallPilot Manager, click Maintenance → Maintenance Admin.
Result: The Maintenance screen appears.
- 3 Click the plus sign (+) beside the CallPilot server to expand the component tree.
- 4 Continue clicking the plus sign (+) until the component with which you want to work is visible.
- 5 Click the hardware component for which you want to run diagnostics.
Result: The Maintenance screen refreshes to show details about the component.
- 6 Scroll down to the Diagnostics section.
- 7 Select the check box for each diagnostic for which you want to review results.
- 8 Click Get Last Result.

Result: The results appear in the Diagnostic Results box with the following information:

- diagnostic title

- diagnostic result: pass or fail
- the date and time the test was completed

Working with the Multimedia Monitor


The Multimedia Monitor shows the status of multimedia channels. The multimedia channels are the DSP ports that process the calls. They are the voice, fax, and speech recognition channels.

To view or work with multimedia channel states

- 1 Run CallPilot Manager and log in.
- 2 In CallPilot Manager, click Maintenance → Multimedia Monitor.

Result: The Multimedia Monitor screen appears, showing the channels associated with each DSP.

Figure 7: Multimedia monitor screen



Note: For an explanation of the channel states, refer to the CallPilot Manager online Help.

3 Do one of the following:

IF you want to stop or start	THEN
all of the channels associated with a DSP	select the check box to the left of the DSP that you want to stop or start. Repeat this step for each DSP.
only one or several channels that are associated with a DSP	select the check box for each channel that you want to stop or start.

4 Click Courtesy Stop or Start, as required.

Result: If you clicked Courtesy Stop or Start, you are asked to confirm the Courtesy Stop or Start. Click OK.

The selected channels change to off-duty or idle status, according to the action you chose.

Note: If the buttons are not available, wait a few seconds for the screen to refresh.

Working with the Channel Monitor


The Channel Monitor shows the status of call channels. The call channels are the connections between the server and the switch that carry the call signals to CallPilot.

To view or work with call channel states

- 1 Run CallPilot Manager and log in.
- 2 In CallPilot Manager, click Maintenance → Channel Monitor.

Result: The Channel Monitor screen appears, showing the DS30X (also known as DS0) channels associated with each DS30X link.

Figure 8: Channel monitor screen



Note: For an explanation of the channel states, refer to the CallPilot Manager online Help.

3 Do one of the following:

IF you want to stop or start

THEN

all of the channels associated with a DS30X link

select the check box to the left of the DS30X link that you want to stop or start.

Repeat this step for each DS30X link.

only one or several channels that are associated with a DS30X link

select the check box for each channel that you want to stop or start.

4 Click Courtesy Stop or Start as required.

Result: If you clicked Courtesy Stop or Start, you are asked to confirm the Courtesy Stop or Start. Click OK.

The selected channels change to off-duty or idle status, according to the action you chose.

Note: If the buttons are not available, wait a few seconds for the screen to refresh.

Chapter 7

Using CallPilot system utilities

In this chapter

Overview	94
Diagnostics Tool	95
PEP Maintenance utility	97
Session Trace	98
System Monitor	101

Overview

The following table lists the CallPilot system utilities.

Utility	Description
Diagnostics Tool	Allows CallPilot startup diagnostics to be enabled or disabled (turned on or off).
PEP Maintenance	Displays a list of installed PEPs and enables PEP removal.
Session Trace	Displays detailed information about the activity in a user's mailbox and the state of the message waiting indicator (MWI).
System Monitor	Displays the following information: <ul style="list-style-type: none">■ the status of all CallPilot channels■ the status of all CallPilot services <p>Note: This status is more accurate than the status that Windows provides in the Services Control Panel.</p> <ul style="list-style-type: none">■ particulars about the CallPilot System, such as names, keycodes, serial numbers, IP addresses, and system numbers

Accessing the system utilities

All CallPilot utilities are accessible from the CallPilot server in the Start → Programs → CallPilot → System Utilities menu.

Diagnostics Tool

The Diagnostics Tool allows you to enable or disable CallPilot startup diagnostics. CallPilot startup diagnostics automatically identify hardware problems that may exist when the system and its services are started. When you disable startup diagnostics, you can save time during system maintenance operations where restarts or call processing services restarts are required. There are three recommended steps:

- Use the Diagnostics Tool to turn off CallPilot startup diagnostics.
- Perform system maintenance.
- Use the Diagnostics Tool to turn on CallPilot startup diagnostics.

To access the Diagnostics Tool

On the Windows desktop, click Start → Programs → CallPilot → System Utilities → Diagnostic Tool.

Result: The Diagnostics Tool window appears.

To enable startup diagnostics

From the Diagnostics Tool window, select Configuration → Maintenance Startup Diag → Enable.

To disable startup diagnostics

ATTENTION

Nortel recommends that you leave the startup diagnostics turned on. When you disable CallPilot startup diagnostics, you prevent CallPilot from automatically identifying hardware problems that may exist when the system and its services are started (for example, DSP, Time Switch, or Media Bus).

On the Diagnostics Tool window, select Configuration → Maintenance Startup Diag → Disable.

PEP Maintenance utility

The PEP Maintenance utility displays a list of all installed PEPs on the server and enables you to uninstall PEPs. For information on installing or uninstalling PEPs, refer to the *Installation and Configuration Task List* (555-7101-210).

To access the PEP Maintenance utility

From the Windows desktop, click Start → Programs → CallPilot → System Utilities → PEP Maintenance Utility.

Result: The DMI Viewer window appears.

To view a list of all installed PEPs

- 1 Click the component for which you want to display the PEP list.
 - 2 Click Show PEPs.
- Result:** A list of all installed PEPs appears in the left pane.
- 3 If you want to review the readme file associated with a PEP, click the PEP, and then click Read.

Result: The readme file opens in Notepad.

Session Trace

The Session Trace tool displays detailed information about the activity in a user's mailbox and the state of the message waiting indicator (MWI). The session information includes

- voice messaging
- call answering
- express messaging activity (messages composed and sent, or left in a mailbox)
- the number of messages played or unplayed at the beginning, middle, and end of a session
- messages and personal distribution lists restored into a mailbox
- the last change to the MWI (turned on or off, or untouched)

This session information allows an administrator or technician to study the state of a user's mailbox and the MWI, and to use that information to follow up on any user complaints. For example, a user may complain that the MWI was on, but no voice messages were in the mailbox when the user logged on. The session information can tell the administrator why the MWI was turned on.

To access the session trace tool

From the Windows desktop, click Start → Programs → CallPilot → System Utilities → Session Trace Tool.

Result: The MCE Session Trace window appears.

To find a session

- 1** From the Session Type drop-down menu, choose the type of session. To display a list of all session types, select All Session Types.
- 2** Enter as much information in the search criteria boxes to identify the session you want to view. To display a list of all users for the selected Session Type, leave the search criteria boxes blank.
- 3** Click Search to initiate the search.
 - a.** If you did not enter any user information, a list of users matching the Session Type appears at the bottom of the window. To select a user from the list, double-click the user name to display session type information.
 - b.** If you selected All Session Types for a user, the session type information appears to the right of the window.
- 4** Double-click the session type to display the session information.

Result: The Session Type information appears at the bottom of the window. The following example shows Call Answering session type information.

Figure 9: Call answering session

The screenshot shows the 'MCE Session Trace' application window. The interface includes a menu bar (File, View, Help), a toolbar with icons for home and help, and a main display area. On the left, there are search filters for Session Type, Last Name, First Name, Mailbox Number, Called DN, Calling DN, Start Date & Time, End Date & Time, and Last Search Time. A 'Search' button is located below these filters. The main display area is divided into two sections: a table of session records and a detailed view of the selected session.

Session Type	Start Time	End Time
Logon OK	15:37:14 Apr 28	15:38:40 Apr 28
MWI Dif	15:38:41 Apr 28	15:38:41 Apr 28
Logon OK	15:39:40 Apr 28	15:40:09 Apr 28
MWI Dif	15:40:10 Apr 28	15:40:10 Apr 28
Call Answering	15:42:30 Apr 28	15:42:40 Apr 28
MWI On	15:42:40 Apr 28	15:42:40 Apr 28
Logon OK	15:42:47 Apr 28	15:43:56 Apr 28
MWI Dif	15:43:11 Apr 28	15:43:11 Apr 28
MWI Dif	15:43:57 Apr 28	15:43:57 Apr 28
Call Answering	15:46:48 Apr 28	15:46:53 Apr 28
MWI On	16:56:24 Apr 28	16:56:24 Apr 28
MWI On	01:30:13 Apr 29	01:30:13 Apr 29
Expired Messages	03:30:09 Apr 29	03:30:09 Apr 29

The detailed view for the selected 'Call Answering' session shows the following information:

- Session Type: Call Answering
- Start Time: 15:42:30 Apr 28
- End Time: 15:42:40 Apr 28
- Session Length: 10 seconds
- Called DN: 8050
- Calling DN: 8051
- Call Origination: Inbound
- Message Length: 1 second
- Message Disposition: Message left

At the bottom of the window, it indicates '43 records found' and a 'NUM' button.

System Monitor

The System Monitor consists of three tabs, as described in the following table.

Table 14: System Monitor tabs

Tab	Description
Channel Monitor	Shows the status of all CallPilot services, multimedia channels, and call channels (DS30X channels).
System Info	Displays details about the CallPilot System, such as features purchased, keycode, serial number, and CallPilot server IP addresses.
Legend/Help	Provides a description of icons and terminologies displayed in the System Monitor window.

System Monitor is a nondestructive tool that does not alter the behavior of any CallPilot components.

To access the System Monitor


On the Windows desktop, click Start → Programs → CallPilot → System Utilities → System Monitor.

Result: The CallPilot System Monitor window appears. By default, the Channel Monitor tab appears on top. Click the other tabs to view the information on those tabs.

Channel Monitor tab


The following is an example of the Channel Monitor tab when connected to an Meridian 1*

Figure 10: Channel Monitor with M1.



The following is an example of the Channel Monitor tab when connected to a T1/SMDI.

Figure 11: channel Monitor with T1/SMDI



CallPilot services

The Service Name pane shows the status of services from a CallPilot perspective. The status shown in the Windows Services Control Panel may state that a service is running, but it may not actually be fully running or in service from a CallPilot perspective. Refer to the System Monitor tool Channel Monitor tab for the true status.

The services listed under Service Name should be either running or in full service when CallPilot is functioning optimally. If any CallPilot services are stopped, investigate the cause of this. Call Nortel technical support for assistance.

Note: While any stopped services should be investigated, some services are not critical. CallPilot may continue to handle call processing even with some services stopped.

The critical services that are required for basic CallPilot call answering are listed in the following table. For your reference, the equivalent names as they appear in the Windows Control Panel are also listed.

CallPilot System Monitor	Windows Control Panel equivalent
CTMS Service	CTMS Server
Telephony (TAPI)	Telephony Service
MCE SLEE	CallPilot SLEE Service
MCE Notification	CallPilot MWI Service
MAS Notification	CallPilot Notification Service
MAS CCR	CallPilot Call Channel Router
MAS BCR	CallPilot Blue Call Router
SQL Anywhere	Adaptive Server Anywhere - %ComputerName%_SQLANY
MAS MltmediaCache	CallPilot Multimedia Cache
MAS MltmediaVol1	CallPilot Multimedia Volume 1
MAS MltmediaVol102 (TRP only)	CallPilot Multimedia Volume 102 (TRP only)
MAS MltmediaVol103 (TRP only)	CallPilot Multimedia Volume 103 (TRP only)
MAS Rsrc. Pckg. 1	CallPilot Resource Package1

DSPs

In the DSP pane, each DSP is represented in a separate row. Each box in the row is one DSP channel or multimedia channel. Click the Legend/Help tab to view descriptions of the multimedia channel icons.

For tower and rackmount CallPilot servers, DSPs reside in MPB96 and MPB16-4 boards and MPC-8 cards. For 1002rp servers, DSPs are distributed as follows:

- MPB96 board has 12 DSP sections embedded on board
- One MPB16-4 board consists of two embedded DSPs and up to four MPC-8 cards.
- Each MPC-8 card contains a single DSP.

DS30X links

In the DS30X link pane, each DS30 row represents a separate DS30X link (also referred to as a DS30 link). Each box in the row represents one DS30X channel.

The DS30X links connect the CallPilot server to the MGate card (NTRB18CA) in the Meridian 1 switch or Succession 1000* system.

For the 1002rp server, the DS30X link to the switch is supported by the connection of the server to the switch backplane.

T1 Links

In the T1 link pane, each row represents a T1 link. Each box in the row represents one DS0 channel.

System Info tab

Figure 12 on page 106 shows an example of the System Info tab.

Figure 12: System info tab

CallPilot System Monitor

Channel Monitor | **System Info** | Legend/Help

1. CallPilot Release: 04.04.04

2. Serial Number: 1111

3. Date Installed:

4. Platform Type: TRP 1002 Rack

5. Switch Type: M1

6. Connectivity: M1 Proprietary CTI

7. Configd DSPs: 36

8. Configd Channels: 186

9. Configd DSOs: 186

10. Voice Channels: 136

11. Fax Channels: 50

12. SR Channels: 0

13. TTS Channels: 20

14. SCCS Integration: No

15. Networking: Yes

16. NMS: Yes

17. AppBuilder Fax: Yes

18. TTS Languages: 10

Installed DSP | Firmware

DSP11-001	NG0253b
DSP11-002	NG0253b
DSP11-003	NG0253b
DSP11-004	NG0253b
DSP11-005	NG0253b
DSP11-006	NG0253b
DSP11-007	NG0253b
DSP11-008	NG0253b

19. SR Languages: 3

20. Prompt Languages: 6

21. Hours of Storage: 2400

22. Desktop Seats: 10000

23. Voice Seats: 10000

24. Keycode: VXY9 LYPV D7KK YA0L 8JET 30K7 CJMJ 35LT

25. SR Seats: 0

26. Fax Seats: 10000

27. TTSSeats: 10000

28. Dongle: 1111

Operating System Info

Windows 2003 Server 5.2

Service Pack 1

Current User: Administrator

Host Name: load1002ip

IP Addresses

47.11.241.95 - CLAN

47.11.237.30 - ELAN

PEPs Installed	Installed (dd/mm/yyyy)
CP404503G05C	15/09/06 13:17
CP404045U03S	15/09/06 12:16

ASDN	Media	Description
52300	Voice	Voice Messaging
52301	Fax	Multimedia Messaging
52302	Voice	Voice Messaging

Refresh | Snapshot


The numbered items provide information about the features purchased. Information about the underlying operating system is provided in the top right corner, including the server IP addresses.

PEP information and configured Service DN's are listed in the bottom part of the window.

Legend/Help tab

Figure 13 on page 107 shows an example of the Legend/Help tab. Consult this window for descriptions of the icons found in the Channel Monitor tab.

Figure 13: Legend/Help tab



Chapter 8

Replacing basic chassis components

In this chapter

Removing the front bezel and server cover	110
Replacing air filters	114
Replacing the power supply	116
Replacing the SCA SCSI drive cage and fused power cable	119
Replacing the cooling fan	126
Replacing the fuse (AC system only)	129
Replacing the alarm board	131
Setting jumpers on the alarm board	133
Replacing the status display panel	136

Removing the front bezel and server cover

If the maintenance task requires replacing front panel components, you must remove the front bezel. The exception is the hard drives, which can be accessed by simply unlocking and opening the front bezel doors.

If you require access to the server interior, remove both the front bezel and the server cover.

Requirements

Before you remove the front bezel and server cover, gather the following tools:

- the customer's chassis keys for the front bezel doors
- a flat-blade screwdriver
- an antistatic wrist strap

About the front bezel doors

Two locked doors on the front of the server cover the front panel, including the CD-ROM drive and tape drive.

These doors are part of the front bezel. You must unlock the front panel doors before you can remove the front bezel.

To remove the front bezel




CAUTION

Risk of equipment damage

Do not attempt to move or lift the server before you have removed the front bezel. If the front bezel is attached, the server can disengage from the front bezel and fall.

Figure 14: Front bezel removed



G101733

- 1 Unlock and open the double doors of the front bezel. See A in Figure 14 on page 111.
- 2 Firmly grasp the front bezel by the hand-holds on either side of the chassis, and pull the front bezel from the chassis. See B in Figure 14 on page 111.

To remove the server cover



DANGER

Risk of electric shock

High current inside the chassis can cause severe injury.



CAUTION

Risk of equipment damage

Take precautions to protect internal components. Electrostatic discharge (ESD) can damage boards and make them unusable. Wear an ESD wrist strap.

- 1 Remove the front bezel.
- 2 Power down the server and disconnect all power cords.
- 3 Loosen the three thumbscrews at the rear of the top cover.
- 4 Remove the server cover by pulling the cover toward the rear of the chassis, and then lifting it up and off.
- 5 Clip the lead from your ESD wrist strap to an unpainted metal section of the chassis.

To replace the front bezel after maintenance is complete

Replacing air filters

To ensure your server cools and functions properly, remove and clean air filters every six months in clean environments and every three months in industrial or dirty environments. If they appear to be damaged or become inefficient, replace the filters. There are four air filters on the 1002rp server—one inside each of the two doors of the front bezel, and two on the top half of the front bezel. They are made of polyester foam material and are flame retardant.

Requirements

You require the customer's chassis keys for the front bezel.

To replace the front bezel air filter

- 1 Remove the front bezel from the chassis. See “To remove the front bezel” on page 111.
- 2 Pull the filters away from the Velcro strips that secure them to the bezel.
- 3 Replace the filter by seating the new filter pads evenly over the Velcro strips and securing them.
- 4 Install and lock the front bezel on the chassis.

To replace the door air filter

- 1 Unlock and open the front doors.
- 2 The air filter is trapped between the inside of the door and the wire. The wire pivots near the key lock. Pull the wire away from the key lock to free the air filter.
- 3 Remove and replace the air filter.

- 4** Pivot the wire to trap the filter, ensuring that the ends of the wires are pinched inside the door.
- 5** Close and lock the doors.

Replacing the power supply

The power supply is hot-swappable. This means that you can replace the power supply without powering down the server.

Requirements

Before you hot-swap a power supply, gather the following tools:

- one flat-blade screwdriver
- one Phillips screwdriver
- one antistatic wrist strap
- the replacement power supply

When to hot-swap the power supply

A green LED indicates that the power supply is working properly. If the green LED on the power supply module is unlit or red, the module is failing or has failed. Other indicators of failure are the alarm that sounds and the power supply module LED on the status display that turns red.

To hot-swap a power supply




DANGER

Risk of electric shock

High current inside the chassis can cause severe injury.

- 1 Loosen the thumbscrews at the top right and left of the failed power supply module (see A in the following diagram).

If needed, use a flat-blade screwdriver. The thumbscrew must rotate freely and not contact the chassis threads.



G101731

- 2 Grasp the molded horizontal handles on the power supply module and pull the power supply module free from the chassis (see B in the preceding diagram).
- 3 Align the replacement module with the empty chassis bay.
- 4 Slide the replacement power supply module into the bay until the module is secured by its connector. Use some force, if necessary.
- 5 Secure the power supply module to the chassis with two thumbscrews at the corners of the power supply faceplate.

Result: The power supply LED illuminates green.

Note: If the LED does not illuminate, remove and reinstall the power supply with more force. If this does not work, contact your Nortel customer support representative.

Replacing the SCA SCSI drive cage and fused power cable

Due to the potential of an over-current condition, Nortel provides a retrofit SCSI power cable kit for the **N0029330** power cable. The kit comprises an improved SCSI power cable, product label, and retrofit procedure.


The cable kit part number for all locations, except EMEA, is **FR029367**. At EMEA locations, use part number **N0029367**.

- Only qualified field technicians who are familiar with CallPilot and RAID should attempt this procedure.
- A full-system backup and RAID drive consistency check must be performed prior to replacing the SCSI power cable. These can both be performed while the server is online.
- If at any step in the procedure, the result is not as indicated, stop and contact your next level of support for assistance before continuing.

To replace the SCSI power cable

- 1 Log into the CallPilot server.
- 2 Launch the MegaRAID client to check the status of the RAID subsystem:
 - a. Click Start → Programs → Power Console Plus → Launch Client.
Result: The Server Selection window appears.
 - b. Select Access Mode → Full Access and click OK.
Result: The MegaRAID Power Console Plus window appears.

Figure 16: MegaRAID Power Console Plus



- 3 Open the Physical Devices window and check the drive pair settings. The table below shows the correct settings.

Table 15: Drive pair settings

LED No	ID	Channel-1	LED No	ID	Channel-2
0	0	ONLIN A01-01	3	0	ONLIN A01-02
1	1	ONLIN A02-01	4	1	ONLIN A02-02
2	2	ONLIN A03-01	5	2	ONLIN A03-02

Note: If your settings do not match those in the table, stop and contact your next level of support for assistance before continuing.

- 4 Check that all drives are marked in green and Online.

Note: If they are not all online, stop and contact your next level of support for assistance before continuing.

- 5 Check the RAID drive consistency:
 - a. Select Check Consistency.
Result: The Logical Drives Configured dialog box appears.
 - b. Use the arrow key to highlight the first drive to be checked.
 - c. Press the space key to select the drive.
 - d. Press F10 to check consistency.
Result: The Do you wish to continue? dialog box appears.
 - e. Click Ok.
Result: The consistency check begins and a status dialog box appears.
 - f. Repeat steps c to e for each drive until all three drives have been checked for consistency. This may take up to 2 hours to complete. If any data consistency errors are detected, they are corrected automatically.
- 6 Perform a full-system backup of the CallPilot server (either to tape or file server).
- 7 Review the backup logs to verify success.
- 8 Perform a controlled shutdown of the CallPilot software:
 - a. Click Ctrl+Alt+Delete and select Shutdown from the Windows Security window.
Result: The Shutdown Computer dialog box appears.
 - b. Select Shutdown.
Result: The CallPilot server turns off.
- 9 Remove power from the system by disconnecting the AC or DC mains.
- 10 Remove the bezel cover from the front of the chassis using the four snaps located at each corner.

Figure 17: Bezel cover on chassis front



- 11** Remove the 4 Phillips-head screws from each corner of the SCSI disk-drive cage

Figure 18: Chassis front with bezel removed.



- 12 Carefully remove the SCSI drive cage from the chassis to provide access to the internal cable assemblies.


Figure 19: SCSI drive cage attached to chassis



Note: An arrow points to the SCSI power cable in the picture above.

- 13 Unplug the original power cable from the SCA backplane and from the T board inside the chassis. The power cable is schematically shown in Figure 20 on page 124.

Figure 20: SCSI power cable attached to T board



- Note:** Leave all other cable assemblies connected. Do not damage or disconnect other components on the SCA backplane.
- 14 Replace the original SCSI power cable with the new cable. Securely attach it to both the SCA backplane and the T board inside the chassis.
 - 15 Reinstall the SCSI drive cage into the bay and screw it into place. Torque the screws at 6 to 8 inch lbs.
 - 16 Affix a revised product label above the existing labels on the left rear of the chassis.

Figure 21: Product label location on chassis



- 17 Replace the bezel cover on the front of the chassis.
- 18 Reconnect the AC or DC mains power.
- 19 Reboot the CallPilot server and bring it into full service.

Replacing the cooling fan

The cooling fan is hot-swappable, so you can replace the cooling fan without powering down the server.

When to hot-swap the cooling fan

When the LED associated with a cooling fan turns red, the fan requires replacement.



CAUTION

Risk of equipment damage


Use an ESD wrist strap to protect static-sensitive components.

To hot-swap a cooling fan

- 1 Remove the front bezel.
- 2 Use the front panel display LED to locate the defective fan.
- 3 Loosen the thumbscrew located on the outside of the failed cooling fan module (see A Figure 22 on page 127).

If needed, use a flat-blade screwdriver. The thumbscrew must rotate freely and not contact the chassis threads.

Figure 22: Cooling fan thumbscrew



G101728

- 4 Unseat the cooling fan module by sliding the module horizontally away from the display and toward the rack rail (see B in the diagram).
- Result:** The module power connector unseats from the power connector located behind the display and LEDs.
- 5 Slide the failed cooling fan module out of the chassis (see C in the diagram).
 - 6 Align the replacement cooling fan module tabs with the four support slots on the chassis.

Ensure that the module is oriented with the thumbscrew, and insert the tabs into the supporting slots of the chassis.

- 7 Slide the cooling fan module toward the front panel display and into position.

Result: The fan module connects with slight resistance. The fans rotate and pull air into the chassis. The cooling fan LED goes out.

- 8 Tighten the module thumbscrew and replace the front bezel.

Replacing the fuse (AC system only)

The fuse is located below the power input socket on the rear panel. When the server fuse blows, the server stops operating.



CAUTION

Risk of equipment damage and personal injury

Disconnect power from the server before replacing a fuse.

Requirements


You require the following:

- an approved fuse for replacement
Two different types of fuses exist: one for North America, and one for international use. Ensure that the fuse you are replacing has been approved by Nortel for your region.
- a flat-blade screwdriver

To replace the fuse

- 1 Power off the server.
- 2 Unplug the power cable from the wall outlet.
- 3 Unplug the power cable from the power input socket on the server.
- 4 Unscrew the fuse receptacle (see A in Figure 23 on page 130).

Figure 23: Fuse receptacle



G101732

- 5 Slide the fuse receptacle out of the fuse chamber.
Note: Observe how the blown fuse is positioned in the receptacle.
- 6 Remove the blown fuse from the fuse receptacle.
- 7 Install the approved replacement fuse. Use a flat-blade screwdriver to screw in the fuse receptacle with a push and 1/4 clockwise turn.
- 8 Slide the fuse receptacle back into its chamber.
- 9 Fasten the fuse receptacle with a flat-blade screwdriver.
- 10 Plug the power cable back into the power input socket on the server.
- 11 Plug the power cable into the wall outlet.
- 12 Power on the server.

ATTENTION

If the fuse blows after replacement, swap one power supply module with the other. If this does not work, call your Nortel customer support representative.

Replacing the alarm board

The 1002rp server alarm board and status panel are used to monitor and indicate the server status. The basic hardware check on page 23 fails if the board is defective or damaged. When these units are damaged, replace them immediately.



CAUTION

Risk of equipment damage

Take precautions to protect computer boards. ESD can damage boards and make them unusable. Wear an ESD wrist strap.

Requirements

Before replacing the alarm board or panel display, gather the following tools:


- a Phillips screwdriver
- an antistatic wrist strap
- the replacement components

To replace the alarm board

- 1 Power off the server.
- 2 Loosen the two thumbscrews securing the faceplate to the left of the 1002rp server power supply modules (see A in Figure 24 on page 132).

If needed, use a flat-blade screwdriver. The thumbscrew must rotate freely and not contact the chassis threads.

Figure 24: Alarm board carrier



G101729


- 3 Pull the carrier free from the chassis (see B in Figure 24 on page 132).
- 4 The alarm board is secured to the carrier by two Phillips-head screws. Remove the defective alarm board from the carrier.
- 5 Secure the replacement alarm board to the carrier using two Phillips-head screws.
- 6 Align the carrier with the chassis and slide the board into the chassis.
Note: The card encounters some resistance as it meets the connector.
- 7 Tighten the thumbscrews to secure the faceplate to the chassis.

Setting jumpers on the alarm board

The jumpers on the alarm board enable or disable sensing and display functions. This section describes the features that are enabled or disabled by setting jumpers on the alarm board.

The default and recommended setting is to have only JP3 jumpered (see Figure 25 on page 134). This setting enables normal sensing and LED display.

Figure 25: Jumpers on alarm board



G101730

Jumper descriptions

JP6—do not change

Leave the jumper installed on JP6.

JP5—Disarming no power in the bottom bay

If you are operating with one power supply, you can disable sensing of no power from the bottom power supply. To do this, install a jumper on jumper block 1, JP5.

Ensure that the functioning power supply is installed in the upper power bay.

JP4

Not used.

JP3—LED display

Install a jumper on jumper block 1, JP3, to configure the alarm board to send alarm signals to the full array of LEDs. This is the default setting and the required setting for normal server operation.

If this jumper is not installed over both pins, the alarm board does not send the correct format of signals to the front panel display.

Replacing the status display panel

The display is located at the front of the chassis and is cabled to the rear of the chassis and the alarm board.

To replace the status display panel



CAUTION

Risk of equipment damage


Use an ESD wrist strap to protect static-sensitive components.

- 1 Power off the server.
- 2 Remove the top cover and the front bezel from the chassis.
- 3 Remove the cooling fans (see “Replacing the cooling fan” on page 126).

The cooling fans block the access to the status panel.

- 4 Loosen the four Phillips-head screws that secure the status display panel to the front of the chassis (see A in Figure 26 on page 137)

Figure 26: Status display panel.



G101727

- 5 Label and remove the 40-pin flat cable from the back of the status display panel.
- 6 Move the defective status display panel towards the back of the chassis, and then lift it out of the chassis (see B and C in the diagram).
- 7 Set the replacement status display panel into position, and secure it to the chassis by replacing the Phillips-head screws.
- 8 Reconnect the cable.
- 9 Replace the top cover and front bezel.

Chapter 9

Replacing media drives

In this chapter

Replacing a faulty hard drive	140
About the media drive bay	144
Removing the media drive carrier from the chassis	145
Replacing a tape, CD-ROM or floppy drive	149
Installing a tape drive	153

Replacing a faulty hard drive

The hard drives are hot-swappable. This means that you can replace a faulty hard drive without powering down the server.

When to hot-swap hard drives


With a RAID controller, hot-swap device drivers, and operating system support, faulty SCA SCSI hard drives can be hot-swapped on the 1002rp server.

Note: Identify which hard drive to remove using the Windows Event Viewer (see “Viewing event logs” on page 33). The appearance of event codes such as 40211(disk access error) or 40218 (error reading or writing multimedia volume) may be an indication of a failing disk drive.

Use the RAID management software to check if any drives are in a failed state.

The following image shows a failed drive highlighted in red with the corresponding logical drive highlighted in yellow (degraded mode)

Figure 27: Failed hard drive displayed in red.



RAID SCSI hard drive configuration

Table 16 on page 141 shows proper SCSI drive bay, channel, and ID configurations in the hot-swappable drive bay. The SCSI backplane assigns the SCSI IDs as shown.

Table 16: RAID SCSI hard drive configurations

Hard drive bay	SCSI channel	SCSI ID	Logical drive label ^a
1 (far left)	0	0	A01-01 (primary hard drive)
2	0	1	A02-01 (primary hard drive)
3	0	2	A03-01 (primary hard drive)
4	1	0	A01-02 (secondary hard drive)
5	1	1	A02-02 (secondary hard drive)

Hard drive bay	SCSI channel	SCSI ID	Logical drive label ^a
6 (far right)	1	2	A03-02 (secondary hard drive)

- a. RAID pairs (logical drives) consist of the following pairs: hard drives 1 and 4, 2 and 5, and 3 and 6. These pairs are represented in the software with the labels A01-01 and A01-02, A02-01 and A02-02, and A03-01 and A03-02, where the first number is the logical drive number (for example, A03) and the second number indicates if it is the primary or secondary hard drive (01 for primary and 02 for secondary).

To replace hot-pluggable SCA SCSI hard drives




CAUTION

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

- 1 Ensure the new hard drive has the SCSI ID set to 0, termination disabled, and parity checking enabled.
- 2 Open the front bezel doors.
- 3 Locate the SCA SCSI drive frame below a cooling fan and beside the media drive.
- 4 Loosen the two thumbscrews on the carrier of the faulty hard drive, and remove the carrier from the chassis.

Figure 28: Remove SCSI carrier from chassis



G101735

- 5 Remove the faulty drive by loosening the four Phillips-head screws that secure it to the carrier.
- 6 Attach the new drive to the carrier by four Phillips-head screws.
- 7 Align the carrier with the drive frame and slide it into the chassis.
Note: Expect resistance as the carrier and backplane connectors meet.
- 8 Fasten the two thumbscrews.
- 9 Close the front bezel and lock it.

About the media drive bay

Media drive bays contain media devices, including CD-ROM, tape, and floppy drives. If your media drives become damaged or you want to upgrade, you can replace these drives. This section provides procedures for replacing or upgrading any device in the media drive bay.

To replace media drives

Perform the procedures in the following order to replace media drives:

- 1 “Removing the media drive carrier from the chassis” on page 145
- 2 “Replacing a tape, CD-ROM or floppy drive” on page 149

Removing the media drive carrier from the chassis

When replacing the media hard drives, the first step is to remove the media drive carrier from the media drive bay.

Requirements


To remove the media drive carrier from the media drive bay, you require the following:

- keys for the front bezel doors
- a Phillips screwdriver
- cable identification labels
- a pen or pencil

Locate the media drives

The media drives (CD-ROM drive, tape drive, and floppy drive) are shown in the bottom right corner shown in Figure 29 on page 146.

Figure 29: Media drives



G101750

Media drive carrier

The media drives are housed in a media drive carrier that can be removed from the server, as described later in this section. Where no media device is installed, a blank panel is secured to the media drive carrier for protection.

Media drive carrier slot assignment

The carrier is designed to stack three devices horizontally, and to house the floppy drive vertically to the right side of the carrier frame.

To remove the media drive carrier from the chassis



DANGER

Risk of electrocution

High current inside the chassis can cause severe injury.




CAUTION

Risk of equipment damage

Electrostatic discharge due to improper handling can cause components to be damaged or rendered unusable.

- 1** Remove the front bezel from the chassis. See “Removing the front bezel and server cover” on page 110.
- 2** Locate the media drive carrier, and loosen the four Phillips-head screws and washers securing the carrier to the drive bay, as shown in Figure 30 on page 148.

Figure 30: Remove media drive from chassis



G100747

- 3 Hold cables away from the drive bay as you pull the media drive carrier away from the chassis until the connectors attached behind the components can be reached.

**CAUTION****Risk of equipment damage**

To avoid damaging cables during this procedure, ensure that no cables are crossed when moving the media drive carrier in and out of the drive bay.

- 4 Label and disconnect cables from installed media drives, and then free the carrier from the chassis.

Replacing a tape, CD-ROM or floppy drive

This section describes how to replace a media drive (tape, CD-ROM, or floppy drive) in the media drive carrier.

To replace a media drive



CAUTION


Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

- 1 Remove the media drive carrier from the chassis (see “Removing the media drive carrier from the chassis” on page 145).
- 2 Remove the faulty drive from the media drive carrier and save the screws (see the diagrams that follow).


Note: To remove the tape drive or CD-ROM drive, you must first remove the floppy drive.

Figure 31: Replace media drive - step 1



G101739

Figure 32: Replace media drive - step 2



G101748


- 3 If you are installing a tape drive, configure it as described in “To configure the tape drive” on page 153.
 - 4 Slide the new drive into the media drive carrier, and secure it with the screws that were previously removed.
 - 5 Reattach any media drives that you removed to access a specific media drive slot.
 - 6 Position the media drive carrier in the media drive bay, leaving enough room to reach behind the carrier, and attach the connectors.
 - 7 Carefully connect the existing signal and power cables as shown in “Cabling example” on page 153.
- Note:** If your tape drive is a narrow device, you require a wide-to-narrow adapter to connect to the wide SCSI cable.
- 8 Slide the carrier into the media drive bay.
- Note:** Ensure that the cables are free and undamaged.

- 9** Secure the media drive carrier to the chassis with four Phillips-head screws.
- 10** Replace and lock the front bezel.

Installing a tape drive

This procedure provides instructions for installing a tape drive on a server that currently does not have a tape drive.

Figure 33: Cabling example



G101651

To configure the tape drive

Note: Some settings may already be properly configured. If it is not clear from the drive manufacturer's documentation how to set jumpers, contact your Nortel technical support representative.

- 1 Set the SCSI ID to 6.
- 2 Disable the Active Terminators (Term Enable).
Note: Termination is provided by an active SCSI terminator that you connect to the end of the SCSI cable (see "Cabling example" on page 153).
- 3 Enable Parity Checking.
- 4 Enable Termination power (TPWR).
- 5 Leave the remaining settings at the default values.

To install a new tape drive (no tape drive previously installed)



CAUTION

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

- 1 Courtesy down CallPilot, and then power down the server.
- 2 Ensure that the tape drive settings are as described in "To configure the tape drive".
- 3 Remove the chassis cover.
- 4 Remove the media drive carrier (see "Removing the media drive carrier from the chassis" on page 145).
- 5 Slide the new tape drive into the media drive carrier, and secure it with four undercut Phillips-head screws.

Note: You may need to first remove other media drives from the carrier to access the tape drive slot.

- 6** Reattach any media drives that you removed to access the tape drive slot.
- 7** Position the media drive carrier in the media drive bay, leaving enough room to reach behind the carrier, and attach the connectors.
- 8** Carefully connect the existing signal and power cables as shown in “Cabling example” on page 153.
- 9** Slide the carrier into the media drive bay.
Note: Ensure that the cables are free and undamaged.
- 10** Secure the media drive carrier to the chassis with four Phillips-head screws.
Result: The tape drive is installed.
- 11** Replace the chassis cover and front bezel.
- 12** Power on the server.
Result: The tape drive is detected by Windows, and the tape drive is ready for use.

Chapter 10

RAID operations

In this chapter

Outlining RAID functions	158
Configuring RAID firmware, driver, and power console	159
Replacing the LSI1600 card with LSI320-2	161
Configuring the RAID controller after a hardware change	163
Splitting the RAID drives	167
Synchronizing RAID drives	171

Outlining RAID functions

Redundant Array of Independent Disks (RAID) is a technology that can combine two or more drives for fault tolerance and continued system performance. The CallPilot RAID controller is a PCI RAID SCSI card that provides high-performance disk mirroring. CallPilot uses RAID Level 1.

With Level 1 mirroring, two equal-capacity disk drives mirror one another. One disk drive serves as the backup copy of the other disk drive. If one disk drive fails, the other continues to run.

Configuring RAID firmware, driver, and power console

Verifying the RAID configuration

There is a direct relationship between the driver, firmware and Power Console utility versions used with a RAID card. While mixing driver versions with firmware is not critical, mixing Power Console Utility with the wrong driver or firmware can lead to system instability and data corruption. Table 17 on page 159 shows the accepted and tested combinations for Windows 2003

Table 17:RAID driver, firmware, and Power console configuration.

RAID card	Driver	Firmware	MegaRAID Power Console
LSI1600	6.45 (6.36 works temporarily but must be upgraded)	111U	5.00i
LSI320-2	6.45 (6.36 works temporarily but must be upgraded)	1L37	5.00i

To determine the current RAID firmware version:

- 1 Launch the MegaRAID client using: Start → Programs → Power Console Plus → Launch Client.
- 2 From the MegaRAID Power Console Plus, Server Selection window, select Access Mode → Full Access to view or change configuration information and click OK.
- 3 Select Adapter → Properties.

- 4 If the configuration is not one of the valid configuration in Table 17 on page 159, perform a firmware update. For instructions, see “Replacing the LSI1600 card with LSI320-2” on page 161.

Replacing the LSI1600 card with LSI320-2

Use this procedure to replace a failed LSI1600 RAID card.

To replace the LSI1600 card with the LSI320-2 card.

ATTENTION

If your replacement RAID card has been previously used and holds an existing configuration, the system will report a mismatch between the controller NVRAM and Drive MetaData. The steps below will correct the mismatch.

WARNING

Nortel strongly recommends that you not perform low level formatting. Performing low level formatting results in the drives becoming unusable.

- 1 Power up the server and press Ctrl+M when prompted during system bootup to enter the utility.
- 2 Select Objects → Adapter → Other Adapter Options to set the following:
 - a. Set Force Boot to On.
 - b. Set Auto-Rebuild to Disabled.
 - c. Select Objects → Channel and ensure channel speed is 160M. ((Default for LSI320 is 320M).
 - d. Repeat for all channels.
- 3 Exit the utility and reboot the server.
- 4 Set the server to boot from CD.
- 5 Insert the RAID Update Utility CD and reboot the server.

- Result:** The DOS boot menu appears.
- 6 Select Update LSI320-2 Firmware.
- Result:** The system will prompt twice to confirm you are upgrading the firmware.
- 7 Answer Y to both questions.
- Result:** The system upgrades the firmware and asks you to reboot.
- 8 Allow the system to reboot to Windows 2003.
- 9 Insert the RAID Update Utility CD and unzip the RAIDUP.EXE file.
- Result:** A directory called RAIDUP is created on C:\ drive
- 10 Locate SCSI controllers → LSI Adapter in the RAIDUP directory. Double click on it, then select Driver.
- Result:** You are asked to choose the Upgrade Driver.
- 11 Point to the c:\raidup\Win2k3 folder.
- 12 The system asks you to reboot.
- Result:** The system reboots to Windows 2003.
- 13 Check the driver, firmware and Power Console configuration.
- Open the MegaRAID Power Console from the Start → Programs → Power Console Plus → Launch Client menu.
 - Select Help About from the menu and verify the MegaRAID Power Console version is 5.00i.
 - Select Adapter → Properties and verify the firmware version is 1L37 and the board type is LSI320-2.
 - Exit the Power Console.
- 14 Right click on C:\WINNT\SYSTEM32\DRIVERS\mraid3xx.sys and select Properties → Version. Verify the Driver version is 6.45.

Configuring the RAID controller after a hardware change

The RAID card's configuration is stored on both the card and on the hard drive, so typically you are not required to reconfigure RAID unless you are making a change to the RAID system (for example, if you replace the hard drives with higher-capacity hard drives).



CAUTION

Risk of data loss

This procedure requires that the logical drive be initialized. When you initialize the logical drive, all data on the hard drives is erased.

Do not perform this procedure unless you are replacing the hard drives, or you are rebuilding the CallPilot system (that is, reinstalling the Windows operating system and CallPilot software).

WARNING

Nortel strongly recommends that you not perform low level formatting. Performing low level formatting results in the drives becoming unusable.

To configure an LSI Elite 1600 or LSI320-2 RAID system

- 1 Turn on the server and press Ctrl+M when prompted during system bootup.

Note: The Ctrl+M utility can take up to 1 minute to launch. The system may appear frozen. Do not reset.

- 2 From the Management menu, select Objects and press Enter.

- 3 From the Objects menu select Adapter and press Enter.
- 4 From the Adapter menu select Factory Default.
- 5 Select Yes to confirm the selection and press Enter.
- 6 Press Ctrl+Alt+Delete when prompted to restart system.
- 7 During bootup, press Ctrl+M to re-enter the RAID setup utility.
- 8 From the Management menu select Objects → Adapter, then ensure the values are set as follows:

Flex RAID Power Fail: **Enabled**

Fast Initialization: **On**

Disk Spin up Timing: **1 Disk every 6 secs**

Cache Flush Timings: **Every 4 seconds**

Rebuild Rate: **30%**

Alarm Control: **Enabled**

Other Adapter Options:

— Emulation: **Mass Storage**

— Auto Rebuild: **Disabled**

— Initiator ID: **7**

— Cluster Mode: **Disabled**

— Multiple PCI Delayed Transactions: **Disabled**

— Force Boot: **On**

— Coercion Algorithm: **GigaByte Way**

— Cc Restoration: **Enabled**

Note: The Coercion Algorithm must be set properly. Once changed, it cannot be changed again. The only way to reset it is to reconfigure RAID from scratch and load the default configuration, then reboot.

- 9 Select Objects → Channel and press Enter. Ensure that the values are set as follows:

Termination State: **Enabled**
SCSI Transfer Rate: **160M**
- 10 In the Configure menu, select New Configuration. Press Yes to proceed.

Result: The system should display both SCSI channels, each having three drives. SCSI ID's should be listed in order from 0 to 2 for each channel, starting from the top. All disk drives should be in READY state.

Note: Do not use the Load command on the Configure menu. This command is not for RAID operations.

- 11 Create the first logical drive by selecting A01-01 (first drive from channel 0), to A01-02 (first drive from channel 1) and pressing the space bar.

Result: After selection, the drives will blink.

- 12 Press Enter to create the first logical drive.
- 13 Repeat the process for the second and third logical drives to create packs as follows:

A02-01 and A02-02 as second pack

A03-01 and A03-02 as third pack

- 14 Press Enter or F10 to configure the logical drives.
- 15 Press the space bar to Select Configuration Array. *Span-1* appears in the box opened for A01 logical drive. DO NOT select and press the space bar for the other logical drives at this point.
- 16 Configure logical drive A01, by pressing F10.

RAID 1;

Size: accept the size displayed;

Accept

SPAN = NO

- 17 Highlight Accept and press Enter to accept these new values. Repeat for the two remaining logical drives.

Result: After the last logical drive, the system will prompt you to save the configuration.

- 18 Highlight YES and press Enter.
- 19 Press ESC twice to exit the submenus.
- 20 In the Management menu choose the Initialize submenu.
- 21 Press F2 to select all three logical drives.

- 22** Press F10 and consecutively select YES to initialize the drive packs.
- 23** When the initialization is complete, press any key to return to the Management menu.
- 24** Press ESC to exit the utility. Save the configuration when prompted.
- 25** Press Ctrl+Alt+Delete as indicated by the menu to reboot.

Splitting the RAID drives

Ensure that your system is in full working order and the RAID hardware configuration is set up properly as described on page 163.

ATTENTION

You must verify that the RAID channel 1 is connected to the first three hard drives on the left as facing the machine, and channel 2 is connected to the last three on the right. Either open the lid and follow the cables or take one hard drive offline and observe which drive is marked FAIL by the system. If the drive matches the graphic location on the Windows MegaRAID console, proceed with the next step.

ATTENTION

The drives must not be un-seated, re-seated or disconnected during the RAID splitting process unless you are planning to replace the drives.

Full data backup

ATTENTION

As an extra precaution, it is recommended that a full system backup be performed **PRIOR** to performing a RAID-split. For more information on system backups refer to the CallPilot Manager online help.

Verifying consistency on the drives

This optional consistency check on the RAID system's logical drive ensures that the data on the drives is identical. If any errors are found, they are corrected automatically. Perform a consistency check *before* you split the RAID system pack. A good data backup on an offline drive will be important if you need to revert to the CallPilot system from an unsuccessful upgrade or update. The consistency check can take up to 2 hours to complete.

To perform a consistency check

- 1 Restart the CallPilot system and press Ctrl+M when prompted, to enter the RAID setup utility during bootup.
- 2 From the Management Console, select Check Consistency.
Result: The Logical Drives Configured dialog box displays.
- 3 Use the arrow key to highlight the first drive to be checked.
- 4 Press the space key to select the drive.
- 5 Press F10 to check consistency.
Result: The "Check Consistency?" confirm dialog box appears.
- 6 Select YES and press Enter.

Result: The consistency check begins and a status dialog box appears.

- 7 Repeat steps 3 to 6 for each drive until all three drives have been checked for consistency.

To split the RAID

ATTENTION

Because the 1002rp has three physical drives, the RAID splitting must be done at the Ctrl+M utility level. Do not perform this procedure using the Windows MegaRAID console. There is a risk of database corruption.

- 1 Restart the CallPilot system and press Ctrl+M when prompted, to enter the RAID setup utility during bootup.

- 2 From the Management menu select Objects > Physical Drive.

Result: A list of all drives organized per channel appears.

- 3 Select the A01- 2 drive using the cursor and press Enter.

- 4 Select Fail Drive.

Result: A warning message box appears. Ignore it and select Yes. The drive status changes to FAILED. The alarm should start beeping.

- 5 Repeat this process for the remaining two drives present on Channel 2.

- 6 Press Esc three times to exit the Ctrl+M utility.

- 7 Reboot.

Result: The system reports that three drives are in critical mode and starts beeping. This is OK; the system will still reboot.

Attention: The alarm can be silenced, but under no circumstances should it be disabled. On the toolbar, select Objects → Adapter → Alarm Control → Silence Alarm from the toolbar.

At this point, the RAID is split, and the drives marked FAILED become the backup drives and are no longer written to. A PEP installation can now be done without impact to the 'backup' drives.

Synchronizing RAID drives

To synchronize the RAID after a successful operation

- 1 Without shutting down the server, right-click the first drive on Channel 2.

Example: (0) A1-2-Failed.

- 2 From the pop-up menu select Rebuild. When the Rebuild is complete, repeat the process for the remaining two drives on Channel 2.

Result: When all three drives are rebuilt:

- a. All three drive status' changes to ONLINE.
- b. The color of the icons changes to green.
- c. The alarm should stop beeping unless it was temporarily silenced.

Note: The process can take up to 1 hour. DO NOT shut down the machine before the rebuild is complete.

- 3 Monitor the rebuild by opening the Windows MegaRAID console.

To synchronize the RAID after an unsuccessful operation

If the operation has failed, the system needs to be returned to the original configuration.

- 1 Reboot the CallPilot server.
- 2 Press Ctrl+M when prompted while the server is booting.

Result: The RAID configuration utility opens.

- 3 Break the mirroring of the logical drives.
 - a. Select Objects → Physical Drive.

Note: All server drives on channel 1 must be online.
 - b. Select CH1 ID0 (A01-01) and press Enter.
 - c. Select Fail Drive and press Enter.
 - d. Select Yes to confirm the fail action and press Enter.
 - e. Repeat these steps for each remaining drive on channel 2: CH1 ID1 (A02-01) and CH1 ID2 (A03-01).
- 4 Bring the drives on channel 2 online (the drives on which the previous CallPilot release is installed).
 - a. Select Objects → Physical Drive.
 - b. Select CH2 ID0 (A01-02) and press Enter.
 - c. Select Make Online and press Enter.
 - d. Select Yes to confirm that the driver must be brought online and press Enter.
 - e. Repeat these steps for each remaining drive on channel 2: CH2 ID1 (A02-02) and CH2 ID2 (A03-02).
- 5 Press Esc to return to the Objects menu.
- 6 Press Esc to return to the Management menu.
- 7 Press Esc to exit the RAID configuration utility.

Result: A confirmation box appears.
- 8 Click Yes to confirm that you want to exit the RAID configuration utility and press Enter.
- 9 Press Ctrl+Alt+Delete to reboot the server.

Chapter 11

Upgrading to High Capacity

In this section

Board and card configuration for High Capacity	174
Identifying hardware components	176
Upgrading to High Capacity	178

Board and card configuration for High Capacity

A High Capacity system requires you to add additional boards or cards, or both, to your server. This section compares configurations for a 96-channel system to a High Capacity system for the supported switches.

Table 18: Board and card configurations for the T1 switch

System type	MPB96 boards	PCI T1 cards	Max. channels	MPU
96-channel	1	2	96	96
High Capacity	3	4	192	288

Table 19: Board configurations for the M1/CS1000 switch

System type	MPB96 boards	Max. channels	MPU
96-channel	1	96	96
High Capacity	3	192	288

Taking safety precautions

Before you make any changes to the server hardware, follow these safety precautions:

- Respect appropriate ESD rules.

- Power the system OFF.
- Do not drop and leave screws inside the server.
- Do not drop hard objects (such as screwdrivers) inside the server as this can damage the server.

Identifying hardware components

Figure 34 shows the arrangement of slots in a 1002rp server chassis.

Figure 34: 1002rp server chassis





Figure 35 shows the layout of jumpers and switches on the D/480JCT-2T1 PCI T1 board.

Figure 35: D/480JCT-2T1 PCI T1 board



Upgrading to High Capacity

Choose one of the following upgrade procedures based on your switch connectivity.

ATTENTION

You must use one of the valid configurations and respect the slot map or the system behavior will be erratic.



CAUTION

Risk of electrical damage

- Wear an antistatic ESD wrist strap when handling cards or boards, or when working inside the server.
- Do not touch the components or gold-edge connectors of cards or boards.
- Place the cards and boards on an antistatic surface until you are ready to install them.

Upgrading to High Capacity: T1 switch connectivity

To add two MPB96 boards and two T1 PCI cards

- 1 Courtesy stop all CallPilot channels.
- 2 Power down the server and all peripheral devices.
- 3 Disconnect the following cables:
 - a. power cable
 - b. peripheral device cable
 - c. D/480JCT-2T1 cables

- 4** Remove the server cover.
For instructions on removing the server cover, see “Removing the front bezel and server cover” on page 110.
- 5** Disconnect the CT Bus cable (if present).
- 6** Ensure that the current configuration is as follows (this is standard for a 96-channel configuration):
 - a.** There is an existing MPB96 board in PCI slot 3.
 - b.** There is an existing Intel D/480JCT-2T1 PCI card in slot 4, and its SW100 ID rotary dial switch is set to 0.
 - c.** There is an existing Intel D/480JCT-2T1 PCI card in slot 5, and its SW100 ID rotary dial switch is set to 1.
- 7** Remove any termination jumpers from the Intel D/480JCT-2T1 PCI cards. For jumper location, see Figure 35 on page 177.
- 8** Plug the first additional MPB96 card into PCI slot 6.
- 9** On the first additional Intel D/480JCT-2T1 PCI card:
 - a.** Set the card’s SW100 ID rotary dial switch to 2.
 - b.** Ensure that there are no termination jumpers installed on P700.
 - c.** Plug the card into PCI slot 7.
- 10** On the second additional Intel D/480JCT-2T1 PCI card:
 - a.** Set the card’s SW100 ID rotary dial switch to 3.
 - b.** Ensure that there are no termination jumpers on P700 pins 3 and 4.
 - c.** Plug the card into PCI slot 8.
- 11** Plug the second additional MPB96 card into PCI slot 9.
- 12** Connect the 7 drop CT Bus cable to ensure that the connectors are connected to the end cards and no connector is left dangling at any end of the cable.
- 13** Replace the server cover.
- 14** Replace the front bezel and lock it.
- 15** Reconnect the peripheral device and power cables.

- 16 Connect the D/480JCT-2T1 cables to the two new and two existing Intel D/480JCT-2T1 PCI cards.

Note: Ensure that a single-point ground reference is available for all the power outlets serving the CallPilot server and its peripherals. Before the CallPilot server installation, a qualified electrician must implement the single-point ground reference requirement between the power outlets of the CallPilot server and the power outlets of the switch.

- 17 Power up the server and log on to Windows.

Result: The Windows New Hardware Found Wizard screen appears.

ATTENTION

Before clicking Next to install the hardware driver, *wait 10 minutes or until you see the dialog box “CallPilot is running and is able to accept calls”*; otherwise the server could display a blue screen and then restart. If this happens, the server may not recognize the installed cards and boards.

- 18 Wait 10 minutes for the server to return to full service.
- 19 Click Next.
- 20 Select the presented Nortel MPB driver and click Next.
- 21 Repeat the previous two steps each time the Windows New Hardware Found Wizard screen appears.
- 22 Restart the server.

Note: After restarting the server, you receive a dialog box indicating you have new hardware. Click OK.

- 23 Run the Configuration Wizard to configure the new hardware.

For instructions, refer to the *Installation and Configuration Task List* (555-7101-210).

Result: The upgrade to High Capacity is complete.

- 24** Restart the server.
- 25** When the server is back in full service, test the multimedia channels to ensure the new boards and cards are functioning properly.

Refer to “Testing the CallPilot installation” in the *Installation and Configuration Task List* (555-7101-210).

Upgrading to High Capacity: M1/CS1000 switch connectivity

To add two MPB96 boards

- 1 Courtesy stop all CallPilot channels.
- 2 Power down the server and all peripheral devices.
- 3 Disconnect the following cables:
 - a. power cable
 - b. peripheral device cable
 - c. DS30X cables
- 4 Remove the server cover.

For instructions on removing the server cover, see “Removing the front bezel and server cover” on page 110.
- 5 Disconnect the CT Bus cable (if present).
- 6 Ensure that there is an existing MPB96 board in PCI slot 3 (this is standard for a 96-channel configuration).
- 7 Plug the first additional MPB96 board into PCI slot 6.
- 8 Plug the second additional MPB96 board into PCI slot 9.
- 9 Connect the 7-drop CT Bus cable to the MPB96 boards; the connectors of the CT Bus cable must connect to the three MPB96 boards in slots 3, 6, and 9.

Note: There should be no dangling connectors at either end of the CT Bus cable.
- 10 Replace the server cover.
- 11 Replace the front bezel and lock it.
- 12 Reconnect the peripheral device and power cables.
- 13 Reconnect the DS30X cable to the faceplate of the MPB96 board.

For instructions about attaching the cable, refer to *Meridian 1 and CallPilot Server Configuration* (555-7101-222) or *Succession CSE 1000 and CallPilot Server Configuration* (555-7101-510).

Note: Ensure that a single-point ground reference is available for all the power outlets serving the CallPilot server and its peripherals. Before the CallPilot server installation, a qualified electrician must implement the single-point ground reference requirement between the power outlets of the CallPilot server and the power outlets of the switch.

- 14 Power up the server and log on to Windows.

Result: The Windows New Hardware Found Wizard screen appears.

ATTENTION

Before clicking Next to install the hardware driver, wait 10 minutes or until you see the dialog box “CallPilot is running and is able to accept calls”; otherwise the server could display a blue screen and then restart. If this happens, the server may not recognize the installed boards.

- 15 Wait 10 minutes for the server to return to full service.
- 16 Click Next.
- 17 Select the presented Nortel MPB driver and click Next.
- 18 Repeat the previous two steps each time the Windows New Hardware Found Wizard screen appears.
- 19 Restart the server.

Note: After restarting the server, you receive a dialog box indicating you have new hardware. Click OK.

- 20 Run the Configuration Wizard to configure the new hardware.

For instructions, refer to the *Installation and Configuration Task List* (555-7101-210).

Result: The upgrade to High Capacity is complete.

- 21** Restart the server.
- 22** When the server is back in full service, test the multimedia channels to ensure the new boards are functioning properly.

Refer to “Testing the CallPilot installation” in the *Installation and Configuration Task List* (555-7101-210).

Chapter 12

Replacing voice processing boards

In this chapter

DSP numbering and location	186
Replacing an MPB96 board	187


DSP numbering and location

DSPs are the built-in voice processing components on MPB boards. DSPs are numbered to distinguish them in CallPilot maintenance programs, such as the Maintenance page in CallPilot Manager. Each DSP supports up to eight multimedia channels.

DSP numbering on MPB96 boards

The MPB96 board has 12 embedded DSPs. MPC-8 cards are not required. If an embedded DSP is faulty, you must replace the entire MPB96 board.

Figure 36: MPB96 board



Replacing an MPB96 board

This section describes how to replace an MPB96 board.

You must replace an MPB96 board:

- if the board becomes faulty
- when the PCI firmware needs to be updated, and the board must be sent back to the factory



CAUTION

Risk of electrical damage

- Wear an antistatic ESD wrist strap when handling cards or boards, or when working inside the server.
- Do not touch the components or gold-edge connectors of cards or boards.
- Place the board on an antistatic surface until you are ready to install it.

To replace an MPB96 board

- 1 Courtesy stop all CallPilot channels.
- 2 Power down the server and all peripheral devices.
- 3 Disconnect the following cables:
 - a. power cable
 - b. peripheral device cables
 - c. DS30X cables (Meridian 1 and Succession 1000 only)
- 4 Remove the server cover.

For instructions on removing the server cover, see “Removing the

front bezel and server cover” on page 110.

- 5 Disconnect the CTbus cable (if present)
- 6 Remove the original MPB96 board from the slot.
- 7 Unpack the replacement MPB96 board.
- 8 Hold the MPB96 board by its top edge or upper corners and then align it with the following:
 - end-plate opening in the chassis (ensure that the tapered foot of the board’s retaining bracket fits into the slot in the expansion slot frame)
 - PCI connector
- 9 Press the new MPB96 board firmly into its slot.
- 10 Secure the board using the retaining screw.
- 11 Reattach the CTbus cable.
- 12 Replace the server cover.
- 13 Replace the front bezel and lock it.
- 14 Reconnect the peripheral device and power cables.
- 15 Reconnect the DS30X cable to the faceplate of the MPB96 board.

Note: Ensure that a single-point ground reference is available for all the power outlets serving the CallPilot server and its peripherals. Before the CallPilot server installation, a qualified electrician must implement the single-point ground reference requirement between the power outlets of the CallPilot server and the power outlets of the switch.

- 16 Power up the server and log on to Windows.
- 17 Run the Configuration Wizard to detect the new hardware.

For instructions, refer to the *Installation and Configuration Task List* (555-7101-210).

Result: The MPB96 board replacement is complete.

- 18 Restart the server.

- 19** When the server is back in full service, test the multimedia channels to ensure the new MPB96 board is functioning properly.

Refer to “Testing the CallPilot installation” in the *Installation and Configuration Task List* (555-7101-210).

Chapter 13

Replacing the D/480JCT-2T1 T1 interface card

In this chapter

D/480JCT-2T1 card function	192
Replacing the D/480JCT-2T1 card	192

D/480JCT-2T1 card function

Either two or four D/480JCT-2T1 T1 interface cards can be installed to provide 96 or 192 DSO voice channels, respectively, to the switch. Each T1 interface card occupies one PCI slot.

The Intel D/480JCT-2T1 card carries the media stream and call control signals between CallPilot and the SL-100 or DMS-100 switch.

Replacing the D/480JCT-2T1 card

If you determine that a problem exists with your card, replace it. You must identify the type of card before you can decide where to install it.

Requirements

To replace the card, you require the following:

- one Philips screwdriver
- one antistatic wrist strap
- the replacement card

Identify the card

Identify the card from other types of cards by its connector.



DANGER

Risk of electric shock

High voltage inside the chassis can cause severe injury.

**CAUTION**

Risk of equipment damage

Take precautions to protect internal components. Electrostatic discharge (ESD) can damage boards and make them unusable. Wear an ESD wrist strap.

To replace a faulty D/480JCT-2T1 card

- 1 Review the manufacturer's documentation for the replacement of the Intel D/480JCT-2T1 card.
- 2 Power down the server and disconnect all power cords.
- 3 Remove external T1 cables connected to the faulty D/480JCT-2T1 card.
- 4 See valid slot assignments described in the procedure on page 178 to determine the configuration.
- 5 Remove the chassis cover to expose the installed cards.
- 6 Set aside any cables covering the card.
- 7 Remove the CT Bus cable.
- 8 Free the card from the faceplate by loosening the screw.
- 9 Lift the card out of the slot and set it aside.
- 10 Unpack the replacement D/480JCT-2T1 card and configure the rotary switch to the correct setting. Use the settings described in the procedure starting on page 178.
- 11 If required, install a CT Bus termination jumper to the D/480JCT-2T1 card on P700 between pin 3 and pin 4 to enable CT Bus termination.

Note: Only one Intel D/480JCT-2T1 PCI card in the system (the last on the CT Bus cable) should have a termination jumper installed.

- 12 Apply downward pressure until the card is evenly and securely seated in the slot.
- 13 Secure the card by tightening the screw located at the top of the faceplate.
- 14 Replace the CT Bus cable.
- 15 Replace the chassis cover.
- 16 Power up the server.

Manually setting T1 card manual termination jumpers

Manually set T1 card manual termination jumpers only on the last card at the end of the CT Bus.




ATTENTION

Risk of equipment damage

Do not install this jumper on any of the other T1 cards.

Apply a jumper between pins 3 and 4 of the P700 header on the Intel/Dialogic D/480JCT-2T1 card. The diagram below shows a detail of the T1 card.

Figure 37: D/480JCT-2T1 card




To test the D/480JCT-2T1 card

Test the D/480JCT-2T1 card using the Universal Dialogic Diagnostic (UDD) utility.

Note: Before running this utility, you must stop essential services. All call processing ceases and you must restart the system after the diagnostics are complete.

- 1 Stop the CallPilot HAL Monitor service. Refer to “To start or stop a component” on page 81 for instructions.

Figure 38: Component services



- 2 Click Start → Programs → Intel Dialogic System → Universal Dialogic Diagnostics Utility.

Result: The Intel Warning box appears asking you to confirm the stoppage of the boards.


Figure 39: Intel Warning box



- 3 Click Yes to confirm.

Result: The Universal Intel Dialogic Diagnostics screen appears.


Figure 40: Universal Intel Dialogic Diagnostics



- 4 Click Select All and then click Run Tests.

Result: The Test Progress window appears.

Figure 41: Dialogic Test Progress



- 5 Click Done when the tests are complete. Save any error information.
- 6 Restart the CallPilot HAL Monitor service. Refer to "To start or stop a component" on page 81 for instructions

Chapter 14

Maintaining the Pentium III SBC card


In this chapter

Overview	200
Replacing the Pentium III SBC card	201
Configuring the 1002rp Pentium III BIOS	205
Replacing inline memory modules	208
Maintaining the onboard video and network cards	210

Overview

This section describes the Pentium III SBC card (single board card). It covers procedures for replacing and configuring the SBC card. The SBC card is always installed in the SBC slot located between the ISA expansion slots and the PCI slots on the backplane. Refer to Figure 42 on page 200 for SBC card location.

Figure 42: SBC card location



Procedures included

This section describes the following procedures:

- replacing the SBC card (page 201)
- upgrading and configuring the BIOS (page 205)
- adding memory DIMMs to the SBC (page 208)

Replacing the Pentium III SBC card

Use system diagnostic tools and refer to error codes to determine whether the SBC card should be replaced. This section provides instructions for replacing the SBC card.

Requirements


Before you replace the SBC card, gather the following tools:

- one Phillips-head screwdriver
- one antistatic wrist strap
- the replacement SBC card
- cable labels

SBC card connectors and jumpers

Figure 43 on page 202 shows the location of connectors where cables must be disconnected or connected as part of the procedure to replace the SBC card. The jumpers shown in this diagram are used in the BIOS configuration procedures

Figure 43: SBC card connectors and jumpers.



G101650

To replace the SBC card



DANGER

Risk of explosion

The SBC has a lithium battery installed. If you are discarding the SBC, dispose of used batteries according to the manufacturer's instructions. Replacement of the battery with an incorrect type also raises the risk of an explosion.

- 1 Power down the server.
- 2 Disconnect the power cord.
- 3 Remove the top cover.
- 4 Disconnect and label all cables from the SBC card. See "SBC card connectors and jumpers" on page 201. Refer to Figure 42 on page 200 to locate the SBC card.
- 5 Disconnect and label cables from the SBC card faceplate.
- 6 Loosen and remove the screw that is securing the SBC card.
- 7 Loosen and remove the screw located at the top of the card faceplate.
- 8 Loosen the SBC and pull it up from the backplane.

Note: You can now do the following:

- Replace the SBC with a new card. To replace it, continue with step 9.
 - Increase RAM by adding DIMM(s) to the card. See "To add an SDRAM DIMM to the SBC card" on page 208.
- 9 Remove the new card from its protective wrapping.
 - 10 Align the card with its slot on the backplane and press it into place.
Result: The board seats properly in both the ISA-style and PCI-style connectors.
 - 11 Fasten the card down with the screw provided.

- 12** Install the new I/O bracket.
- 13** Fasten the I/O bracket using the screw provided.
- 14** Remove the labels attached to all connectors and reconnect them to the card. See “SBC card connectors and jumpers” on page 201.
- 15** Replace the top cover.

Configuring the 1002rp Pentium III BIOS

BIOS is the Basic Input/Output System of the computer. It is Flash ROM-based code. The system is equipped with Flash BIOS, which enables you to upgrade by running a single program that writes updated code to the Flash ROM chips.

When to upgrade the BIOS

Do not upgrade the BIOS unless specifically instructed to do so by your Nortel representative. The CallPilot server is shipped to the customer with the required minimum BIOS vintage, so an upgrade is only necessary if Nortel deems this necessary to solve a system problem. The minimum release BIOS for CallPilot 4.0 is NNCXUA07 or later.

When to configure the BIOS

BIOS configuration is performed at the factory before the CallPilot server is shipped to the customer. It may be necessary to reconfigure the BIOS at a customer site after a BIOS or CMOS failure and recovery.

Requirements for upgrading or reconfiguring the BIOS

CallPilot Image CD (1, 2 and 3)

To upgrade the BIOS

You must perform both of the following procedures to upgrade the BIOS:

- 1 Upgrade the BIOS (page 205).
- 2 Configure the SBC (page 207).



CAUTION

Risk of data loss

Perform this procedure only if specifically instructed to do so by your Nortel representative.

- 1 Disconnect the cable that connects the CallPilot server to the CLAN subnet.
- 2 Power on the CallPilot server.
- 3 Insert the CallPilot Image CD 1 of 3 for the platform into the CD-ROM drive.
- 4 Set the CallPilot server BIOS to boot from the CD-ROM.
Result: The server boots from the CD-ROM and displays the installation menu.
- 5 Press 2 to select `Utilities (BIOS, Firmware, etc...)`, and then press Enter.
- 6 Press 1 to select `Update 1002rp BIOS to version NNCXUA07` and then press Enter.
Result: The system prompts you to confirm that the single board computer (SBC) is a SLE model.
- 7 Choose yes (Y) to confirm.
Result: The system prompts you to save the existing BIOS.
- 8 Type `n` and then press Enter.
Result: The system prompts you to enter the file name.
- 9 Type `nncxau07.rom` and then press Enter.
Result: The system prompts you to program the boot block.
- 10 Type `y` and then press Enter.

Result: The system updates the BIOS and then prompts you to reboot the server.

- 11 Press Ctrl+Alt+Delete to reboot the CallPilot server.

Result: The CallPilot server reboots.

- 12 During the reboot sequence, check the version of the BIOS on the top of the first screen. The BIOS version must be NNCXUA07.

Tip: If the BIOS version is not NNCXUA07, then check if the J10 and J11 jumpers are both in the top position. Power down the server, remove the single board computer (SBC) board and set the jumpers to the correct position. Follow the electrostatic discharge (ESD) rules to prevent static electricity from damaging the SBC board.

To configure the Pentium III SBC



CAUTION

Risk of data loss

Perform this procedure only if specifically instructed to do so by your Nortel representative.

- 1 Restart the server, and then press Delete to enter Setup when prompted.
- 2 Set the MPS 1.4 Support value to Disabled in the Chipset menu.
- 3 Press F9 to accept the other default values.
- 4 Press Enter when prompted to confirm this change.
- 5 Press F10 to save and exit the BIOS setup.
- 6 Restart the server.

Result: BIOS reconfiguration is completed.

Replacing inline memory modules

The DIMM is located on the SBC. The gold-plated edge connectors on DIMMs are designed to plug into matching edge-connector slots. The design allows you to add or remove these modules repeatedly without tools or without causing damage. Install a DIMM on the SBC only.

Capacity

The base CallPilot has one 512-Mbyte DIMM installed in Bank 1. No other memory configurations are supported on this server.

Requirements

To add a DIMM to the card, you require the following:

- an antistatic wrist strap
- a DIMM with gold-plated edge connectors

To add an SDRAM DIMM to the SBC card



CAUTION

Risk of electrical damage

Wear an antistatic ESD wrist strap when handling cards or boards, or when working inside the server.

- 1 Remove the SBC card from the server and place it down on a flat surface.

Note: To remove an old DIMM, perform steps 2 and 3. To add a new DIMM, go to step 4.

- 2** Push the DIMM release tab outwards at both sides of the DIMM to be removed.
- 3** Hold the DIMM by its edges, being careful not to touch its components. Remove the DIMM by lifting it away from its slot. Store it in an antistatic package.
- 4** Orient the DIMM so that the two notches in the bottom edge of the DIMM align with the keyed slot.
- 5** Insert the bottom edge of the DIMM into the slot, and press down firmly on the DIMM until it seats correctly.

When the DIMM seats correctly, release the tabs lock back to an upright position. If the DIMM does not seat correctly, remove it and reinstall. Do not force the locking tabs to close.

- 6** Replace the SBC card in the server.

Maintaining the onboard video and network cards

Network card failure

The network cards are integrated into the SBC card. If the network cards fail, they cannot be replaced by add-in network cards in the expansion slots.

Video card failure

The video cards are integrated into the SBC card. If the video cards fail, they cannot be replaced by add-in video cards in the expansion slots.

Indicators for video card failure

If the monitor appears to be functioning but no display is visible, look for the following indicators of video card malfunction:

- Brightness and contrast are set at normal level.
- The server is powered on, and one long beep is followed by two short beeps.
- The floppy drive light goes on when the server is powered, but no display is visible on the monitor.
- The floppy drive light comes on when you type **dir a:** and press Enter, but no display is visible on the monitor.

Index

Numerics

9-pin connector 60

A

add DIMMs to the SBC 208

air filter, door
replacement of 114

air filter, front bezel
replacement of 114

alarm board
jumpers 133
replacement of 131

Alarm Monitor 67

alarms

about 64, 67
investigating 67

alert icons, component states 77

application event log
definition 34

arp command 43
parameters and descriptions 43
running from Windows 44
syntax 43

B

backplane, SCSI 141

bezel, front 110
removal of 111
replacement of 112

BIOS
requirements for upgrading 205

boot failure
CallPilot
what to do 28
Windows
what to do 28

C

call channels
disabling 71
working with 90–91

CallPilot
utilities
Diagnostics Tool 94
PEP Maintenance 94, 97
Session Trace 98
System Monitor 94

CallPilot Manager

alarms
about 64, 67
investigating 67

alert icons, component states 77

Channel Monitor, using 71, 90–91

Event Browser, using 69–70

events
about 64, 69
investigating 69

fault management
alarm notification 64
event processing 64

Maintenance screen
Diagnostics section 74
General section 74
Maintenance section 74

- purpose 72
 - Multimedia Monitor, using 71, 88–89
- CallPilot services
 - Channel Monitor tab 103
- CD-ROM drive
 - replacement of 149
- Channel Monitor tab 101
 - CallPilot services 103
 - critical 104
 - DS30X links pane in 105
 - DSP pane in 104
- Channel Monitor, using 71, 90–91
- channels
 - call, working with 90–91
 - disabling 71
 - multimedia, working with 88–89
- chassis keys 110
- chkdsk utility 49
 - parameters and descriptions 49
 - running from Windows 50
 - syntax 49
- commands
 - Net Start 61
 - Net Stop 54
 - TSTSERIO 56, 57, 58, 60
- commands, TCP/IP
 - arp 43
 - ipconfig 38
 - nbtstat 44
 - netstat 47
 - ping 40
 - tracert 41
- components
 - CallPilot Manager maintenance activities 75
 - dependencies 65
 - diagnostics that can be run 84
 - diagnostics-eligible 83
 - list 72
 - replacing 19
 - states
 - Alert icons 77
 - description 76–77

- viewing 78
- configure the Pentium III SBC 207
- configuring
 - RAID system 163
- copyright 2
- Courtesy stop, description 80
- critical services, CallPilot 104

D

- diagnostic tools
 - TSTSERIO tests 56, 57, 58, 60
- diagnostics
 - integrated
 - running 83, 84–85
 - troubleshooting failures 84
 - when to run 83
 - last results
 - viewing 86
 - serial port
 - overview 52
 - TCP/IP 38
 - arp 43
 - ipconfig 38
 - nbtstat 44
 - netstat 47
 - ping 40
 - tracert 41
- Diagnostics section, Maintenance screen 74
- Diagnostics Tool 94
- diagnostics tool
 - TCP/IP 38
- display panel, status
 - replacement of 136
- doors on the front bezel 110
- D-sub connector
 - 9-pin 60
- Dual Inline Memory Modules (DIMMs) 208

E

- Event Browser, using 69–70

- event log
 - application 34
 - security 34
 - system 34
- event logs
 - types, description 34
 - viewing 34
- events
 - about 64, 69
 - investigating 69

F

- fan, hot-swap 126
- fault management
 - alarm notification 64
 - event processing 64
- firmware, flashing the 161
- floppy drive
 - replacement of 149
- front bezel 110
- fuse
 - replacement of 129

G

- General section, Maintenance screen 74

H

- hard drive bay 141
- hard drive, RAID SCSI
 - configuration of 141
- hard drive, SCSI hot-pluggable
 - replacement of 142
- hard drives
 - when to hot-swap 140
- hardware problems, detecting 65

I

- indicators 210
- integrated diagnostics
 - running 84–85
 - troubleshooting failures 84
 - when to run 83
- ipconfig command 38
 - flags and descriptions 39
 - running from Windows 39
 - syntax 38
- ipconfig default 38

L

- LED, non-illumination of 118
- Legend/Help tab 106
- location
 - MPB96 DSP 186
- logs
 - event types
 - viewing 34
 - event, viewing 34

M

- maintenance
 - activities by component 75
 - preparing for 19
- Maintenance screen, CallPilot Manager
 - Diagnostics section 74
 - General section 74
 - Maintenance section 74
 - purpose 72
- media drive bay
 - order of replacement procedures 144
- media drive carrier
 - removal from chassis 147
- media drives
 - location 145
- MPB96 board 186
 - replacing or adding 187

multimedia channels, working with 88–89
Multimedia Monitor, using 71, 88–89

N

nbtstat command 44
 parameters and descriptions 45
 running from Windows 46
 syntax 44
Net Start command 61
Net Stop
 Windows 54
Net Stop command 54
netstat command 47
 parameters and descriptions 47
 running from Windows 47
 syntax 47
network card
 failure 210

P

parts, obtaining replacement 19
Pentium III SBC 201
PEP Maintenance utility 94, 97
ping command 40
 parameters and descriptions 40
 running from Windows 41
 syntax 40
POST error codes and messages 27
POST message formats 24
power supply, hot-swap 116
Power-On Self-Test
 See POST

Q

quitting
 system 53

R

RAID 158
RAID firmware
 upgrading 161
RAID system
 configuration 163
 configuring 163
Redundant Array of Independent Disks
 (RAID) 158
regulatory information 2
replacement parts, obtaining 19
restarting system after TSTSERIO tests 61

S

SBC card, Pentium III
 replacing 203
SCSI controller
 error messages 27
SCSI ID 141
SCSI unit 141
security event log
 definition 34
serial port
 diagnostics 52
server cover 110
 removal of 112
Session Trace utility 98
shutting down
 system 53
startup problems
 what to do 28
Stop, description 80
system
 restarting after TSTSERIO tests 61
 shutting down 53
system event log
 definition 34
System Info tab 105
System Monitor 94
 Channel Monitor tab 101
 Legend/Help tab 106

- System Info tab 105
- System Monitor utility 101
- system utilities
 - System Monitor 101

T

- tape drive
 - cabling example 153
 - configuration of 153
 - installation of new 154
 - replacement of 149
- TCP/IP diagnostics 38
 - arp 43
 - ipconfig 38
 - nbtstat 44
 - netstat 47
 - ping 40
 - tracert 41
- tracert command 41
 - parameters and descriptions 42
 - running from Windows 42
 - syntax 42
- trademarks 2
- TSTSERIO
 - Windows 58
- TSTSERIO command 56

U

- utilities
 - chkdsk 49
 - Diagnostics Tool 94
 - PEP Maintenance 94, 97
 - Session Trace 98
 - System Monitor 94, 101

V

- video card, failure 210
- viewing 34

W

- Windows
 - Net Stop utility 54
 - TSTSERIO 58
 - viewing 34

1002rp Server Maintenance and Diagnostics

CallPilot

Release 4.0

Document Number: 555-7101-206

Document Version: Standard 1.11

January 2007

All Rights Reserved.

To provide feedback or report a problem in this document, go to
www.nortel.com/documentfeedback.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

*Nortel Networks, the Nortel Networks logo, and the Globemark are trademarks of Nortel Networks.

*Microsoft, MS, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

All other trademarks and registered trademarks are the property of their respective owners.

