



Communication Server 1000 Meridian and CallPilot Server Configuration

CallPilot
Release 4.0

Document Number: 555-7101-510

Document Version: Standard 1.16

January 2007

Copyright © 2007 Nortel Networks.

All Rights Reserved.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

The process of transmitting data and call messaging between the CallPilot server and the switch or system is proprietary to Nortel Networks. Any other use of the data and the transmission process is a violation of the user license unless specifically authorized in writing by Nortel Networks prior to such use. Violations of the license by alternative usage of any portion of this process or the related hardware constitutes grounds for an immediate termination of the license and Nortel Networks reserves the right to seek all allowable remedies for such breach.

Trademarks

*Nortel Networks, the Nortel Networks logo, the Globemark, and Unified Networks, BNR, CallPilot, DMS, DMS-100, DMS-250, DMS-MTX, DMS-SCP, DPN, Dualmode, Helmsman, IVR, MAP, Meridian, Meridian 1, Meridian Link, Meridian Mail, Norstar, SL-1, SL-100, Succession, Supernode, Symposium, Telesis, and Unity are trademarks of Nortel Networks.

3COM is a trademark of 3Com Corporation.

ADOBE is a trademark of Adobe Systems Incorporated.

ATLAS is a trademark of Quantum Corporation.

BLACKBERRY is a trademark of Research in Motion Limited.

CRYSTAL REPORTS is a trademark of Seagate Software Inc.

EUDORA and QUALCOMM are trademarks of Qualcomm, Inc.

ETRUST and INOCULATEIT are trademarks of Computer Associates Think Inc.

DIRECTX, EXCHANGE.NET, FRONTPAGE, INTERNET EXPLORER, LINKEXCHANGE, MICROSOFT, MICROSOFT EXCHANGE SERVER, MS-DOS, NETMEETING, OUTLOOK, POWERPOINT, VISUAL STUDIO, WINDOWS, WINDOWS MEDIA, WINDOWS NT, and WINDOWS SERVER are trademarks of Microsoft Corporation.

GROUPWISE and NOVELL are trademarks of Novell Inc.

INTEL is a trademark of Intel Corporation.

LOGITECH is a trademark of Logitech, Inc.

MCAFEE and NETSHIELD are trademarks of McAfee Associates, Inc.

MYLEX is a trademark of Mylex Corporation.

NETSCAPE COMMUNICATOR is a trademark of Netscape Communications Corporation.

NOTES is a trademark of Lotus Development Corporation.

NORTON ANTIVIRUS and PCANYWHERE are trademarks of Symantec Corporation.

QUICKTIME is a trademark of Apple Computer, Inc.

RADISYS is a trademark of Radisys Corporation.

ROLM is a trademark of Siemens ROLM Communications Inc.

SLR4, SLR5, and TANDBERG are trademarks of Tandberg Data ASA.

SONY is a trademark of Sony Corporation.

SYBASE is a trademark of Sybase, Inc.

TEAC is a trademark of TEAC Corporation.

US ROBOTICS, the US ROBOTICS logo, and SPORTSTER are trademarks of US Robotics.

WINZIP is a trademark of Nico Mark Computing, Inc.

XEON is a trademark of Intel, Inc.

All other trademarks and registered trademarks are the property of their respective owners.

Publication history

January 2007	CallPilot 4.0, Standard 1.16 of the <i>CallPilot Communication Server 1000 System and CallPilot Server Configuration</i> guide is released for general availability.
January 2007	CallPilot 4.0, Standard 1.15 of the <i>CallPilot Communication Server 1000 System and CallPilot Server Configuration</i> guide is released for general availability.
December 2006	CallPilot 4.0, Standard 1.14 of the <i>CallPilot Communication Server 1000 System and CallPilot Server Configuration</i> guide is released for general availability.
December 2006	CallPilot 4.0, Standard 1.13 of the <i>CallPilot Communication Server 1000 System and CallPilot Server Configuration</i> guide is released for general availability.
December 2006	CallPilot 4.0, Standard 1.12 of the <i>CallPilot Succession 1000 System and CallPilot Server Configuration</i> guide is released for general availability.
November 2006	CallPilot 4.0, Standard 1.11 of the <i>CallPilot Succession 1000 System and CallPilot Server Configuration</i> guide is released for general availability.
October 2006	CallPilot 4.0, Standard 1.10 of the <i>CallPilot Succession 1000 System and CallPilot Server Configuration</i> guide is released for general availability.
June 2006	CallPilot 4.0, Standard 1.08 of <i>CallPilot Succession 1000 System and CallPilot Server Configuration</i> is released for general availability.
October 2005	CallPilot 4.0, Standard 1.07 of <i>CallPilot Succession 1000 system and CallPilot Server Configuration</i> is released for general availability.
October 2005	CallPilot 4.0, Standard 1.06 of <i>CallPilot Succession 1000 system and CallPilot Server Configuration</i> is released for general availability.
July 2005	CallPilot 4.0, Standard 1.05 of <i>CallPilot Succession 1000 system and CallPilot Server Configuration</i> is released for general availability.
July 2005	CallPilot 4.0, Standard 1.04 of <i>CallPilot Succession 1000 system and CallPilot Server Configuration</i> is released for general availability.

July 2005	CallPilot 4.0, Standard 1.03 of <i>CallPilot Succession 1000 system and CallPilot Server Configuration</i> is released for general availability.
July 2005	CallPilot 4.0, Standard 1.02 of <i>CallPilot Succession 1000 system and CallPilot Server Configuration</i> is released for general availability.
July 2005	CallPilot 4.0, Standard 1.01 of <i>CallPilot Succession 1000 system and CallPilot Server Configuration</i> is released for general availability.
July 2005	CallPilot 4.0, Standard 1.0 of <i>CallPilot Succession 1000 system and CallPilot Server Configuration</i> is released for general availability.
November 2004	CallPilot 3.0, Standard 1.0; <i>CallPilot Succession 1000 system and CallPilot Server Configuration</i> ; title of book changed; revisions for change of operating system from Windows NT to Windows 2003.
September 2002	Standard 1.0 of <i>CallPilot Succession 1000 system and CallPilot Server Configuration</i> is released for CallPilot 2.0 general availability.

Task List

To set the MGate card's DIP switches.....	44
To install the MGate card	44
To replace an MGate card	47
To connect the DS30X cable	56
To install the DS30X cable for the MPB96 board	61
To provision the ELAN subnet	68
To define the MGCR parameter	70
To configure the IP addresses and enable the Ethernet interface ..	71
To modify the customer data block.....	74
To configure an ACD agent queue	79
To configure agents	82
To enable the card slots	84
To create a default ACD DN	85
To configure a CDN queue	86
To configure a phantom superloop	89
To configure a phantom DN	90
To configure dummy ACD DNs	91
To provision digital phonesets	92
To provision 500/2500 phonesets	93
To modify the route data block	95
To save the configuration	96
To log on to Windows 2003 on the CallPilot server	99
To run the Setup Wizard.....	100
To log on to the CallPilot server	103
To run the Configuration Wizard.....	105
To change pcAnywhere caller passwords	108
To set remote desktop policy.....	100
To add the server as a member of an existing domain:.....	113
To stop and disable the Win 32 Time Service	118
To run Configuration Wizard in a domain	121
To change the computer name.....	121
To change the local account passwords	122
To test the connection to the ELAN subnet	129
To test the connection to the NNS Subnet	130
To verify that CallPilot can receive calls	131
To verify that you can leave a message	132
To add a user for testing purposes	132
To configure the Voice Messaging DN	133
To leave a message	134
To verify that you can retrieve a message.....	135
To test call channels and voice channels	136
To test call channels and fax channels.....	137
To test call channels and speech recognition channels	139
To restore the SDN Table and put all channels back in service	140

Contents

1	How to get Help	11
2	CallPilot and CS 1000 connectivity overview	13
	Overview	14
	Symposium Voice Services Support	17
	Section A: CallPilot network setup	19
	CallPilot and CS 1000 integration	20
	CS 1000 Media Gateway	23
	Section B: Understanding call routing	25
	CS 1000 call routing components	26
	Phantom DNs	28
	CallPilot Service Directory Numbers and the SDN Table	30
	How calls are routed	32
	Multimedia channels in the CallPilot server	34
	How multimedia channels are acquired by callers	35
3	Connecting the CallPilot server to the CS 1000 system	37
	Section A: Installing the MGate card	39
	About the MGate card (NTRB18CA)	40
	Installing the MGate card (NTRB18CA)	43
	Replacing an MGate card (NTRB18CA)	47
	Section B: Connecting the CallPilot server to the switch	49
	About the DS30X cable	50
	Connecting MPB16-4 boards to MGate cards (NTRB18CA)	53
	Connecting the MPB96 boards to MGate cards (NTRB18CA)	58
4	Configuring the CS 1000 system	63
	CS 1000 hardware and software requirements	64
	CS 1000 configuration checklist	65
	Provisioning the ELAN subnet	68
	Defining the Message Register for AML message tracing	70
	Configuring CS 1000 IP addresses and enabling the Ethernet interface	71
	Defining CallPilot in the customer data block	74
	Configuring the ACD agent queue	79
	Configuring ACD agents	81
	Enabling the card slots	84
	Defining the default ACD DN	85
	Configuring CDN queues for messaging services	86
	Configuring phantom DNs	88
	Configuring dummy ACD DNs	91
	Provisioning user phonesets	92

Configuring the route data block for Network Message Service	95
Saving CS 1000 changes	96
5	
Configuring the CallPilot server software	97
Overview	98
Logging on to Windows 2003 on the CallPilot server	99
Running the Setup Wizard	100
Logging on to the CallPilot server with CallPilot Manager	101
Running the Configuration Wizard	105
Changing pcAnywhere caller passwords	108
Setting Remote Desktop Policy on a Server	110
Configuring CallPilot to operate in a Windows 2000 or 2003 domain.	112
6	
Testing the CallPilot installation	123
Checking that CallPilot is ready to accept calls	124
Testing the connection to the ELAN subnet	129
Testing the connection to the NNS Subnet	130
Verifying that CallPilot can receive calls	131
Testing the CallPilot software and channels	132

Chapter 1

How to get Help

This section explains how to get help for Nortel products and services.

Getting Help from the Nortel Web site

The best way to get technical support for Nortel products is from the Nortel Technical Support Web site:

<http://www.nortel.com/support>

This site provides quick access to software, documentation, bulletins, and tools to address issues with Nortel products. More specifically, the site enables you to:

- download software, documentation, and product bulletins
- search the Technical Support Web site and the Nortel Knowledge Base for answers to technical issues
- sign up for automatic notification of new software and documentation for Nortel equipment
- open and manage technical support cases

Getting Help over the phone from a Nortel Solutions Center

If you don't find the information you require on the Nortel Technical Support Web site, and have a Nortel support contract, you can also get help over the phone from a Nortel Solutions Center.

In North America, call 1-800-4NORTEL (1-800-466-7835).

Outside North America, go to the following Web site to obtain the phone number for your region:

<http://www.nortel.com/callus>

Getting Help from a specialist by using an Express Routing Code

To access some Nortel Technical Solutions Centers, you can use an Express Routing Code (ERC) to quickly route your call to a specialist in your Nortel product or service. To locate the ERC for your product or service, go to:

<http://www.nortel.com/erc>

Getting Help through a Nortel distributor or reseller

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller.

Chapter 2

CallPilot and CS 1000 connectivity overview

In this chapter

Overview	14
Symposium Voice Services Support	17

Section A: CallPilot network setup 19

CallPilot and CS 1000 integration	20
CS 1000 Media Gateway	23
Section B: Understanding call routing	25

Section B: Understanding call routing 25

CS 1000 call routing components	26
Phantom DNs	28
CallPilot Service Directory Numbers and the SDN Table	30
How calls are routed	32
Multimedia channels in the CallPilot server	34
How multimedia channels are acquired by callers	35

Overview

Introduction

This guide describes the CS 1000* system setup and CallPilot* server configuration steps of the CallPilot installation. This guide includes:

- configuring the CS 1000 system for correct operation with CallPilot
- connecting the CallPilot system to the CS 1000 system and the Nortel Server Subnet (NS Subnet)
- configuring the CallPilot server

Note: To comply with the Restriction of Hazardous Substances (RoHS) Directive 2002/95/EC, some of the part numbers now contain an E5 or E6 suffix. For example, part number NTRH2014 is now NTRH2014E6. The part numbers in this guide do not contain the suffix.

Before you begin

Before configuring the CS 1000 system and CallPilot server:

- Review the *Installing CallPilot* section in the *CallPilot Installation and Configuration Task List*.
- Complete stage 2 of the *CallPilot Installation and Configuration Task List*.
- Complete the worksheets in the *CallPilot Installation and Configuration Task List*.

Note: If you need a high-level overview of CallPilot and CS 1000 connectivity, then read the remainder of this chapter.

Otherwise, the installation steps begin in the following chapters:

- for tower or rackmount servers, in “Connecting the CallPilot server to the CS 1000 system” on page 37
- for the 201i server, in “Configuring the CS 1000 system” on page 63

Complete the steps in each chapter before you continue to the next chapter.

Installation and configuration checklist

Check off the stages and steps in Table 1 on page 15 as they are completed.

Table 1: Installation and configuration checklist

Step	Description	Check
Stage 1: Install the connectivity hardware.		
	<p>Note: For the 201i server, this stage is not applicable. Hardware connectivity is established when the 201i server is installed in the CS 1000 system, as described in the <i>CallPilot 201i Server Hardware Installation Guide</i>.</p>	
1	If your server is a tower or rackmount server, install the MGate card (NTRB18CA) in the CS 1000 system. For instructions, see “Installing the MGate card (NTRB18CA)” on page 43.	<input type="checkbox"/>
2	Connect the tower or rackmount server to the CS 1000 system. For instructions, see “Connecting the CallPilot server to the switch” on page 49C.	<input type="checkbox"/>
Stage 2: Configure the CS 1000 system and CallPilot server.		
3	Configure the CS 1000 system. Use the “Switch configuration worksheet” that you completed in the <i>CallPilot Installation and Configuration Task List</i> . For configuration instructions, see “CS 1000 configuration checklist” on page 65.	<input type="checkbox"/>
4	Run the Configuration Wizard and configure the CallPilot server. Use the “Configuration Wizard worksheet” that you completed in the <i>CallPilot Installation and Configuration Task List</i> . For configuration instructions, see “Running the Configuration Wizard” on page 105.	<input type="checkbox"/>
5	Change the pcAnywhere password or set the Remote Desktop Policy. <ul style="list-style-type: none"> ■ If you are using pcAnywhere, continue to “Changing pcAnywhere caller passwords” on page 108. <p>Note: pcAnywhere is not supported on the CallPilot 201i system. Continue to “Setting Remote Desktop Policy on a Server” on page 110.</p> ■ If you are using Remote Desktop Connection, continue to “Setting Remote Desktop Policy on a Server” on page 110. 	<input type="checkbox"/>
Stage 3: Test CallPilot connectivity.		
	<p>Note: For instructions, see “Testing the CallPilot installation” on page 123.</p>	
6	Check the CallPilot system-ready indicators to see if CallPilot is ready to accept calls.	<input type="checkbox"/>

Step	Description	Check
7	Test the connection to the ELAN subnet, if applicable.	<input type="checkbox"/>
8	Test the connection to the Nortel Server Subnet (NS Subnet).	<input type="checkbox"/>
9	Verify that CallPilot answers when you dial the Voice Messaging DN.	<input type="checkbox"/>

Stage 4: Test the CallPilot services and channels.

Note: For instructions, see “Testing the CallPilot installation” on page 123.

10	Check the system-ready indicators.	<input type="checkbox"/>
11	Verify network connectivity to the CallPilot server over the ELAN subnet and NNS Subnet.	<input type="checkbox"/>
12	Verify that CallPilot can receive calls.	<input type="checkbox"/>
13	Verify that you can leave a message.	<input type="checkbox"/>
14	Verify that you can retrieve a message.	<input type="checkbox"/>
15	Verify that each call channel and multimedia channel is functioning correctly.	<input type="checkbox"/>
16	Check for CallPilot alarms using the Alarm Monitor in CallPilot Manager. Upon confirmation that CallPilot is operating correctly, clear all alarms.	<input type="checkbox"/>

Stage 5: Install CallPilot Manager on a stand-alone web server (optional).

17	Perform this step only if you want to set up a separate web server for CallPilot administration. This is necessary if you want to use the Reporter application, or if high administration traffic is expected. For instructions, refer to the <i>CallPilot Software Administration Guide</i> .	<input type="checkbox"/>
----	--	--------------------------

Symposium Voice Services Support

Introduction

This section is applicable only if you are enabling the Symposium* Voice Services Support feature. This section provides an overview of the specific CS 1000 configuration steps required for the Symposium Voice Services Support feature.

Notes:

For Symposium integration with CallPilot, Symposium channels can only be voice channels.

ACD overflow is not supported.

Configuring the CS 1000 system to support CallPilot and Symposium Call Center Server

This guide provides the specific CS 1000 system configuration instructions required to support CallPilot. Where there is an exception or additional step required for the Symposium Voice Services Support feature, this information is also provided. A list of these exceptions and additional steps is provided below:

1. In overlay 17 (see “Provisioning the ELAN subnet” on page 68), the SECU prompt must be set to YES.
2. You must set up two additional ACD agent queues: one for ACCESS ports, and one for IVR* ports. See “Configuring the ACD agent queue” on page 79.
3. In overlay 11, you must specify AST 0 1, where 0 is the number for key 0, and 1 is the number for key 1.

Configuring CallPilot for Symposium Voice Services Support

To configure CallPilot for Symposium Voice Services Support, make the following changes.

1. In the Configuration Wizard, you must specify the following information for the Symposium Voice Services Support feature:
 - On the CS 1000 Information web page, you must specify the Symposium Call Center Server NNS Subnet IP address.
 - In the Channel Detail Information dialog box, you must select the check box for ACCESS or IVR for channels that are to be used for the Symposium Voice Services Support feature. These are the same channels that you must program on the CS 1000 system in an ACCESS ACD queue or IVR ACD queue. Also specify the Class ID for the channel.
2. In the CallPilot Manager Service Directory Number page, do the following:

- Use the ACCESS ACD-DN to create an SDN for the Symposium Voice Services Support feature.
- Define treatment IDs used by Symposium Call Center Server as voice menus or announcements.

See also

Refer to the Symposium Call Center Server documentation for additional CS 1000 system instructions related to Symposium Call Center Server configuration.

For additional information on Symposium to CallPilot integration, refer to the *CallPilot Distributor Technical Reference*.

Section A: CallPilot network setup

In this section

CallPilot and CS 1000 integration	20
CS 1000 Media Gateway	23
Section B:Understanding call routing	25
Section B:Understanding call routing	25

CallPilot and CS 1000 integration

Introduction


This section describes how the CallPilot server is integrated into your network with the CS 1000 system.

Sample network diagrams

201i server


Figure 1 on page 20 shows an example of how the 201i server can be integrated with the CS 1000 system in your network.

Figure 1: 201i integrated with CS 1000



Tower or rackmount servers

Figure 2 on page 21 shows how a tower or rackmount server can be integrated with the CS 1000 system in your network:

Figure 2: tower/rackmount server integrated with CS 1000

Note: The above diagram shows a tower server. However, the same configuration applies to a rackmount server.

CS 1000 network setup

In the previous illustrations, the telephony LAN (TLAN) provides IP connectivity between the CS 1000 system and the i2004 Internet phonesets. The connection between the Call Server and Media Gateway can be point-to-point, or it can be through the LAN, if the system is installed in a distributed data network.

For information about the CS 1000 system and i2004 Internet phoneset bandwidth and network requirements, refer to the *Communication Server 1000S: Installation and Configuration (553-3031-210)*.

For a description of each CS 1000 system component, see “CS 1000 Media Gateway” on page 23.

CallPilot components

CallPilot server

The CallPilot server connects to the CS 1000 system and, where desktop messaging is enabled, to the Nortel Server Subnet (NS Subnet). If your server is a 201i server, it resides inside the CS 1000 system.

MGate card (NTRB18CA) — tower and rackmount servers only

The MGate card (NTRB18CA) is a line card that is installed inside the CS 1000 system. The MGate card sends the voice and data signals to the MPB boards in the CallPilot server.

MPB boards (for tower and rackmount servers only)

The CallPilot server supports the following types of MPB boards:

- **MPB16-4 boards**
DSPs are provided on the MPB16-4 board in the form of two integrated MPCs and up to four optional MPC-8 cards. (For more information about MPC-8 cards, see “MPC-8 cards” on page 22.)
MPB 16-4 boards are no longer shipped with the CallPilot server. The MPB96 supersedes the MPB16-4.
- **MPB96 boards**
DSPs are provided on the MPB96 board in the form of 12 integrated MPCs. MPC-8 cards are not required on the MPB96 board.

Each tower or rackmount CallPilot server ships with at least one MPB96 board.

MPC-8 cards

The MPC-8 cards reside in slots in the 201i server, or in the MPB16-4 board for tower or rackmount servers. These cards process the voice and data signals that arrive from the CS 1000 system.

See also “Multimedia channels in the CallPilot server” on page 34.

Modem

The server connects to a modem to allow remote access by a support PC for installation, maintenance, and diagnostics.

Desktop client PCs

You can install desktop client messaging software on client PCs to enable mailbox users to receive phone, fax, and voicemail on their PCs. For more information, refer to the *Desktop Messaging and My CallPilot Installation Guide (555-7101-505)*.

Any PC that has network access to the CallPilot server and has a web browser installed can be used to administer CallPilot. The CallPilot administration software is web-based.

CS 1000 Media Gateway

Introduction

The Media Gateway and Media Gateway Expansion provide the interface for analog or digital trunks, i2004 Internet phonesets, analog phonesets, and applications such as CallPilot.

Media Gateway and Media Gateway Expansion

The Media Gateway and the Media Gateway Expansion provides four IPE slots. These slots support cards such as analog line cards, trunk cards, and application cards. The CallPilot 201i server is an application card that occupies two consecutive slots. The MGate Card (NTRB18CA) is a line card that occupies only one slot.

For a list of the cards that are supported by the CS 1000 system, refer to the *Communication Server 1000S: Installation and Configuration (553-3031-210)*.

ATTENTION

Media Gateway shelves in a CS 1000E do not share the same clock reference. Media Gateway expander shelves share the same clock reference as the Media Gateway shelf that they are connected to. In a CS 1000E, all MGate cards connected to the CallPilot system must reside in the same Media Gateway/Media Gateway Expansion shelf pair. For the CS 1000M and CS 1000S, the MGate cards can reside in separate shelves.

Figure 3 on page 24 shows a Media Gateway.

Figure 3: Media Gateway

G101624

Except for the back panel connectors, the Media Gateway Expansion is similar in external appearance to the Media Gateway.

The MGate Card (NTRB18CA), applicable to tower or rackmount servers only, occupies one slot in the CS 1000 system.

Note: For information about the CS 1000 card slots in relation to the 201i server, refer to *CallPilot 201i Server Hardware Installation Guide (555-7101-220)*.

Section B: Understanding call routing

In this section

CS 1000 call routing components	26
Phantom DNs	28
CallPilot Service Directory Numbers and the SDN Table	30
How calls are routed	32
Multimedia channels in the CallPilot server	34
How multimedia channels are acquired by callers	35

CS 1000 call routing components

Introduction

The CS 1000 system uses the following components to route calls:

- Automatic Call Distribution (ACD)
- Control Directory Number (CDN)

Automatic Call Distribution

Automatic Call Distribution (ACD) is a feature on the CS 1000 system that allows a number of programmed phonesets, known as ACD agents, to share equally in answering incoming calls. In the case of CallPilot, the call-queuing capability of ACD is not used, but the call-handling capability of ACD agents is used.

How CallPilot uses ACD virtual agents

All ACD agents that service CallPilot are put into a single ACD agent queue (unless you are enabling the Symposium Voice Services Support feature; see “How multimedia channels are acquired by callers” on page 35). These agents correspond to DS0 channels on the CallPilot server. Agents are programmed in overlay 11 as 2008 Digital (Aries) sets with Multimedia Messaging Allowed (MMA) class of service. These are not, however, physical phonesets. These are Terminal numbers (TNs) that are programmed to look like real digital sets to the CS 1000 system.

Control Directory Number

For CallPilot, you configure one Control Directory Number (CDN) on the CS 1000 system for each of the following services:

- a primary CDN for Voice Messaging
- a secondary CDN for Multimedia Messaging

A CDN queue is like an ACD queue. The key difference is that calls in the CDN queue are managed by CallPilot, while calls in an ACD queue are managed by the CS 1000 system.

Calls are routed to the CDN queue directly or by terminating on a phantom DN or dummy ACD queue, which is forwarded to the CDN.

How CallPilot uses CDNs

A CDN can operate in one of two modes:

- control mode
- default mode

Normally, a CDN operates in control mode. In control mode, call treatment and call routing are under the control of the CallPilot server. The CS 1000 system simply provides routing to CallPilot. The server specifies the type of treatment to be given to waiting calls. The server processes the calls on a first-come, first-served basis and determines to which DS0 channel the call is routed. DS0 channels are configured as agents of an ACD queue.

A CDN can also operate in default mode (for example, when CallPilot is offline or the AML is down). In default mode, the CS 1000 system takes over call-routing control. Incoming calls receive default treatment provided by the default ACD DN associated with the CDN.

Call queuing

Incoming calls to the CDN are queued in the order of arrival. If calls cannot be processed immediately and must wait in the queue until resources are available, the first caller in the queue is handled first.

Call routing

The CallPilot server determines which DS0 channel can provide the dialed service requested by a waiting call, and instructs the CS 1000 system to route the call to the associated ACD agent.

See also

- “Phantom DNs” on page 28
- “CallPilot Service Directory Numbers and the SDN Table” on page 30

Phantom DNs

Introduction

Instead of using phonesets or dummy ACD DNs to route calls, CallPilot can use “virtual telephones” that exist only in software and have no associated hardware. The DN associated with one of these phantom phones is called a phantom DN.

Creating a Phantom DN

To create a phantom DN, you first create a phantom loop, and then you define a TN within that loop. The system recognizes that any TN defined within that loop is a phantom TN. Each phantom TN is assigned a DN (the phantom DN). When the DN is entered in the CallPilot Service Directory Number page, it becomes the dialable number of a CallPilot service.

Phantom DNs forward to a CDN queue

Incoming calls cannot queue up in the phantom TN as they arrive. When a call arrives at a phantom DN, the system forwards it to a CDN queue before it is routed to a multimedia channel for further call handling. However, the system remembers the phantom DN to keep track of the requested service.

Services that should use phantom DNs

Nortel strongly recommends that you use either phantom DNs or dummy ACD DNs (see “Configuring ACD agents” on page 81) for the following services:

- all services created with Application Builder that are directly dialable by callers
- Speech Activated Messaging
- Paced Speech Messaging
- Voice Item Maintenance
- Fax Item Maintenance
- Express Voice Messaging
- Express Fax Messaging

Networking services

The following Networking services can either have a unique phantom DN configured on the CS 1000 system, or they can share the phantom DN (and SDN) of another service:

- Enterprise Networking
- AMIS Networking
- Integrated AMIS Networking

Share DNs when your supply of available DNs on the CS 1000 system is low. Create a unique DN when you need to closely monitor each service (for example, so that each service generates its own traffic data in Reporter).

Note: After you configure the SDN in CallPilot, specify with which service you are sharing the SDN.

Example

You are ready to put a new menu application into service. Phantom DN 6120 is available on the CS 1000 system. In the Service Directory Number page, you enter 6120 as the SDN for this service. This is the number that callers dial to access the menu.

CallPilot Service Directory Numbers and the SDN Table

Introduction

When a call arrives at a CDN queue either directly or indirectly from a phantom DN or dummy ACD DN, the CS 1000 system gives the caller ringback treatment. While this happens, the dialed DN is looked up in the SDN Table in CallPilot to determine what service is required.

What is the SDN Table?

The SDN Table is where the CDNs, phantom DNs, or dummy ACD DNs that have been configured on the CS 1000 system for your CallPilot services are recorded. In this table, the DN (now called an SDN) is associated with a specific service. You use the CallPilot Manager Service Directory Number page to administer the SDN Table.

What the SDN Table controls

In addition to specifying which service should be activated when a number is dialed, the SDN Table also controls

- the type of channel the service acquires (voice, fax, or speech recognition)
 - the number of channels allocated to the service
- The SDN configuration determines the minimum number of channels guaranteed to a service for simultaneous use and the maximum number of channels that you can use at one time.
- the session behavior for certain services, such as those created with Application Builder (including the maximum session length and a number of fax options)

Types of SDNs

There are two types of SDNs—inbound SDNs and outbound SDNs.

Inbound SDNs require DNs on the CS 1000 system

Services that callers dial need inbound SDNs. An inbound SDN corresponds to either a CDN, a phantom DN, or a dummy ACD DN on the CS 1000 system, since callers must be able to dial in to the CS 1000 system with a unique number.

Outbound SDNs do not require DNs on the CS 1000 system


Callers do not dial outbound SDNs. The system uses outbound SDNs to place outbound calls. Because outbound SDNs do not accept incoming calls, a corresponding CDN, phantom DN, or dummy ACD DN is not necessary on the CS 1000 system.

The following services use outbound SDNs:

- outcalling services (Remote Notification, Delivery to Telephone, Delivery to Fax)
- networking services (AMIS Networking and Enterprise Networking)

How calls are routed

Figure 4: Call flow example



G101145

Note: The example above uses a phantom DN. The same call flow occurs when a caller dials a dummy ACD DN.

Example of phantom DN or dummy ACD DN usage

Two CDN queues have been configured:


- Voice Messaging (6030)
- Multimedia Messaging (6050)

Two phantom DN's have been configured (the same scenario applies if these are set up as dummy ACD DN's):

- 6090 is the DN for a menu service (without fax items)
- 6095 is the DN for Fax Item Maintenance

In Figure 5 on page 33, when the calls come in to the CS 1000 system, there are no available channels, and the calls are queued as a result.

Figure 5: No available channels, calls queued



What happens when users dial the service DNs

1. A caller dials 6090 to access a menu service. This phantom DN forwards to CDN 6030 because the menu contains no fax or speech recognition capability.
2. Another caller dials 6095 to access the Fax Item Maintenance service. The call is forwarded to CDN 6050.
3. CallPilot looks up the DNs in the SDN Table on the server to check which service is being requested, the media type required, and the channel allocations for each service.
4. Call 1, to the menu service that contains only voice functions (no fax items), is routed to an ACD agent that is available to handle voice.
5. Call 2, to the Fax Item Maintenance service, is routed to an ACD agent that is available to handle fax.

Multimedia channels in the CallPilot server

Multimedia Processing Units

In addition to the CPU processing power required by CallPilot, calls that are received by CallPilot require DSP processing power to support the voice, fax, and speech recognition features. DSP processing power is provided by Multimedia Processing Units (MPUs) in the CallPilot server. MPUs are provided by the following CallPilot hardware:

- MPB boards (MPB16-4 for the 1002rp server only, or MPB96)
- MPC-8 cards (if MPB16-4 boards are used)

Types of multimedia channels

Certain types of media require more channel resources to process them. As a result, three types of multimedia channels handle the various types of CallPilot services. Each type of channel terminates on a different number of MPUs, based on how much processing power is required. For example, integrated fax and voice data takes twice as much processing power as voice-only media. A fax channel, therefore, terminates on two MPUs.

Table 2: Number of MPUs per Channel Type

Channel type	Number of MPUs	Description
Voice	1	One voice channel requires one MPU.
Fax	2	Fax requires twice as much processing power as voice-only media, and, therefore, requires two MPUs for one fax channel.
ASR (automated speech recognition)	4	Speech recognition requires four times as much processing power as voice-only media, and, therefore, requires four MPUs for one speech recognition channel.

How multimedia channels are acquired by callers

Introduction

The system uses the information gathered from the SDN configuration to check the ACD agent queue to determine if an idle multimedia channel of the type required by the service is available.

IF	THEN
an idle channel (of the required media type) is available	the system passes the call to CallPilot.
idle channels that meet the requirements defined in the SDN Table are not available	the call remains in the CDN queue and the system applies a delay treatment. The server specifies a default delay treatment of ringback. This means that while a call waits in a queue, the caller hears the phone ringing.

What happens when the call is answered

When a multimedia channel of the appropriate type becomes idle, the call arrives at the multimedia channel and is passed to CallPilot.

Because the SDN Table has already been checked, the requested service is known and is activated. The service also answers the call.

Based on which service is activated, one of the following results happens:

- The appropriate prompt is played.
- CallPilot receives a fax.
- CallPilot records a message.

What happens when the call is dropped

When CallPilot or the caller drops the call (hangs up), the multimedia channel returns to an idle state, ready to be acquired by another call.

What's next?

IF your server is a	THEN
tower or rackmount server (703t, 1002rp or 1005r)	continue with “Connecting the CallPilot server to the switch” on page 49.
201i server	continue with “Configuring the CS 1000 system” on page 63.

Chapter 3

Connecting the CallPilot server to the CS 1000 system

In this chapter

Section A: Installing the MGate card	39
About the MGate card (NTRB18CA)	40
Installing the MGate card (NTRB18CA)	43
Replacing an MGate card (NTRB18CA)	47
Section B: Connecting the CallPilot server to the switch	49
About the DS30X cable	50
Connecting MPB16-4 boards to MGate cards (NTRB18CA)	53
Connecting the MPB96 boards to MGate cards (NTRB18CA)	58

Section A: Installing the MGate card

In this section

About the MGate card (NTRB18CA)	40
Installing the MGate card (NTRB18CA)	43
Replacing an MGate card (NTRB18CA)	47

About the MGate card (NTRB18CA)

Introduction

The MGate card (NTRB18CA) is the line interface card in the CS 1000 system that supports the call channels for CallPilot. A DS30X cable connects the MGate card to the CallPilot server.

Note: The MGate card is hot-swappable. Therefore, you do not need to power down the CS 1000 system before installing or removing an MGate card.

ATTENTION

An MGate card is not used with the 201i server. For the 201i server, the connection to the CS 1000 system is established in the Media Gateway or Media Gateway Expansion when the server is installed. For more information, see the *CallPilot 201i Server Hardware Installation guide*.


Number of channels supported

Each MGate card (NTRB18CA) supports 32 channels. These 32 channels can be any combination of voice, fax, and automated speech recognition channels. For example, you can have 16 voice, 8 fax, and 8 automated speech recognition channels supported by a single MGate card.

On the CallPilot server side, you require additional DSP MPUs to support fax or automated speech recognition channels, but this does not affect the number of channels supported by the MGate card.

LED indicators

The MGate card (NTRB18CA) has red and green LED indicators on the faceplate.

Figure 6: MGate LED indicators

The combined state of the red and green LEDs provides important indicators of the MGate card's status.

Table 3: MGate card status

Red LED	Green LED	Description
OFF	ON	The MGate card is enabled in the CS 1000 system software, and the MGate card is operational.
OFF	OFF	The MGate card is not receiving power, or the MGate card is faulty.
ON	ON	The MGate card is disabled in the CS 1000 system software, but the MGate card is operational.
ON	OFF	The MGate card is disabled in the CS 1000 system software, and the MGate card is faulty.
blinking	blinking	The MGate card is executing self-test diagnostics.

Impact of a faulty MGate card (NTRB18CA)

The CS 1000 system may or may not recognize when an MGate card is faulty. If the CS 1000 system does recognize the problem, then it automatically disables the MGate card and informs CallPilot that the MGate card is faulty.

If the CS 1000 system does not recognize that the MGate card is faulty, it does not automatically disable it. In this situation, you must use overlay 32 to manually disable the MGate card slot.

The DS0 channels associated with the disabled MGate card are taken out of service by CallPilot and assigned a Remote Off Duty status. If there are multiple MGate cards, then CallPilot continues to use the DS0 channels associated with the functioning MGate cards.

Required components

Table 4: MGate card components

Component	Part Number	Description
MGate card	NTRB18CA	Installed in the Media Gateway or Media Gateway Expansion.
DS30X cable (MPB16-4)		Connects the MPB16-4 boards in the CallPilot server to the MGate cards in the Media Gateway or Media Gateway Expansion.
■ Single cable	NTRH2012	
■ Dual cable	NTRH2013	
DS30X cable (MPB96)	NTRH2014	Connects the MPB96 boards in the CallPilot server to the MGate cards in the Media Gateway or Media Gateway Expansion.



CAUTION

Risk of DATA LOSS

The MGate card (NTRB18CA) is shipped from the factory with the appropriate DS30X cables. Do not substitute other versions of these boards and cables in the configurations specified in this documentation, as this can result in data loss.

Installing the MGate card (NTRB18CA)

Introduction

This section describes how to

- set the MGate card's DIP switches
- install the MGate card in the Media Gateway or Media Gateway Expansion
- replace the MGate card

Before you begin


To minimize network blocking, refer to NTP 553-3021-120 for segmenting and traffic rules. Determine which slot you will use to house the MGate card. You can install MGate cards on all IPE slots in the Media Gateway or Media Gateway Expansion.

Note: Media Gateway shelves in a CS 1000E do not share the same clock reference. In a CS 1000E, all MGate cards connected to the CallPilot system must reside in the same Media Gateway or Media Gateway Expansion shelf. For the CS 1000M and CS 1000S, the MGate cards can reside in separate shelves.

For more information about card slots, refer to the *Communication Server 1000S: Installation and Configuration (553-3031-210)*.

MGate Card (NTRB18CA) DIP switches

Figure 7 on page 44 shows an MGate card with the location of the DIP switches.

Figure 7: MGate DIP switches

To set the MGate card's DIP switches

- 1 Remove the MGate card from its protective sleeve.
- 2 Set the DIP switches on the MGate card as shown in Table 5 on page 44. These DIP switch settings are used for all MGate cards and all system configurations.


Table 5: MGate DIP switch settings

	1	2	3	4	5	6	7	8
ON	X	X	X				X	
OFF				X	X	X		X


To install the MGate card

- 1 Remove the Media Gateway or Media Gateway Expansion cover.
- 2 Ensure that the slot in which you are installing the MGate does not already have a cable connected.
- 3 Press and pull the top and bottom latches on the MGate card outward to open the latches for installation of the card.

A hook on the bottom of the latch must clear a small pin to open. Refer to Figure 8 on page 45.

Figure 8: Media Gateway slot latch

- 4 Slide the MGate card into an unoccupied slot.
When correctly inserted, the top of the MGate card is on the left. See the following diagram.

Figure 9: MGate cards in slots

- 5 Press the lock latches to close them.
This locks the MGate card into position against the backplane.
- 6 View the status of the LED indicators to ensure that the card is software-enabled (red LED is OFF) and the card is operational (green LED is ON).
For more information about the LEDs, see “LED indicators” on page 40.
- 7 Replace the inside front cover plate and front bezel. See “To replace the inside front cover plate” on page 44 and “To replace the front bezel” on page 46.

ATTENTION

Ensure that the tabs on the bottom and right side of the inside front cover plate are positioned inside the Media Gateway or Media Gateway Expansion.

What's next?

Continue with “Connecting the CallPilot server to the switch” on page 49.

Replacing an MGate card (NTRB18CA)

Introduction

If the MGate card becomes faulty, follow this procedure to replace it.

To replace an MGate card

Note: You do not need to power down the switch for this procedure as the MGate card is hot-swappable.

- 1 Courtesy stop the DS0 channels from the CallPilot administrative PC to stop all call processing gracefully.

To do this, use the Channel Monitor or the Maintenance page in CallPilot Manager, as described in the *CallPilot Server Maintenance and Diagnostics guide* for your server.

Note: If your system has multiple MGate cards, you can choose to courtesy stop only the DS30X channels that belong to the MGate card that is being replaced.

- 2 Remove the switch's front cover to expose the shelf slots.
- 3 Open the latches to unlock the faulty MGate card.
- 4 Remove the faulty MGate card from the switch.
- 5 Press the replacement MGate into the same slot that the faulty MGate card occupied.

Note: If you place the MGate card in a new slot, then you must do the following:

- a. Reprogram the switch to account for the new slot number.
- b. Move the DS30X cable to the new slot.
- c. Reconfigure the software from the CallPilot administrative client PC.

- 6 Press the latches on the top and bottom of the MGate card to close them.

Result: This locks the card into position against the backplane.

- 7 View the status of the LED indicators to ensure that the card is software-enabled (red LED is OFF) and the card is operational (green LED is ON).
- 8 Re-enable the DS0 channels that were disabled before the card was removed.

To do this, use the Channel Monitor or the Maintenance page in CallPilot Manager, as described in the *CallPilot Server Maintenance and Diagnostics guide* for your server.

Section B: Connecting the CallPilot server to the switch

In this section

About the DS30X cable	50
Connecting MPB16-4 boards to MGate cards (NTRB18CA)	53
Connecting the MPB96 boards to MGate cards (NTRB18CA)	58

About the DS30X cable

Introduction

The MGate card (NTRB18CA) ships from the factory with the DS30X cables required by the MPB board that is installed in the server.



CAUTION

Risk of data loss

Do not substitute other versions of these boards and cables in the configurations specified in this documentation, as this can result in data loss.

DS30X cables supported by MPB16-4 boards

The DS30X cable that establishes the connection between the MPB16-4 boards and the MGate cards is 10 m (30 ft) long. Therefore, the CallPilot server must be placed within 10 m (30 ft) of the Media Gateway or Media Gateway Expansion.

IF the server is equipped with	THEN the DS30X cable is an
one MPB16-4 board	NTRH2012 cable. This is a single DS30X cable that connects one MPB16-4 board to one MGate card.
more than one MPB16-4 board	NTRH2013 cable. This is a dual DS30X cable that connects the first of two MPB16-4 boards to two MGate cards. The connectors on the NTRH2013 dual DS30X cable are labeled DS30X-1 and DS30X-2.

Note: The NTRH2012 and NTRH2013 cables contain ferrites that control EMC emission levels. Do not remove them.


DS30X cable supported by the MPB96 board

The NTRH2014 cable is a triple DS30X cable that connects the first MPB96 board to up to three MGate cards. The cable is 20 m (60 ft) long, which allows you to install the CallPilot server in a different room from the Media Gateway or Media Gateway Expansion.

One end of the cable has a 44-pin connector that connects to the MPB96 board's faceplate. If the server is equipped with more than one MPB96 board, the cable connects to the first board. Note that two NTRH2014 cables are required in high capacity M1 switch configurations. The first and second MPB96 cards of high capacity configurations require NTRH2014 cables but the third MPB96 card does not have a DS30X cable. All three MGate cards associated with any one MPB96 card must all be on the same physical M1 shelf backplane. See the following table for slot information.

Server	MPB96-1	MPB96-2	MPB96-3
1002rp	PCI slot 3	PCI slot 6	PCI slot 9 (no cable connected)
1005r	Slot 1	Slot 2	Slot 3 (no cable connected)

The other end of the cable has three 50-pin connectors that connect to MGate cards. The MGate connectors are labeled DS30X-1, DS30X-2, and DS30X-3. Refer to Figure 10 on page 52.

Figure 10: Connectors between MGate and MPB96

Note: The ferrites on this cable control EMC emission levels. Do not remove them.

Connecting MPB16-4 boards to MGate cards (NTRB18CA)

Introduction

This section describes the MPB16-4 board and MGate card connection scenarios that your CallPilot server supports. You must use the appropriate DS30X cable for the connection scenario—either the NTRH2012 or the NTRH2013 cable.

Note: For a description of the MPB16-4 board, refer to the CallPilot Server *Maintenance and Diagnostics guide* for your server.

Cabling diagrams

The following table lists the supported configurations that illustrates the configuration.

Table 6: Cabling configurations

Number of channels	Number of MPB16-4 boards	Number of MGate cards
32 or less	1	1
32 or less	2	1
48 or less	1	2
48 or less	2	2

Identifying the location of MPB #1 and MPB #2

In the cabling diagrams, the terms MPB16-4 #1 and MPB16-4 #2 are used to identify the two MPB16-4 boards. The table below indicates the location of these boards.

Table 7: MPB16-4 slot locations

MPB Number	1002rp server
MPB16-4 #1	slot 11
MPB16-4 #2	slot 12

Note: On the 1002rp servers, MPB16-4 #1 is the MPB16-4 board closest to the SBC card. For more information on slot assignments, refer to the slot assignment tables in the CallPilot Server *Hardware Installation guide* for your server.


Identifying the location of MGate #1, #2, and #3

In the cabling diagrams, the terms MGate #1, MGate #2, and MGate #3 identify the MGate cards. MGate #1 is in the lowest-numbered slot in the Media Gateway or Media Gateway Expansion. MGate #2 and MGate #3 are in the next available higher slots.

One MPB16-4 board and one MGate card (32 channels or less)

Use the single cable (NTRH2012) to connect the MPB16-4 board to the MGate card. Refer to Figure 11 on page 54.


Figure 11: MGate cabling for the 1002rp server



Two MPB16-4 boards and one MGate card (32 channels or less)


Use the DS30X single cable (NTRH2012) to connect the MPB16-4 #1 to the MGate card. Refer to Figure 12 on page 55.

Note: The MPB number is identified during system startup. Therefore, you must connect the DS30X cable to the MPB assigned the lower bus number by the software.

Figure 12: MGate cabling for the 1002rp server**One MPB16-4 board and two MGate cards (48 channels or less)**

Use the NTRH2013 cable, as shown in the diagrams that follow. Ensure that

- the connector labeled DS30X-1 is connected to MGate #1
- the connector labeled DS30X-2 is connected to MGate #2


Figure 13: MGate cabling for the 1002rp server

Two MPB16-4 boards and two MGate cards (48 channels or less)

Use the NTRH2013 cable, as shown below. Ensure that

- the connector labeled DS30X-1 is connected to MGate #1
- the connector labeled DS30X-2 is connected to MGate #2

Figure 14: MGate cabling for the 1002rp server




To connect the DS30X cable

Before you begin, review the supported cabling configurations illustrated in Table 6 on page 53.

- 1 On the bottom of the Media Gateway or Media Gateway Expansion, locate the connector associated with the slot occupied by the MGate card.
- 2 Attach the DS30X connector on the NTRH2012 or NTRH2013 cable to the slot connector as shown in the previous diagrams.
 - a. Loosen the connector's Velcro fastening strap.
 - b. Connect the amphenol connector on the MGate cable to the connector on the back of the Media Gateway or Media Gateway Expansion.
 - c. Secure the connection by tightening the connector's retaining screw and Velcro fastening strap.

The following diagram describes how to secure the MGate cable connection.

Figure 15: DS30X cable connection

- 3 Connect the other end of the MGate cable to the MPB16-4 board's connector on the bottom of the CallPilot server.

What's next?

Continue with "Configuring the CS 1000 system" on page 63.

Connecting the MPB96 boards to MGate cards (NTRB18CA)

Introduction



The CallPilot server ships from the factory with one or three MPB96 boards already installed. Since the MPB96 boards are already installed in the server, you only need to connect them to the MGate card in the Meridian 1 switch with the NTRH2014 DS30X cable. Note that the third MPB96 card is installed to provide 96 more MPUs for increased multimedia traffic capacity and it is not connected to the Meridian 1 switch. Refer to Figure 18 on page 60.

You can connect the MPB96 board to up to three MGate cards, depending on the number of DS0 channels. If fewer than three MGate cards are present, you can leave the unused parts of the NTRH2014 cable unconnected.

ATTENTION

You must connect the DS30X-1 cable to an MGate card to receive the clock source for the MPB96 board. Failure to connect the DS30X-1 cable to an MGate card can result in noise interference on the remaining voice channels.


Note: For a description of the MPB96 board, refer to the *CallPilot Server Maintenance and Diagnostics guide* for your server.

MGate cabling for the 703t server**Figure 16: One MPB96 board and three MGate cards (up to 96 channels)****MGate cabling for the rackmount servers****Figure 17: One MPB96 board and three MGate cards (up to 96 channels)**

High-capacity—three MPB96 boards and six MGate cards

Three MPB96 boards, installed with six MGate cards, provide a capacity of up to 192 channels and 288 MPUs.

Figure 18: High capacity 3-MPB96 and 6-MGate




Note that all three MGate cards associated with any one MPB96 card should all be on the same physical shelf backplane. Nortel recommends that M1 traffic engineering and configuration rules be re-checked whenever adding or moving MGate cards. (Refer to NTP 553-3021-120.) This may be helpful to ensure that channel blocking to MGate cards does not occur due to inappropriate M1 superloop provisioning, M1 backplane partitioning or incorrect M1 backplane cabling.

To install the DS30X cable for the MPB96 board

- 1 On the bottom of the Media Gateway or Media Gateway Expansion, locate the connector associated with the slot occupied by the MGate card.
- 2 Attach the DS30X connector on the NTRH2014 cable to the slot connector as shown in the previous diagram.
 - a. Loosen the connector's Velcro fastening strap.
 - b. Connect the amphenol connector on the MGate cable to the connector on the back of the Media Gateway or Media Gateway Expansion.
 - c. Secure the connection by tightening the connector's retaining screw and Velcro fastening strap.

Figure 19 on page 61 shows how to secure the MGate cable connection.

Figure 19: DS30X cable connection to MPB96

G101592

- 3 Connect the other end of the MGate cable to the MPB96 board's connector on the bottom of the CallPilot server.

What's next?

Continue with "Configuring the CS 1000 system" on page 63.

Chapter 4

Configuring the CS 1000 system

In this chapter

CS 1000 hardware and software requirements	64
CS 1000 configuration checklist	65
Provisioning the ELAN subnet	68
Defining the Message Register for AML message tracing	70
Configuring CS 1000 IP addresses and enabling the Ethernet interface	71
Defining CallPilot in the customer data block	74
Configuring the ACD agent queue	79
Configuring ACD agents	81
Enabling the card slots	84
Defining the default ACD DN	85
Configuring CDN queues for messaging services	86
Configuring phantom DNs	88
Configuring dummy ACD DNs	91
Provisioning user phonesets	92
Configuring the route data block for Network Message Service	95
Saving CS 1000 changes	96

CS 1000 hardware and software requirements

Required hardware

To support connectivity to tower and rackmount CallPilot servers, you must install one or more MGate cards (NTRB18CA) in the Media Gateway or Media Gateway Expansion, as described in Section A: “Installing the MGate card,” on page 39. Note that if upgrading from Meridian Mail to CallPilot, MGate cards must be changed from NTRB18AA to NTRB18CA.

ATTENTION

An MGate card (NTRB18CA) is not used with the 201i server.

Required CS 1000 system software

To support the CallPilot 201i server, the CS 1000 system requires software release X21 Release 3.0 or later.

To support the CallPilot 1005r, 703t and 1002rp servers, the CS 1000 system requires software release X21 Release 3.0 or later.

Required X21 PEPs

Check the CallPilot Distributor Technical Reference (DTR) at <http://my.nortel.com> for required X21 PEPs.

You require a user name and password to access this site.

X21 PEPs are available only on the Meridian* PEP Library (MPL) web site at: <https://transportvo.nortel.com/mpl/mpl>

If you cannot access the Meridian PEP Library, or if you cannot find the Service Updates (SUs), check the CallPilot Distributor Technical Reference, or contact your Nortel representative.

The Meridian PEP Library is a secure web site requiring a user name and a password to log on. If you do not have an account, you must apply for one. It can take up to 72 hours to process your account request.

CS 1000 configuration checklist

Introduction

The following checklist provides a list of the tasks you must complete for correct CallPilot and CS 1000 system interoperation. Detailed instructions are provided for each task, as indicated, in the remainder of this chapter.

Table 8: Configuration checklist

Step		Overlay	See page	Check
1	Ensure that the ELAN subnet for the AML link and its associated VSID in the configuration record is defined. This provides the Ethernet connection over which AML messages are exchanged between the CS 1000 system and CallPilot.	17	68	<input type="checkbox"/>
2	Define the Message Register for AML message tracing.	17	70	<input type="checkbox"/>
3	If the CS 1000 system has not been defined with an IP address, configure it for the ELAN subnet interface.	117	71	<input type="checkbox"/>
4	Enable the ELAN subnet link.	137	71	<input type="checkbox"/>
5	Enable the ELAN subnet connection.	48	71	<input type="checkbox"/>
6	Define CallPilot in the customer data block with the Call Park Allowed (CPA) and Message Center Included (MCI) options enabled. Also define in the customer data block how unanswered and busy calls are routed.	15	74	<input type="checkbox"/>
7	Define the Call Forward by Call Type feature.	16	77	<input type="checkbox"/>
8	Create an ACD agent queue to hold the agents that service CallPilot. If you are enabling the Symposium Voice Services Support feature, you must also set up two additional ACD agent queues—one for ACCESS ports, and one for IVR ports.	23	79	<input type="checkbox"/>

Step		Overlay	See page	Check
9	Create an agent for each CallPilot channel. All agents belong to the ACD agent queues that you created in step 8.	11	81	<input type="checkbox"/>
10	Enable the slots in which the MGate card (NTRB18CA) is installed.	32	84	<input type="checkbox"/>
11	Define the default ACD DN that will be referenced in each CDN queue. Set this ACD DN as night call forward to the attendant.	23	85	<input type="checkbox"/>
12	Create two CDN queues as follows: <ul style="list-style-type: none"> ■ Create a primary CDN for Voice Messaging. ■ Create a secondary CDN for Multimedia Messaging. 	23	86	<input type="checkbox"/>
13	If required, create a phantom loop.	97	88	<input type="checkbox"/>
14	Create a phantom DN or dummy ACD DN for each service that must be directly dialable.	10 or 23	88 or 91	<input type="checkbox"/>
15	Provision user phonesets to support CallPilot. Notes: <ul style="list-style-type: none"> ■ To determine which phonesets are supported by the CS 1000 system, refer to the <i>Communication Server 1000S: Installation and Configuration (553-3031-210)</i>. ■ For instructions on provisioning i2004 phonesets, refer to <i>Software Input/Output: Administration (553-3001-311)</i>. 	10 or 11	92	<input type="checkbox"/>
16	If you purchased Network Message Service, configure the route data block.	16	95	<input type="checkbox"/>
17	Save the configuration changes.	43	96	<input type="checkbox"/>
18	If you made changes to the ELAN subnet interface configuration in step 3 of this checklist, perform a CS 1000 INI after you have saved the configuration changes (as instructed in step 17 of this checklist).	n/a	n/a	<input type="checkbox"/>
19	To prevent voice channel blocking, check the M1 traffic engineering, M1 superloop wiring, M1 backplane partitioning and M1 cabling. Refer to NTP 553-3021-120.	n/a	n/a	<input type="checkbox"/>

Note: You can also print configuration information from overlay 20 at any time.

How the overlays are presented in this chapter

Overlays are programmed by responding to a series of prompts. The procedures in this section mention only those prompts that require a specific entry for CallPilot.

You can program other prompts if necessary for your site. To accept the default value for other prompts, press Enter.

ATTENTION

Ensure that you update the CS 1000 database when you finish making changes, as described in “Saving CS 1000 changes” on page 96.

Working with overlays

When you work with overlays, follow these general steps:

- 1 Load the appropriate overlay.
- 2 Respond to the prompts as shown in the tables in this section. Press Enter after each prompt until you reach the next one that you must define for CallPilot.
- 3 When you complete the configuration, enter **** in response to the REQ prompt.

The customer number

CallPilot can only be provided on a per customer basis on the CS 1000 system. AML messages used for communications between the CS 1000 system and CallPilot contain a customer number to which CallPilot belongs.

ATTENTION

When you enter the customer number in the overlays, ensure that it is the correct customer number.

Provisioning the ELAN subnet

Introduction

Define and configure the ELAN subnet for the AML link and its associated VSID in the configuration record. This provides the Ethernet connection over which AML messages are exchanged between the CS 1000 system and CallPilot.

To provision the ELAN subnet

- 1 Load overlay 17.
- 2 For each prompt listed below, enter the response indicated. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	CHG	Change
TYPE	ADAN	Action device and number
ADAN	NEW ELAN xx	Configure a new link and assign it a number, where xx is within the ELAN subnet range (16–31). You can use any number in this range as long as it is not already used.
CTYP	ELAN	Card type
DES	x...x	Enter a designator to identify this ELAN subnet.
REQ	CHG	Change
TYPE	VAS	Value added server configuration
VAS	new	Configure a new AML link or change the existing link configuration.
VSID	yy	The VAS identifier can be in the range of 16–31. For convenience, this can be the same number you assigned to the new ELAN subnet link (in response to the ADAN prompt).
ELAN	xx	This should be the same number defined in ADAN.

Prompt	Response	Description
SECU	x...x	If you have Symposium connected to your switch, choose YES (even if you are not using Symposium Voice Services Support).
REQ	CHG	Change
TYPE	PARM	System parameters
NCR	x...x	Number of call registers (range depends on system type). Increment the current value by 2 x the number of CallPilot DS0 channels. For example, if the current NCR value is 500 and there are 24 DS0 channels, change the NCR value to 548.
CSQI	(20) to 255	Maximum number of call registers for CSL input queues. Set this parameter to 2 x the number of CallPilot DS0 channels. For example, if there are 24 DS0 channels, enter 48.
CSQO	(20) to 255	Maximum number of call registers for CSL/AML output queues. Set this parameter to 2 x the number of CallPilot DS0 channels. For example, if there are 24 DS0 channels, enter 48.
	<Enter>	Press Enter until you reach the end of the overlay (REQ prompt).
REQ	****	Exits the overlay.

Defining the Message Register for AML message tracing

Introduction

This section provides instructions for updating the Message Register (MGCR) parameter. The MGCR parameter affects the AML output when message tracing is turned on for the ELAN subnet.

ATTENTION

The MGCR parameter is used by your Nortel customer support representative to troubleshoot your CallPilot and CS 1000. This parameter is not required for normal day-to-day CallPilot operation.

To define the MGCR parameter

- 1 Load overlay 17.
- 2 For each prompt listed below, enter the response indicated. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	CHG	Change
TYPE	PARM	System parameters
MGCR	0 to NCR	Maximum number of call registers used by AUX messaging. The recommended value for CallPilot is 25.
REQ	****	Exits the overlay.

Configuring CS 1000 IP addresses and enabling the Ethernet interface

Introduction

If the CS 1000 system has not been defined with the necessary IP address information (see below), configure the IP addresses for the Ethernet interface. You must also enable the Ethernet interface, as described in this section.

Notes:

- The CS 1000 system has dual CPUs.
- If the CS 1000 system is also connected to a Nortel Server Subnet (NS Subnet), you must define a gateway IP address.

ATTENTION

To change an IP address after CallPilot is installed and running, you must do the following:

- 1 Courtesy stop and shut down CallPilot.
- 2 Change the IP addresses on the switch, as described in this section.
- 3 Restart CallPilot.
- 4 Rerun the CallPilot Configuration Wizard to update the switch IP address information.

To configure the IP addresses and enable the Ethernet interface

The following data is used in examples in this procedure:

Data	Value (examples only)
Primary IP address	47.1.1.10
Primary Host Name	PRIMARY_HOST
Subnet mask	255.255.255.0
Default gateway IP address	47.1.1.1
Network IP address	0.0.0.0

- 1 Load overlay 117.
- 2 Perform the following substeps to check the current IP addresses to see if they already match what you plan to configure for CallPilot.

If the current values displayed by the following commands must be updated, then continue with the remaining steps in this procedure. Otherwise, go to step 15.

- a. Type PRT HOST and press Enter.
 - b. Type STAT HOST and press Enter.
 - c. Type PRT MASK and press Enter.
 - d. Type PRT ELNK and press Enter.
- 3 Load overlay 137.
- 4 Type DIS ELNK and press Enter.
- 5 Type STAT ELNK and press Enter.
- 6 Confirm that the system displays ELNK DISABLED.
- 7 Load overlay 117.
- 8 Create a host entry for the primary IP address by entering the following command:

NEW HOST NAME xxx.xxx.xxx.xxx (where NAME is the host name for the primary IP address, and xxx.xxx.xxx.xxx is the primary IP address)

Example: NEW HOST PRIMARY_HOST 47.1.1.10
- 9 If the CS 1000 system is connected to a Nortel Server Subnet (NS Subnet), create a host entry for the gateway IP address by entering the following command:

NEW HOST NAME xxx.xxx.xxx.xxx (where NAME is the host name for the gateway IP address, and xxx.xxx.xxx.xxx is the gateway IP address)

Example: NEW HOST GATEWAY 47.1.1.1
- 10 Assign a host to the primary IP address by entering the following command:

CHG ELNK ACTIVE NAME (where NAME is the host name for the primary IP address)

Example: CHG ELNK ACTIVE PRIMARY_HOST (entry for primary host)
- 11 Set up the Ethernet subnet mask by entering the following command:

CHG MASK xxx.xxx.xxx.xxx (where xxx.xxx.xxx.xxx is the subnet mask)

Example: CHG MASK 255.255.255.0
- 12 If using a gateway, ensure that the routing entry is set up and enabled. If the route has been set up previously (due to an existing Ethernet connected solution), go to step 13. Otherwise, set up and enable the routing entry as follows:
 - a. Set up the routing entry by entering the following command:

NEW ROUTE xxx.xxx.xxx.xxx yyy.yyy.yyy.yyy (where xxx.xxx.xxx.xxx is the network IP address and yyy.yyy.yyy.yyy is the gateway IP address; put one space between the network IP address and the gateway IP address)

Example: NEW ROUTE 0.0.0.0 47.1.1.1

- b.** Enable the route by entering the following command:
ENL ROUTE x (where x is the number assigned to the ROUTE entry)
- 13** Update the INET database by entering the following command: UPDATE DBS
- 14** Type **** and press Enter to exit the overlay.
- 15** Load overlay 137.
- 16** Type STAT ELNK and press Enter.
- 17** If the system displays ELNK ENABLED, then go to step 18. If the system displays ELNK DISABLED, then do the following substeps:
 - a.** Type ENL ELNK and press Enter.
 - b.** Type STAT ELNK and press Enter.
 - c.** Confirm that the system displays ELNK ENABLED. Then go to step 18.
- 18** Load overlay 48.
- 19** Type STAT ELAN and press Enter.
- 20** If the system displays ELAN ENABLED, then go to step 21. If the system displays ELAN DISABLED, then do the following substeps:
 - a.** Type ENL ELAN and press Enter.
 - b.** Type STAT ELAN and press Enter.
 - c.** Confirm that the system displays ELAN ENABLED. Then go to step 21.
- 21** Load overlay 117.
- 22** Verify the changes as follows:
 - a.** Type PRT HOST and press Enter.
 - b.** Type STAT HOST and press Enter.
 - c.** Type PRT MASK and press Enter.

Defining CallPilot in the customer data block

Introduction

You must define the CallPilot service in the customer data block, with the Call Park Allowed (CPA) and Message Center Included (MCI) options enabled.

During this configuration, you also define how unanswered and busy calls are routed:

- Flexible Call Forward (FNAD/FNAN/FNAL) is set on a per customer basis. Define the call forward DN in the user's phoneset data.
- Call Forward No Answer/Busy (MDID/NDID/MWFB) is set on a per customer basis. All no answer and busy calls are routed to the flexible call forward DN, provided that the called phoneset has the Message Waiting Allowed (MWA) class of service enabled.

Normally, non-Direct Inward Dialing (DID) calls are routed to CallPilot when a no answer or busy condition is encountered. As an option, you can route DID calls to the attendant's or user's Hunt DN.

To modify the customer data block

- 1 Load overlay 15.
- 2 For each prompt listed below, enter the response indicated. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	CHG	Change
TYPE	FTR	Customer features and options
CUST	xx	Customer number (0–99)
OPT	CPA MCI	Call Park Allowed and Message Center Included are enabled for the customer.
IDEF	YES or NO	Internal/External Definition Set to YES if the Call Forward by Call Type feature (CFCT) is enabled on the CS 1000 system.

- 3 Load overlay 15 again, and then for each prompt listed below, enter the response indicated:

Prompt	Response	Description
REQ	CHG	Change

Prompt	Response	Description
TYPE	ATT	TYPE Attendant consoles
CUST	xx	Customer number (0–99) AQTT 1–255 (30) Attendant Queue Timing Threshold in seconds
ATDN	(0) yyyy	Attendant DN
MATT	NO (YES)	Set to YES if Network Message Service (NMS) has not been purchased. If NMS has been purchased, set the primary CS 1000 system to YES and all secondary systems to NO.
AQTT	1–255 (30)	Attendant Queue Timing Threshold in seconds
AODN	CallPilot CDN	Attendant Overflow DN. Set this prompt to a CallPilot CDN to launch a CallPilot service when the attendant overflows. The SDN Table in CallPilot must have the desired AODN service defined for DN 0. The CS 1000 system issues an SCH1872 error, but accepts the DN. This error is a warning that the DN must be a CallPilot CDN.

- 4** Load overlay 15 again, and then for each prompt listed below, enter the response indicated:

Prompt	Response	Description
REQ	CHG	Change
TYPE	RDR	Call Redirection
CUST	xx	Customer number (0–99)
FNAD	FDN	Call forward no answer DID calls are routed to flexible CFNA DN.
FNAN	FDN	Call forward no answer non-DID calls are routed to flexible CFNA DN.

Prompt	Response	Description
AODN	CallPilot CDN	Attendant Overflow DN. Set this prompt to a CallPilot CDN to launch a CallPilot service when the attendant overflows. The SDN Table in CallPilot must have the desired AODN service defined for DN 0. The CS 1000 system issues an SCH1872 error, but accepts the DN. This error is a warning that the DN must be a CallPilot CDN.
FNAL	FDN	Call forward no answer local calls (with CFCT enabled) are routed to flexible CFNA DN.
CFNA, CFN0, CFN1, CFN2	4	The number of ring cycles before the call is forwarded. The prompts CFN0, CFN1, and CFN2 may appear instead of CFNA, depending on the release installed on the CS 1000 system. Refer to your CS 1000 system X21 documentation for details.

- 5** Load overlay 15 again, and then for each prompt listed below, enter the response indicated:

Prompt	Response	Description
REQ	CHG	Change
TYPE	FTR	
CUST	xx	Customer number (0–99)
EEST	(NO) YES	Customer features and options The originating party does not receive DTMF feedback. Set remote CS 1000 sites to NO.

- 6** Load overlay 15 again, and then for each prompt listed below, enter the response indicated:

Prompt	Response	Description
REQ	CHG	Change
TYPE	NET	Networking
CUST	xx	Customer number (0–99)
ISDN	(NO) YES	Set to YES only if NMS has been purchased. Otherwise, set to NO.

Prompt	Response	Description
PNI		NMS only. The Private Network Identifier. Within one network, use the same PNI value in overlays 15 and 16. When you interwork with different networks, enter the PNI of this CS 1000 system in overlay 15, and the PNI of the remote CS 1000 system in overlay 16.
HLOC		NMS only. Home Location Code (ESN) of the CS 1000 system. This can be in the range 100–999.
LSC		NMS only. Local Steering Code (established in the Coordinated Dialing Plan, or CDP) of the CS 1000 system. This prompt only appears for 5- or 6-digit dialing plans.
	<Enter>	Press Enter until you reach the end of the overlay (REQ prompt).
REQ	****	Exits the overlay.

Additional steps to support the Call Forward by Call Type feature

The Call Forward by Call Type (CFCT) feature is installed as part of the base X21 software.

- 1 Load overlay 16.
- 2 For each prompt listed below, enter the response indicated.
- 3 For those prompts that are not listed, you can accept the default by pressing Enter.
- 4 IDEF must be set to YES in overlay 15 to support CFCT and for the IDEF prompt to appear in overlay 16 (see “To modify the customer data block” on page 74).

Prompt	Response	Description
REQ	NEW or CHG	
TYPE	RDB	Route data block
CUST	xx	Customer number (0–99)
ROUTE		Route number
RCLS	EXT	Route class is marked as external.

Prompt	Response	Description
IDEF	LOC	Use local data to define a call as internal or external.
	<Enter>	Press Enter until you reach the end of the overlay (REQ prompt).
REQ	****	Exits the overlay.

Configuring the ACD agent queue

Introduction

You must set up only one ACD agent queue to service CallPilot, unless you are enabling the Symposium Voice Services Support feature (see “Symposium Voice Services Support additional requirements” below). This queue holds all the agents that correspond to DS0 channels on the CallPilot server.

Symposium Voice Services Support additional requirements

If you are enabling the Symposium Voice Services Support feature, you must set up two additional ACD agent queues: one for ACCESS ports, and one for IVR ports. A segment of the CallPilot ports must be dedicated to the Symposium Voice Services Support feature.

To configure an ACD agent queue

- 1 Load overlay 23.
- 2 For each prompt listed below, enter the response indicated. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	NEW	Add new data.
TYPE	ACD	Indicates this is an ACD queue.
CUST	xx	Customer number (0–99)
ACDN	yyyy	This is the ACD DN for CallPilot.
MWC	NO	Message Waiting Center
MAXP	zzzz	Maximum number of agents. MAXP must be equal to or greater than the total number of multimedia channels installed on your system.
IVR	YES	Interactive Voice Response queue
CALP	POS or TER	Called Party DN POS - Sends the POSID+DNIS in the called Party DN field in the PCI message TER - Sends the terminating DN in the called Party DN field in the PCI message

Prompt	Response	Description
ALOG	YES	Provide automatic logon for ACD agents.
	<Enter>	Press Enter until you reach the REQ prompt.
REQ	****	Exits the overlay.

Configuring ACD agents

Introduction

For CallPilot, you must define channels as ACD agents on M2008 digital sets. All agents are added to the ACD queues that you have configured.

Each agent must have the VCE and MMA class of service. To get the VCE class of service on the upper 16 units (15 to 31), you must first specify the FLXA class of service. Each agent must be provisioned with the following feature keys: ACD, SCN, NRD, MSB, TRN, and AO3.

Note: You can define a more restrictive class of service for the agents (for example, Conditionally Toll Denied [CTD]). Call restrictions in effect for the class of service take precedence over the dialing restrictions and permissions provided by CallPilot.

Terminal numbers

A Terminal number (TN) is required for each agent.

Integrated server (201i server)

For the 201i server, ACD agents use TNs associated with the slot locations of the 201i server.

Note: The left card slot used by the TNs must be used first.

Tower or rackmount servers

For the tower and rack versions of the CallPilot server, ACD agents use TNs associated with the slot location of the MGate card (NTRB18CA).

Position IDs

You also need a Position ID for each agent. The server uses the position ID to inform the CS 1000 system to which agent an incoming call should be routed.

For ease of maintenance, assign sequential numbers to the IDs that are not already in use.

To configure agents

- 1 Load overlay 11.
- 2 For each prompt listed below, enter the response indicated. For those prompts that are not listed, you can accept the default by pressing Enter.:

Prompt	Response	Description
REQ	NEW	
TYPE	2008	ARIES digital set with 8 programmable keys.
TN	c u	Terminal number of the MGate card (tower and rack server), or the 201i server, where c is the card, and u is the unit.
CUST	xx	Customer number (0–99)
CLS	WTA UNR VCE FLXA VCE MMA (units 16–31)	Voice terminal, Multimedia Agent, Flexible voice/data MMA (units 0–15) allowed.
key	0 acd xxxx 0 yyyy	where xxxx is the ACD DN of the CallPilot agent queue, and yyyy is the Position ID of the agent.
key	1 scn zzzz	where zzzz is the single-call nonringing DN used to make outbound calls.
key	2 msb	Make Set Busy
key	3 nrd	Not Ready
key	4 trn	Transfer
key	5 ao3	Three-Party Conference
AST (For IVR & Access Agents only)	0 1	If you are enabling the Symposium Voice Services Support feature, you must define 0 and 1 as the AST key 0 and key 1 values. If you are not enabling the Symposium Voice Services Support feature, then press Enter to skip this prompt.
	<Enter>	Press Enter until you reach the end of the overlay (the REQ prompt).

Prompt	Response	Description
REQ		If you are finished adding agents, enter **** to exit the overlay. To add another agent, return to the top of the table.

Enabling the card slots

Introduction

After you have configured the ACD agents, use overlay 32 to ensure that the card slots used by an MGate card (NTRB18CA) or 201i server are enabled.

Note: The 201i server occupies two slots. Both slots must be enabled to use all ports supported by the 201i server.

To enable the card slots

Note: This procedure uses the syntax STAT n and ENLC n.

- 1 Load overlay 32.
- 2 Type STAT n and press Enter, where n is the card slot used by an MGate card or 201i server.
Result: The status of the ACD agents defined for this slot appears. If the ACD agents are disabled, then enable the card slot.
- 3 Type ENLC n and press Enter, where n is the card slot used by an MGate card or 201i server.
- 4 To verify that the card slot and the ACD agents are enabled, type STAT n and press Enter, where n is the card slot used by an MGate card or 201i server.
Result: The status of the ACD agents defined for this slot appears.
- 5 Repeat this procedure for all other card slots used by an MGate card or 201i server.

Defining the default ACD DN

Introduction

Before you configure the CDN queue, define the default ACD DN that needs to be referenced in the CDN. During normal operation, the CDN is in control mode, and callers are queued to be routed and then answered by CallPilot services. Under error conditions (for example, if the AML link is down), the CDN operates in default mode and calls are routed to the default ACD DN defined for the CDN. This section describes how to set up the default ACD DN so that these calls are handled by the attendant.

For the attendant to process incoming calls to CallPilot when the CDN is in default mode, define a dummy ACD DN and set it to night call forward to the attendant.

To create a default ACD DN

- 1 Load overlay 23.
- 2 For each prompt listed below, enter the response indicated. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	NEW	
TYPE	ACD	
CUST	0	Customer number (0–99)
ACDN	xxxx	The ACD DN. Enter this DN as the DFDN in the CDN configuration.
MWC	NO	Message Waiting Center. Set to NO.
MAXP	1	This indicates that there are no agents in this queue and it is, therefore, a dummy queue.
NCFW	0	Night call forward to the attendant.
	<Enter>	Press Enter until you reach the end of the overlay (the REQ prompt).
REQ	****	Exits the overlay.

Configuring CDN queues for messaging services

Introduction

Configure the following CDN queues:

- Configure a primary CDN for Voice Messaging. This becomes the main CDN queue.
- Configure a secondary CDN for Multimedia Messaging, if you want to provide users with fax capability.

Note: Nortel strongly recommends that you use either a phantom DN or a dummy ACD DN for all other messaging services.

To configure a CDN queue

- 1 Load overlay 23.
- 2 For each prompt listed below, enter the response indicated. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	NEW	
TYPE	CDN	Control DN queue
CUST	xx	Customer number (0–99)
CDN	yyyy	The Control DN of the queue. This number must be entered as the SDN for the messaging service in the SDN Table.
DFDN	zzzz	The default ACD DN (see page 115). Calls to the CDN are directed to this ACD DN if the link or CallPilot goes down. Nortel recommends that this is not defined as the ACD DN of the CallPilot ACD queue.
VSID	<Enter>	Press Enter so that the ID is dynamically assigned to the CDN when the ELAN subnet link is established.
	<Enter>	Press Enter until you reach the end of the overlay (the REQ prompt).

Prompt	Response	Description
REQ		To configure another CDN, return to the top of the table. To exit, enter ****.

Configuring phantom DNs

Introduction

There are two reasons for configuring phantom DNs on the switch:

- to create dialable numbers for CallPilot services
- to create virtual fax DNs for users who want a separate fax number

ATTENTION

Another option is to configure dummy ACD DNs instead of phantom DNs. See “Configuring dummy ACD DNs” on page 91.

Supporting multiple languages

For Fax Item Maintenance, Voice Item Maintenance, Speech Activated Messaging, and Paced Speech Messaging, you might have purchased multiple language support.

This means that, for example, you can create an English and a Spanish version of Voice Item Maintenance if you have these languages installed. To support this, you must create a phantom DN for each supported language.

Therefore, in this case, you need two phantom DNs (one for English Voice Item Maintenance and one for Spanish Voice Item Maintenance). This also means that callers must dial a different number to access the service, based on the language they prefer.

Virtual fax DNs for users with fax capabilities

Users who have fax capabilities can have one DN that serves as both their regular extension number and their fax number. In this case, you set up a phone for the user as described in “Provisioning user phonesets” on page 92. The user’s phone must be forwarded to the Multimedia Messaging CDN.

However, some users may require two separate DNs—one DN that serves as their regular telephone number, and a second DN that serves as their fax number. For these users, you cannot simply define the virtual fax DN as another DN on the user’s phoneset. Instead, you must set up a TN as the virtual fax DN. Because physical TNs are more costly, Nortel recommends that you configure phantom DNs instead.

A separate TN is necessary because a single TN (the telephone) can be call forwarded to only one DN (regardless of how many DNs appear on that phone). For these users, you must ensure that their telephone number (the mailbox DN) forwards to the Voice Messaging CDN, whereas their fax number (the virtual fax DN) forwards to the Multimedia Messaging CDN.

Note: When you add the user to CallPilot (as a mailbox owner), you must define this virtual fax DN as one of the user's extension DNs.

To check for existing phantom loops

A phantom loop must exist before you begin to configure phantom DNs. Use overlay 22 to print the configuration record to see if any phantom loops are already configured. A phantom loop is shown with the prefix "P", illustrated in this example:

Note: You can use superloops as phantom loops.

```
.
CEQU
MPED 8D
SUPL 000 004 008 012
016 032 036 040
048 P064 P068 (phantom loops 64 and 68)
DDCS
.
.
```

If no phantom loops are configured, then continue with "To configure a phantom superloop" on page 89. If a phantom loop is configured, then go to "To configure a phantom DN" on page 90.

To configure a phantom superloop

- 1 If no phantom loops are configured, load overlay 97.
- 2 For each prompt listed below, enter the response indicated. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	CHG	
TYPE	SUPL	Superloop
SUPL	Nxxx	Prefix the loop number with N to create a phantom loop. The loop number range is 96–112 in multiples of 4 (corresponds to slots 61– 80).
	<Enter>	Press Enter until you reach the end of the overlay (the REQ prompt).
REQ	****	Exits the overlay.

To configure a phantom DN

- 1 Load overlay 10.
- 2 For each prompt listed below, enter the response indicated. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	NEW	
TYPE	500	PBX set type
TN	c u	Terminal number, where c is the card, and u is the unit. PHANTOM is echoed by the switch when the specified loop is phantom.
CDEN	xx	The card density supported by the loop, where xx can be DD - double density 4D - quadruple density
DN	yyyy	The DN must be single appearance.
CLS	WTA UNR	Unrestricted. Phantom DNs cannot originate calls, so this option is secure.
FTR	DCFW nn xxxx	DCFW = Default Call Forward nn = maximum number of digits in the DCFW DN xxxx = the CDN to which this DN forwards If this phantom DN is for a voice service, enter the Voice Messaging CDN. If this phantom DN is for a fax service, enter the Multimedia Messaging CDN. If this phantom DN is a virtual fax DN for a user, enter the Multimedia Messaging CDN.
	<Enter>	Press Enter until you reach the end of the overlay (REQ prompt).
REQ		If you are finished adding phantom DNs, enter **** to exit. To add another DN, return to the top of the table.

Configuring dummy ACD DN

Introduction

As an alternative to creating phantom DN's for directly dialable services, you can create a dummy ACD DN that is set up to call forward to the appropriate CDN depending on the multimedia channel type required.

Example

- For a service that requires only voice capability, forward the dummy ACD DN to the Voice Messaging CDN.
- For a service that requires fax capability, forward the dummy ACD DN to the Multimedia Messaging CDN.

To configure dummy ACD DN's

- 1 Load overlay 23.
- 2 For each prompt listed below, enter the response indicated. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	NEW	
TYPE	ACD	
CUST	xx	Customer number (0–99)
ACDN	xxxx	Enter the DN for the service.
MWC	YES or NO	Message Waiting Center. If the CallPilot server is a Network Message Service (NMS) satellite site, set to YES. Otherwise, set to NO.
MAXP	1	This indicates that there are no agents in this queue and it is, therefore, a dummy queue.
NCFW	yyyy	Specify the appropriate CDN depending on multimedia channel type required (Voice Messaging CDN or Multimedia Messaging CDN).
	<Enter>	Press Enter until you reach the end of the overlay (the REQ prompt).
REQ	****	Exits the overlay.

Provisioning user phonesets

Introduction

You must set up users' phonesets in a certain way to support CallPilot. The procedure depends on whether you are provisioning a digital phoneset or a 500 phoneset.

Required features

You must set up phonesets to support the following features:

- Call forward no answer to the appropriate CDN (voice or multimedia)
Note: You cannot forward users' phonesets to the Speech Activated Messaging CDN because this service does not provide call answering functionality.
- Call forward busy to the appropriate CDN
- Call forward all calls to the appropriate CDN
- Message Waiting key with the appropriate CDN as the Message Center DN

Note: If you do not plan to give fax capability to the user's mailbox, use the Voice Messaging CDN. If you plan to give fax capability to the user's mailbox, then use the Multimedia Messaging CDN.

To provision digital phonesets

- 1 Load overlay 11.
- 2 For each prompt listed below, enter the response indicated in overlay 11. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	NEW or CHG	
TYPE	2317, 2008, and so on	Type of set.
TN	c u	Terminal number of the phone, where c is the card, and u is the unit.
CUST	xx	Customer number (0–99)
FDN	yyyy	Flexible call forward no answer DN. Set this to the CDN of the Voice Messaging or Multimedia Messaging CDN queue.
HUNT	zzzz	Hunt (internal). Set this to the CDN of the Voice Messaging or Multimedia Messaging CDN queue.

Prompt	Response	Description
CLS	WTA, UNR, FNA, FBA, HTA, MWA	Call forward no answer allowed. Call forward busy allowed. Hunt allowed. Message waiting allowed.
KEY	0 SCR xxxx	Single call ringing DN, where xxxx is the user's DN.
CPND	New	Calling Party Name Display (if adding a new set).
NAME	First,Last	The name of the phoneset user.
KEY	3 MSB	Make set busy
KEY	4 TRN	Transfer
KEY	5 AO3	Three-party conference. Required by the Call Sender feature.
KEY	6 CFW nn xxxx	Call forward all calls, where nn is the maximum number of digits in the Call Forward DN, and xxxx is the Voice Messaging or Multimedia Messaging CDN.
KEY	8 MWK yyyy	Add a message waiting key/lamp, where yyyy is the Voice Messaging or Multimedia Messaging CDN.
	<Enter>	Press Enter until you reach the end of the overlay (the REQ prompt).
REQ		If you are finished adding phonesets, enter **** to exit. To add another phoneset, return to the top of the table.

To provision 500/2500 phonesets

- 1 Load overlay 10.
- 2 For each prompt listed below, enter the response indicated in overlay 10. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	NEW	
TYPE	500	500 phoneset
TN	c u	Terminal number of the phone, where c is the card, and u is the unit.
CUST	xx	Customer number (0–99)
DN	yyyy	Directory number

Prompt	Response	Description
HUNT	zzzz	Hunt (internal). Set this to the CDN of the Voice Messaging or Multimedia Messaging CDN queue.
CLS	WTA, UNR, HTA, MWA, FNA, FBA, XFA, LPA, DTN	Hunt allowed. Message waiting allowed. Call forward no answer allowed. Call forward busy allowed. MWI lamp is equipped (if not equipped, users are notified of new messages by interrupted dial tone).
FTR	FDN xxxx	Flexible call forward no answer. Set this to the Voice Messaging or Multimedia Messaging CDN.
FTR	CFW yy	Call forward all calls, where yy is the maximum DN length that users can specify as the call forward DN.
	<Enter>	Press Enter until you reach the end of the overlay (the REQ prompt).
REQ		If you are finished adding phonesets, enter ***** to exit. To add another phoneset, return to the top of the table.

Configuring the route data block for Network Message Service

Introduction

If you have purchased Network Message Service (NMS) to allow a number of switches to share CallPilot (installed on only one switch), then configure the route data block. This section provides instructions for this step.

For details on additional switch configuration for NMS, refer to the “*Configuring the switches*” chapter in the *CallPilot Network Planning Guide (555-7101-102)*.

Note: Ensure that Digit Manipulation (DMI in overlay 86) is not used to insert ESN access codes at the sending switch. ESN access code insertion must be done at the receiving switch (INAC in overlay 16).

To modify the route data block

- 1 1 Load overlay 16.
- 2 2 For each prompt listed below, enter the response indicated. For those prompts that are not listed, you can accept the default by pressing Enter.

Prompt	Response	Description
REQ	NEW or CHG	
TYPE	RDB	Route data block
CUST	xx	Customer number (0–99)
ROUTE		Route number
PNI		Customer Private Network ID of the non-local target CS 1000 system
NCRD	Yes	Network call redirection provides the CLID display information.
TRO	Yes	Optimize trunk usage on this route.
INAC	Yes	Insert an ESN access code to incoming private network calls.
	<Enter>	Press Enter until you reach the end of the overlay (REQ prompt).
REQ	****	Exits the overlay.

Saving CS 1000 changes

Introduction

Once you modify the switch configuration to support CallPilot, save all changes to disk.

To save the configuration

- 1 Load overlay 43.
- 2 At the next “.” prompt, type BKO to dump the data to disk.
Result: The system displays the data being saved. The following message appears:
RECORD COUNT=xxxx
DATADUMP COMPLETE
- 3 Return to step 2, and repeat this step two more times.
Use a new disk each time.

ATTENTION

Do not remove the disk while the LED is lit. As long as the LED is on, the disk is still being written to.

What's next?

Continue with “Configuring the CallPilot server software” on page 97.

Chapter 5

Configuring the CallPilot server software

In this chapter

Overview	98
Logging on to Windows 2003 on the CallPilot server	99
Running the Setup Wizard	100
Logging on to the CallPilot server with CallPilot Manager	101
Running the Configuration Wizard	105
Changing pcAnywhere caller passwords	108
Setting Remote Desktop Policy on a Server	110
Configuring CallPilot to operate in a Windows 2000 or 2003 domain	112

Overview

Introduction

The Configuration Wizard enables you to configure the CallPilot server software. You can rerun the Configuration Wizard to update or review the server configuration.

The Configuration Wizard is accessible from CallPilot Manager (a web-based user interface). This chapter describes how to:

- log on to the operating system on the CallPilot server
- log on to the CallPilot server with CallPilot Manager run the Configuration Wizard
- change the pcAnywhere caller passwords or set the Remote Desktop Policy
- configure CallPilot to operate in a Windows 2000 or 2003 domain



CAUTION

Risk of improper configuration

You must use the Configuration Wizard to change the computer name. If you use the operating system method to change the computer name, it is not properly updated in the CallPilot software.

Plan your responses to the Configuration Wizard

Ensure you have planned your responses to the Configuration Wizard by completing the “*Configuration Wizard worksheet*” in the *CallPilot Installation and Configuration Task List*.

Online Help for the Configuration Wizard

Each page in the Configuration Wizard contains a Help button and provides detailed instructions regarding the selection or data entry required. Click Help at any time to get additional instructions.

Running the Configuration Wizard to detect replacement boards

When you replace MPB boards or MPC-8 cards, you must rerun the Configuration Wizard to detect and initialize the hardware. You do not need to change any data in the Configuration Wizard to perform this operation, but you do need to apply the configuration changes as instructed on the last page of the Configuration Wizard.

Logging on to Windows 2003 on the CallPilot server

Introduction

If you want to access CallPilot Manager from the web browser embedded on the CallPilot server, you must first log on to Windows 2003 on the CallPilot server. Alternatively, you can access CallPilot Manager from any PC that has network access to the CallPilot server.

ATTENTION

When logging on, ensure that the CAPS key is not on. The password is case-sensitive.

ATTENTION

When the system starts up, a mini-setup process launches which consists of a number of restarts. When this process is completed, the Windows Logon screen appears

To log on to Windows 2003 on the CallPilot server

- 1 Ensure that the CallPilot server has started and the operating system logon dialog box appears.
- 2 Enter the user ID and password.

User ID	Administrator	You can choose to log on with a different user ID that has local administrative privileges.
Password (default)	Bvw250 (or current Administrator password if it has been changed)	Passwords for operating system accounts should be changed from default values to strong values known only to the customer. CallPilot security is ultimately only as good as the passwords used.

-
- 3 Click OK.
 - 4 Continue with “Running the Setup Wizard” on page 100.

Running the Setup Wizard

After you enter the user ID and password, the CallPilot Setup Wizard welcome screen appears.

Note: For more information on the Setup Wizard, please refer to the *Upgrade and Platform Migration Guide* (NTP 555-7101-207).

To run the Setup Wizard

- 1 Read the information displayed on the screen and click Next.
Result: The Need SU/PEP Installation? screen appears.
- 2 If there are Service Updates (SUs) or PEPs available, you can choose to install them now. Select Yes or No and click Next.
If you choose Yes, install SU/PEPs:
Result: The Installing SU/PEP screen appears.
 - a. Install all the required SUs and PEPs.
Note: Restart your computer (if required) after all SUs and PEPs are installed.
 - b. Click Next to continue if no restart is required. Otherwise, restart the Wizard.*If you choose No, do not install SU/PEPs now.*
Result: The Platform Validity Check screen appears.
- 3 View the items on the validity check and click Next.
- 4 When the system asks you if you have data to restore, select No.
- 5 Click Next to complete the Setup Wizard.
Result: The Finished screen appears.
- 6 Read the information displayed on the Finished screen and click Finish.
- 7 Continue with “Logging on to the CallPilot server with CallPilot Manager” on page 101.

Logging on to the CallPilot server with CallPilot Manager

Introduction

The Configuration Wizard is a menu item in CallPilot Manager. CallPilot Manager is the web-based CallPilot management tool, and can be accessed from any PC that has network access to the CallPilot server.

You can also access CallPilot Manager from the web browser on the CallPilot server. This may be the simplest method when installing CallPilot for the first time.

Logon process overview

The process for logging on to the CallPilot server with CallPilot Manager is the same for remote or local CallPilot servers. The logon process is completed in two stages:

- 1 Launch the web browser (on the CallPilot server, or on any PC that has network access to the CallPilot server), and then connect to CallPilot Manager.

For new installations, CallPilot Manager is located on the CallPilot server. The URL syntax is `http://CallPilot server host name or IP address/cpmgr/`

Example: `http://sunbird/cpmgr/`, where `sunbird` is the host name.



If you installed CallPilot Manager on a stand-alone web server (a separate PC that functions as a web server for CallPilot), the URL syntax is `http://web server host name or IP address/cpmgr/`

Note: For more details, see “Relationship of the CallPilot Manager web server to the CallPilot server” on page 101.

- 2 Log on to the CallPilot server with an administrator’s mailbox number and password.

Relationship of the CallPilot Manager web server to the CallPilot server

The CallPilot Manager web server software can be installed on the CallPilot server or on a stand-alone server. If the CallPilot Manager web server software is installed on a stand-alone server, you must know the CallPilot Manager server’s host name or IP address, as well as the CallPilot server’s host name or IP address.

Figure 20: CallPilot Manager on CallPilot server**Figure 21: CallPilot Manager on stand alone server**

To log on to the CallPilot server

- 1 Launch the web browser on your PC or on the CallPilot server.

IF you are launching the web browser on

THEN

the CallPilot server

the CallPilot Manager, Login page appears automatically. Continue with step 2.


your PC

enter the CallPilot Manager web server's URL in the Address or Location box of your web browser, and then press Enter.

Example: `http://sunbird/cpmgr/`

When the connection is established, the CallPilot Manager - Login page appears. Continue with step 2.

Figure 22: CallPilot Manager, Login



Note: The URL automatically appears as `http://<host name or IP address>/cpmgr/login.asp`. On the CallPilot server, the URL is `http://localhost/cpmgr/login.asp`.

- 2 Enter the administration mailbox number and password. The administrator mailbox number is 000000. The default password is 124578.
- 3 Do one of the following:
 - Enter a server or location by one of the following methods:

- choosing the list of pre-configured servers or locations in the Preset server list box
 - choosing the Last Server Accessed item
 - entering the address manually
 - Type the CallPilot server host name or IP address in the Server box.
- Note:** If you are logging on to the CallPilot server from a PC, type the actual CallPilot server name or IP address in the Server box. If you type local host instead of the CallPilot server name or IP address, you cannot establish an Application Builder connection to the CallPilot server from CallPilot Manager or make calls to the phoneset to play or record greetings.
- If the CallPilot server that you are connecting to has Network Message Service (NMS) installed, type the CallPilot server host name or IP address in the Server box, and then type the name of the switch location on which the administration mailbox resides in the Location box.
- 4 Click Login.

Result: The main CallPilot Manager page appears.

Figure 23: CallPilot Manager main screen



Note: Logging on for the first time forces you to change the password using numeric characters. (This is not a strong password, as described in the CallPilot Fundamentals Guide.)

- 5 Continue with “Running the Configuration Wizard” on page 105.

Running the Configuration Wizard

Introduction

This section describes how to access and run the Configuration Wizard.

Requirements

- CallPilot language CD, if you are installing, adding, or upgrading languages
- completed “*Configuration Wizard worksheet*” from the *CallPilot Installation and Configuration Task List*
- CallPilot keycode and dongle ID (serial number)

To run the Configuration Wizard

ATTENTION

For each page in the Configuration Wizard, follow the instructions on the page. Use the information you recorded in the “Configuration Wizard worksheet” in the CallPilot Installation and Configuration Task List.

If you need additional instructions, click Help. If you are rerunning the Configuration Wizard, some pages may be prefilled. Some pages also contain default values. If the prefilled information does not match the information planned for this server, then update any prefilled values as required.

- 1 Log on to CallPilot Manager. See “Logging on to the CallPilot server with CallPilot Manager” on page 101.
- 2 Click the Configuration Wizard shortcut on the main CallPilot Manager page, or select Tools -> Configuration Wizard.

Result: The Welcome page of the Configuration Wizard appears.

- 3 Click Next to go to the next page.

- 4 Read the instructions carefully on each page.

ATTENTION

The CallPilot 1005r server has three dual network interface cards. Two of the network interface cards are preconfigured with the following IP addresses:

Preconfigured IP address	Label
10.0.0.3	MIRROR
10.0.0.4	HB1
10.0.0.5	HB2
10.0.0.6	Local Area Connection 6

Ensure that the preconfigured IP addresses do not conflict with the ELAN or CLAN interface IP addresses. If there is an IP address conflict, change the preconfigured IP addresses in the Microsoft Network Connections window.

Click Help on the Configuration Wizard page if you need additional instructions. When you are finished with a page, click Next to continue.

Note: If you would like to change the CallPilot account passwords (Administrator, NGenSys, NGenDesign and NGenDist) while the CallPilot server is in a domain, follow the below steps:

- a. Log on with one of the CallPilot local accounts.
 - b. Right-click on My Computer and select Properties.
 - c. Select Computer Name.
 - d. Click Change and select Workgroup.
 - e. Enter WORKGROUP as the workgroup name.
 - f. Restart and log on with one of the CallPilot local accounts.
 - g. Run the Configuration Wizard to change the CallPilot passwords or the CallPilot server host name.
- 5 When you reach the end of the Configuration Wizard, click Finish to save the Configuration Wizard changes, or click Cancel to discard any changes. No changes are implemented unless you click Finish.

Result: The Configuration Wizard requires up to an hour to apply changes, depending on the number of languages you are installing or updating, and the size of the system. When CallPilot completes the configuration changes, you are prompted to restart the server.

6 Restart the server.

Note: Ensure you use the restart procedure documented in the *CallPilot Installation and Configuration Task List*.

Result: The server restarts and the configuration changes are in effect.

Note: If you run the Configuration Wizard after your CallPilot server is added to a domain, two procedures do not work until you remove the server from the domain. The two procedures are: changing the computer name, and changing the local administrator account and the local CallPilot NGen accounts. For more information, refer to “Configuring CallPilot to operate in a Windows 2000 or 2003 domain” on page 112.

Considerations on configuring STI links for the CallPilot tower and rackmount servers

The Configuration Wizard application is used to configure the switch telephony interface (STI) links and the DS0 channels between the MGate cards in the CS 1000 switch and the MPB16-4 or MPB96 boards in the CallPilot server. Each MPB16-4 board can have two STI links and each STI link can have a maximum of 32 DS0 channels. Each MPB96 board can have three STI links. Refer to the Configuration Wizard online Help for more information on configuring the STI links and the DS0 channels.

If your CallPilot server contains two MPB16-4 boards connected to two MGate cards and you need more than 32 DS0 channels between the CallPilot server and the switch, then you must configure both STI links on MPB16-4 #1 before starting to configure the STI links on MPB16-4 #2.

Make sure that you are always able to identify the MPB16-4 boards. Refer to “Identifying the location of MPB #1 and MPB #2” on page 53 for the numbers of the slots in which the MPB #1 and MPB #2 can be installed on CallPilot servers.

If you configure an STI link on MPB16-4 #2 before configuring both STI links on MPB16-4 #1, the DS0 channels on MPB16-4 #2 are not functional. As a result, you experience no voice in the slot that holds the MPB16-4 #2 board.

What’s next?

Your next step will depend on your choice of a remote support tool.

- If you are using pcAnywhere, continue to “Changing pcAnywhere caller passwords” on page 108.

Note: pcAnywhere is not supported on the CallPilot 201i system. Continue to “Setting Remote Desktop Policy on a Server” on page 110.

- If you are using Remote Desktop Connection, continue to “Setting Remote Desktop Policy on a Server” on page 110.

Changing pcAnywhere caller passwords

Introduction

With pcAnywhere, you can perform advanced administrative tasks on the server from a remote PC. You can control the server as though you were directly connected to the server.

pcAnywhere is installed and configured on the server at the factory. One licensed copy of pcAnywhere is provided for the server on the CallPilot Application CD-ROM.

To install pcAnywhere on another PC, you must purchase a separate license. For instructions on how to install and configure pcAnywhere on another PC, refer to the *CallPilot Administrator's Guide (555-7101-301)*.

To simplify the remote logon process, Nortel recommends that you match the pcAnywhere caller password for CallPilotDist to the Nortel user account password for NGenDist. Therefore, Nortel recommends that you change the pcAnywhere caller CallPilotDist password and the operating system NGenDist account password at the same time.

To change pcAnywhere caller passwords

- 1 Stop the pcAnywhere session, if one is running.
- 2 Click Start -> Programs -> Symantec pcAnywhere.
Result: The Symantec pcAnywhere window opens.
- 3 Click the Hosts icon in the pcAnywhere section of the Symantec pcAnywhere window.
Result: The list of hosts is displayed.
- 4 Right-click the CallPilot Support icon, and then choose Properties from the pop-up menu.
Result: The Host Properties: CallPilot Support dialog box appears.
- 5 Click the Callers tab.
- 6 Right-click the CallPilotDist icon, and then choose Properties from the pop-up menu.
- 7 In the Password box, type a new CallPilotDist password.
- 8 In the Confirm Password box, type the CallPilotDist password again.
- 9 Click Apply.
- 10 Click OK.
- 11 Click OK to return to the main Symantec pcAnywhere window.
- 12 Double-click the CallPilot icon to restart the pcAnywhere session.

What's Next?

Continue to “Configuring CallPilot to operate in a Windows 2000 or 2003 domain” on page 112.


Setting Remote Desktop Policy on a Server

CallPilot server comes with the Remote Desktop server enabled and configured for use by default. If necessary, remote desktop access can be enabled or disabled as follows:

To set remote desktop policy

- 1 From the CallPilot server desktop, right-click My Computer, then choose Properties, and click on the Remote tab.

Result: The System Properties screen appears.




- 2 Ensure the Allow users to connect remotely to this computer option is selected. Click OK to close the window.
- 3 Open the Group Policy Snap-in to choose from the five options available for remote control settings. Open a command prompt window by clicking Start > Run.

Result: The Open window appears.

- 4 Type `gpedit.msc` and click OK or press Enter.

Result: The Group Policy Object Editor window appears.



- 5 On the left side of the window, expand Computer Configuration, Administrative Templates, Windows Components, and then select Terminal Services.
- 6 On the right side of the window, double-click Sets Rules for Remote Control Terminal Services User Sessions.
- 7 The Sets Rules for Remote Control Terminal Services User Sessions window appears.
- 8 Select Enabled to load options into the box.
- 9 The default and recommended setting for CallPilot is Enabled with Full Control without User's Permission selected. This setting allows for RDC sessions without requiring interaction or consent from a local console user.
Adjust the settings as required, and click OK to close the screen.
- 10 Click File > Close to close the Group Policy Object Editor.

Note: For instructions on installing and configuring Remote Desktop Connection (RDC), refer to the *CallPilot Troubleshooting Reference Guide* (555-7101-501).

What's Next?

Continue to “Configuring CallPilot to operate in a Windows 2000 or 2003 domain” on page 112.

Configuring CallPilot to operate in a Windows 2000 or 2003 domain

Introduction

Nortel supports CallPilot as a member in a Windows 2000 or 2003 domain. Customers can add their server machine to a Windows 2000 or 2003 domain for added security and manageability. Whether you are upgrading to CallPilot 4.0 or installing a new CallPilot 4.0 system, you can move your server from a Windows workgroup to a Windows 2000 or 2003 domain.

Note: You do not need to add CallPilot to a domain. This procedure is optional. Nortel will continue to support CallPilot 4.0 in a workgroup. If you do not want to add your server to a domain, continue with Chapter 6, “Testing the CallPilot installation,” on page 123.

To add your CallPilot server to a domain, you require network administrator privileges. To perform this procedure, you can either work with your network administrator, or ask your network administrator to create a user account with network administrator privileges.

When you add your CallPilot server to a domain, Nortel recommends that you refer to the latest Distributor Technical Reference (DTR), available on the PIC web site (www.nortel.com/pic).

This section describes how to:

- set domain group policy
- add your CallPilot server to the domain
- stop and disable Win32 Time Service on the CallPilot server
- set up user accounts for remote access
- run Configuration Wizard in a domain

To set domain group policy

When you install Release 4.0 of CallPilot, the installation creates local accounts that contain default strong passwords of six characters. As a result, your local domain group policy can conflict with these default settings. The following four accounts can be affected: Administrator, NGenSys, NGenDist, and NGenDesign. Refer to “Running the Configuration Wizard” on page 105 for information on how to change these user accounts.

If you identify conflicts, you can adjust your group policies for CallPilot, or you can exclude the CallPilot server machine from a specific group policy.

When you add your CallPilot server to a domain, you must also consider that the Windows 2003 Domain Controller determines the security policy that applies to the server.

Note: Nortel strongly recommends that you add the server to a domain *after* running the Configuration Wizard.

To add CallPilot server to a domain

After you install and configure your CallPilot server, and you confirm that your network administrator has set up a Domain Controller and a DNS server on the network, you can add your server as a member of an existing domain.

To add the server as a member of an existing domain:

- 1 On the CallPilot server, courtesy stop all CallPilot channels. Refer to the *Installation and Configuration Task List Guide* (555-7101-210), for more information.
- 2 Compare the M1/Succession time to the time on the Domain Controller, or the time on any existing Domain member computer.

Note: Nortel recommends that the difference between the M1/Succession time and the Domain Controller time does not exceed 10 seconds.

Note: The CallPilot server time is updated by the M1/Succession time, so when you change the M1/Succession time, the CallPilot server time is also updated.

- a. If the difference in the M1/Succession time and the Domain Controller time is greater than 10 seconds, go to Step 3 to change the M1/Succession time to match the Domain Controller time.
- b. If the difference in the M1/Succession time and the Domain Controller time is less than 10 seconds, go to Step 4. You do not need to adjust the time.
- 3 To change M1/Succession time to match the Domain controller time, perform the following steps:
 - a. Log on to the M1/Succession server and go to LD 2.
 - b. Enter TTAD and press **Return**.

Result: The current M1/Succession format for the time and the date appear. An example is:

```
<day> <month> <year> <hour> <minute> <sec> 12 01 2005 22 35 00
```

- c. Enter STAD and press **Return**.

Result: The time and date appear. An example is:

```
<day> <month> <year> <hour> <minute> <sec> 12 01 2005 22 35 00
```

- d. Change the time to match the Domain Controller time.

Note: Nortel recommends that you keep the time difference between the M1 and the Domain Controller time to within a few seconds (+/- 10 seconds). The maximum difference can be up to five minutes before Kerberos authentication problems can arise. Once a month, check the times on the M1/Succession and the domain to


ensure that the five minute tolerance is not exceeded. If the time difference is exceeded by five minutes, you can experience problems with Event Viewer, audit logs, and local system network shares. You can also receive messages on the local server that indicate that the CallPilot server time is out of synchronization with the Domain Controller. Day-to-day operation of the CallPilot server, however, should not be affected.

Note: For normal CallPilot operation, support, and maintenance, you must create a domain user account. In order for you to receive administrator privileges on the local server, the CallPilot administrator must add the domain user account to the CallPilot local administrator group.

- 4 Exit the pcAnywhere session if it is running.
- 5 On the CallPilot server Windows desktop, right-click on **My Computer**, and then select **Properties**.

- 6 In the **System Properties** window, click the **Computer Name** tab.

Result: The following System Properties window appears.



7 Click **Change**.

Result: The Computer Name Changes window appears.



8 To add the server to an existing domain, click the **Domain** option button in the **Member of** pane, and then type the name of the domain.

9 Click **OK**.

Result: The Domain Username And Password window appears.



10 Enter the username and password from the user account on the Domain Controller that has remote access privileges.

Note: You need a domain administrator username and password.

11 Click OK.

Result: When the system processes your change successfully, the following dialog box appears, notifying you that the server now belongs to the specified domain.

**12 Click OK.****13 Click Yes** to restart your computer.

To stop and disable the Win32 Time Service


Note: If you are on a T1/SMDI switch, this procedure does not apply to a T1/SMDI system.

To prevent the Domain Controller from controlling the CallPilot server time, you must disable the Win32 time Service on the CallPilot server. This allows the M1 or Succession switch to continue to control the CallPilot server time.

To stop and disable the Win 32 Time Service

- 1 Log on to the CallPilot server.
- 2 Right-click on **My Computer** and select **Manage > Services and Applications > Services**.


Result: The Computer Management window appears:



- a. In the right pane, right-click on **Windows Time** and select **Stop**.

- b. When the Service stops, right-click on **Windows Time** and select **Properties > General tab**.

Result: The Windows Time Properties (Local Computer) window appears:



- c. Select **Disabled** from the **Startup type** menu.
- d. Click **Apply**, and then click **OK**.
- e. On the **Computer Management** window, verify that the Windows Time service is disabled.
- f. Close the **Computer Management** window.


To set up user accounts for remote access domain

In a Windows Server 2003 domain environment, you must create a dial-up user as a Domain user on the Domain Controller and assign dial-in access permissions to this user. When dialing in to the RAS configuration CallPilot Release 4.0 server, the Domain controller authenticates the username and password.

Note: Local dial-in access is no longer available for accounts Administrator, NGenSys, NGenDist, or NGenDesign through Routing and Remote Access server (RRAS). You can obtain remote dial-in access to the CallPilot system by setting up a domain account with dial-in permissions.

After you set up a domain user account and assign dial-in access permission, you have two options to log on to the local CallPilot system using dial-in access permission.

See below an example of a Domain user account with dial-in access:



Option 1: Use the local Administrator and NGen accounts for remote logon.

To perform Option 1, follow the steps below:

- 1 Ask the network administrator for a user account allowing dial-in access permission.

Note: Ask the network administrator for a username and password that is different from the username and password for your local CallPilot Administrator, NGenSys, NGenDist, and NGenDesign accounts. Record the username and password carefully as it will be required for remote support of the CallPilot server.

- 2 When you dial in to the server, you are prompted for a dial-in Domain user account and password. Enter the username and password that you received in Step 1.
- 3 Initiate a pcAnywhere or a Remote Desktop Client (RDC) session.
- 4 Enter one of the local CallPilot accounts to log on to the CallPilot server: Administrator, NGenSys, NGenDist, or NGenDesign.

Note: Since there is no local record for the Domain user account, two user accounts must be maintained: the Domain user account, and the local account.

Option 2: Use the Domain user account for remote logon

To perform Option 2, follow the steps below:

- 1 Ask the network administrator for a user account allowing dial-in access permission.

Note: Ask the network administrator for a username and password that is different from the username and password for your local CallPilot Administrator, NGenSys, NGenDist, and NGenDesign accounts. Record the username and password carefully as it will be required for remote support of the CallPilot server. The dial-in account must be added to the CallPilot local Administrator group to grant administrator privileges to support personnel.

- 2 Initiate a pcAnywhere or a RDC session.
- 3 When you dial in to the server, the system prompts you for a dial-in domain user account and password. Enter the username and password that you received in **Step 1**.

Note: This option manages the user account in one location, for both dial-in access through pcAnywhere or RDC.

To run Configuration Wizard in a domain

After you add the CallPilot server to a domain, the domain account that is used to log on to the CallPilot server does not have network administrator privileges. As a result, if you run the Configuration Wizard after you add your CallPilot server to the domain, two procedures do not work until you remove the server from the domain. The two procedures are: changing the computer name, and changing the local administrator account and the local CallPilot NGen accounts. To perform these two procedures when your server is in a domain, you must remove the server from the domain, perform the procedure, and then add the server to the domain again.

To change the computer name

To change the computer name when you run Configuration Wizard and CallPilot is a member of a domain, perform the following steps:

- 1 Ask your network administrator to remove the CallPilot server from the domain and add the server to a workgroup. You can also perform this step on your own, if you acquire network administrator privileges from your network administrator.
- 2 Shut down and restart the CallPilot system.

- 3 Run the Configuration Wizard and select the option to change the computer name.
- 4 Shutdown and restart the CallPilot system.
- 5 Ask your network administrator to add the CallPilot server to the domain. You can also perform this step on your own, if you acquire network administrator privileges from your network administrator.
- 6 Shutdown and restart the CallPilot system.

To change the local account passwords

To change the local account passwords when you run Configuration Wizard and CallPilot is a member of a domain, perform the following steps:

- 1 Ask your network administrator to remove the CallPilot server from the domain and add the server to a workgroup. You can also perform this step on your own, if you acquire network administrator privileges from your network administrator.
- 2 Shut down and restart the CallPilot system.
- 3 Run the Configuration Wizard and select the option to change the account passwords.
- 4 Shutdown and restart the CallPilot system.
- 5 Ask your network administrator to add the CallPilot server to the domain. You can also perform this step on your own, if you acquire network administrator privileges from your network administrator.
- 6 Shutdown and restart the CallPilot system.

What's next?

Continue with Chapter 6, "Testing the CallPilot installation," on page 123.

Chapter 6

Testing the CallPilot installation

In this chapter

Checking that CallPilot is ready to accept calls	124
Testing the connection to the ELAN subnet	129
Testing the connection to the NNS Subnet	130
Verifying that CallPilot can receive calls	131
Testing the CallPilot software and channels	132

Checking that CallPilot is ready to accept calls

ATTENTION

CallPilot is not ready to accept calls until the CallPilot services are fully operational. CallPilot services require approximately 10 minutes after starting up the CallPilot server to become fully operational.

Introduction

CallPilot uses various system-ready indicators to indicate when it is ready to accept calls, including:

- displaying messages in dialog boxes on the CallPilot server monitor after logon
It also displays a status icon in the top right corner of the CallPilot Manager window.
- generating events that can be viewed in the Event Browser or Alarm Monitor in CallPilot Manager
- displaying status using the hex display (applies only to the 201i server)

The system-ready indicators described in this section appear when you restart the server, and also when CallPilot is running if a change in system readiness status occurs.

The system-ready indicators appear only if the Configuration Wizard has previously been run on the server. The CallPilot server is not ready to accept calls if the Configuration Wizard has not been run.

Note: It is possible that the Configuration Wizard was run at the factory or channel partner's site before it was shipped to the customer site. If this is the case, then system-ready indicators are visible when the CallPilot server is started the for first time at the customer site.


Checking system readiness by observing the dialog box messages

A system-ready indicator dialog box appears on the screen any time there is a change in system readiness status. You can close these dialog boxes at any time. If the status changes, a dialog box appears again.

At all times, a system-ready indicator icon appears in the task bar in the bottom right corner of the screen. To view the system-ready indicator dialog box after you close it, double-click the system-ready indicator icon. To view the current status (boot, pass, warn, or fail), place the mouse pointer over the system-ready indicator icon. Help text (roll-over text), which states the current status, appears after a few seconds.

Immediately after you log on to the server, the dialog box, shown in Figure 24 on page 125, appears on the screen if CallPilot services are not yet fully operational. It can take approximately 1 minute after logon for the dialog box to appear.

Figure 24: SRI CallPilot boot fail



The Elapsed Time indicates how much time has passed since the CallPilot application began its boot sequence.

Note: This dialog box may not appear if enough time has passed between starting up the CallPilot server and logging on for CallPilot services to become fully operational. It takes approximately 10 minutes after starting up the CallPilot server for CallPilot services to become fully operational.

If the CallPilot start sequence is passed successfully (that is, CallPilot services are fully operational), the dialog box, shown in Figure 25 on page 125, appears.

Figure 25: SRI CallPilot boot pass




Click OK to close the dialog box.

If there are errors, one of the following two dialog boxes appears (depending on the severity of the problem).

Figure 26: SRI CallPilot warning

Close the dialog box by clicking the X in the upper right corner. Check the Event Browser or Alarm Monitor in CallPilot Manager for more details. For instructions, refer to the CallPilot Manager online Help.

Figure 27: SRI CallPilot error message

Close the dialog box by clicking the X in the upper right corner. Check the Event Browser or Alarm Monitor in CallPilot Manager for more details. For instructions, refer to the CallPilot Manager online Help.

Alternative methods for verifying that CallPilot is ready to accept calls

View events in CallPilot Manager or in the operating system Event Viewer on the server

The Pass, Warning, and Error system-ready indicator messages appear as events in the Event Browser and Alarm Monitor in CallPilot Manager, and in the operating system Event Viewer on the server.

By default

- the Event Browser and Alarm Monitor show only the latest 100 events
Change the default settings to remove the system-ready indicator events from the Event Browser and Alarm Monitor windows.
- the Event Browser lists only Critical events
You can change the Filter Criteria so that Major, Minor, and Information events are listed as well.

For detailed instructions on viewing events, refer to the CallPilot Manager online Help.

Observe the HEX display (for the 201i server only)

The HEX display on the 201i server faceplate displays the following messages.

Note: The DOWN, OK, MIN, MAJ, CRI, and “???” messages can appear regardless of whether the Configuration Wizard has been run. Some MIN, MAJ, and CRI events may appear because the server has not been configured. These events may be resolved after running the Configuration Wizard. The BOOT, PASS, WARN, and FAIL messages are system-ready indicator messages; they do not appear if the Configuration Wizard has not been run.

IPE CallPilot server

HEX display	Description
DOWN	The operating system is starting.
OK	The operating system start sequence has passed.
BOOT	CallPilot is starting and is not yet fully operational. Please wait.
PASS	CallPilot is fully operational and ready to accept calls.
WARN	CallPilot is ready to accept calls; however, some services failed the start sequence. Check the event log for further information.
FAIL	CallPilot failed the start sequence and cannot accept calls. Check the event log for further information.
MIN	A minor alarm has occurred. Check the event log for further information.
MAJ	A major alarm has occurred. Check the event log for further information.
CRI	A critical alarm has occurred. Check the event log for further information.

IPE CallPilot server HEX display	Description
???	An alarm of unknown severity has occurred. This error should not occur on a properly installed system. The severity of this event is treated as higher-than-critical.

Testing the connection to the ELAN subnet

Introduction

This procedure tests the network connection between the server and the CS 1000 system over the ELAN subnet.

ATTENTION

Disconnect the Nortel Server Subnet (NS Subnet) from the ELAN subnet before testing to ensure that the ping is testing only the ELAN subnet.

To test the connection to the ELAN subnet

- 1 Click Start -> Programs -> Accessories -> Command Prompt.

Result: The Command Prompt window appears.

- 2 Type ping followed by the ELAN subnet IP address for the CS 1000 system, and then press Enter.

Note: This is the ELAN subnet IP address specified for the CS 1000 system in. Refer to the Configuration Wizard worksheets that you completed in the CallPilot Installation and Configuration Task List for the IP address.

Example: ping 255.255.255.255

Result: The display should indicate a successful ping. If the ping is not successful, check the connection from the CallPilot server's ELAN subnet card to the CS 1000 system.

- 3 If the CallPilot server is also connected to a Nortel Server Subnet (NS Subnet), then continue with "Testing the connection to the NNS Subnet" on page 160.

If the CallPilot server is not connected to a Nortel Server Subnet (NS Subnet), then type exit and press Enter to close the Command Prompt window. Then continue with "Verifying that CallPilot can receive calls" on page 131.

Testing the connection to the NNS Subnet

Introduction

This procedure tests the network connection between the server and the Nortel Server Subnet (NS Subnet). This applies only if CallPilot has an NNS Subnet card and is connected to an NNS Subnet.

ATTENTION

Disconnect the NNS Subnet from the ELAN subnet before testing to ensure that the ping is testing only the NNS Subnet.

To test the connection to the NNS Subnet

- 1 Click Start -> Programs -> Accessories -> Command Prompt.
Result: The Command Prompt window appears.
- 2 Type ping followed by the NNS Subnet IP address of another PC on the NNS Subnet, and then press Enter.
Example: ping 255.255.255.255
Result: The display indicates a successful ping.
- 3 Type exit, and then press Enter to close the Command Prompt window.

Verifying that CallPilot can receive calls

Introduction

The following procedure is a basic test to verify that CallPilot is able to receive calls from the CS 1000 system and answer those calls. A more thorough test that requires the use of CallPilot Manager is described in “Testing the CallPilot software and channels” on page 132.

To verify that CallPilot can receive calls

- 1 Ensure that CallPilot services are fully operational before you begin.
For instructions, see “Checking that CallPilot is ready to accept calls” on page 124.
- 2 Dial the main Voice Messaging DN that you defined in the Configuration Wizard.
- 3 Listen for a response from CallPilot (for example, “CallPilot from Nortel ...”), and then hang up.

If you do not get a response, then do the following:

- a. Check the cabling between the server and the CS 1000 system.
- b. Verify that the CS 1000 system is processing calls to other extensions.
- c. Refer to the *CallPilot Server Maintenance and Diagnostics guide* for your server.

What's next?

Continue with “Testing the CallPilot software and channels” on page 132.

Testing the CallPilot software and channels

Introduction

This section provides a series of tests of the CallPilot installation, including verifying that

- you can leave a message
- you can retrieve a message
- each call channel and multimedia (DSP) channel is functioning properly

Before you begin

- Ensure that you have configured the CS 1000 system and CallPilot server, as described in this guide.
- Obtain the ACD DN for CallPilot.
- Identify a phoneset DN that exists on the CS 1000 system that you can use for testing.
- Have a pencil and paper ready to record the results of the tests.

To verify that you can leave a message

Complete the following procedures to perform this test:

- 1 “To add a user for testing purposes” on page 132
- 2 “To configure the Voice Messaging DN” on page 133
- 3 “To leave a message” on page 134

To add a user for testing purposes

- 1 Log on to the operating system on the CallPilot server.

For instructions, see “Logging on to Windows 2003 on the CallPilot server” on page 99.

Note: Although you can access CallPilot Manager from any PC that has network access to the CallPilot server, later tests require that you be logged on to the CallPilot server.

- 2 Log on to CallPilot Manager.

For instructions, see “Logging on to the CallPilot server with CallPilot Manager” on page 101.

- 3 Click Users. Add User.

Result: The Express Add page appears.

- 4 Type the required information.

Each required field is marked with an asterisk (*). Accept the default values for other fields.

For example, create a user named TEST USER.

ATTENTION

The tests in this section use the mailbox number 8050 as an example. Ensure that you specify a DN that is defined on the CS 1000 system.

- 5 Click Advanced User Add.
Result: The Advanced User Add page appears, and the information you have already entered appears.
- 6 Scroll down to the Security section of the page and specify a mailbox password. Record the password. Leave all other fields at their default values.
- 7 Click Express Add.
Result: The Express Add page appears.
- 8 Click Add.
Result: CallPilot Manager displays a summary of the user just added.

To configure the Voice Messaging DN

Note: Note: If you have already configured a Voice Messaging CDN in the Configuration Wizard, then you can skip this procedure. If you are not sure, continue with this procedure to verify that a Voice Messaging CDN is present, or to configure one if necessary.

- 1 Click System. Service Directory Number.
Result: The Service Directory Number page appears.
- 2 Click New.
Result: The SDN Detail page appears.
- 3 In the Service DN box, type the primary Voice Messaging DN for CallPilot.
Note: If there are no voice channels installed on CallPilot, then use the Fax or Speech Recognition primary DN as the Voice Messaging DN for these tests. You can still use the Voice Messaging application as described in this procedure.
- 4 In the Application Name box, select Voice Messaging.
- 5 In the Media Type box, select Voice.
Note: If there are no voice channels installed on CallPilot, then select Fax or Speech Recognition based on the DN that you specified in step 3.
- 6 Click Save.

To leave a message

- 1 From any active phoneset that is connected to the CS 1000 system, dial the Voice Messaging Service DN that you have just created.
Result: CallPilot plays the following prompt: `CallPilot from Nortel Network. Mailbox?`
Note: If CallPilot does not answer the call or you do not hear a prompt, then check that the call channels and multimedia channels are in Idle state, as described in “Verifying that each call channel and multimedia channel is functioning properly” on page 135.
- 2 Enter the mailbox number followed by number sign (#) (for example, 8050#).
Result: CallPilot plays the following prompt: `Password?`
- 3 Enter the mailbox password 135246#.
Result: CallPilot plays the following prompt: `The temporary password assigned by your administrator must be changed. To access your mailbox, please press 84 and change your password.`
- 4 Press 84.
Result: CallPilot plays the following prompt: `Password change. To authorize the change, please enter your old password followed by number sign.`
- 5 Enter 135246#.
Result: CallPilot plays the following prompt: `Please enter your new password followed by number sign.`
- 6 Enter a new mailbox password followed by number sign (#) (for example, 805011#).
Result: CallPilot plays the following prompt: `Please enter your new password again followed by number sign.`
- 7 Enter the new mailbox password again to confirm (for example, 805011#).
Result: CallPilot plays the following prompt: `Your password has been changed. Your mailbox is empty.`
- 8 Press 75 to compose a message.
Result: CallPilot plays the following prompt: `Compose ...`
- 9 Enter the mailbox number, followed by number sign (#) twice (for example, 8050##).
Result: CallPilot plays the following prompt: `To begin recording, Press 5. To end recording, press number sign.`
- 10 Press 5 to record a message.
- 11 Record a message, and then press number sign (#) to stop.

Result: CallPilot plays the following prompt: `Recording Stopped. There is a brief pause, followed by the prompt: To review the message, press 2, to send it, press 79...`

- 12 Press 79 to send the message.

Result: CallPilot plays the following prompt: `Message sent and deleted.`

- 13 Press 83, and then hang up the phone.

- 14 Verify that the Message Waiting Indicator (MWI) is on.

To verify that you can retrieve a message

- 1 Pick up the telephone handset and dial the same Voice Messaging Service DN again.

- 2 When prompted, enter the mailbox number where the message was left (for example, 8050#).

Result: CallPilot plays the following prompt: `Password?`

- 3 Enter the mailbox password (for example, 805011#).

Result: CallPilot plays the following prompt: `You have one new message. Message one. New. From ...`

ATTENTION

If you do not hear the exact message, `You have one new message...`, this indicates that the wrong prompts have been installed or that CallPilot did not install properly.

If you did not hear the correct message, contact your Nortel customer support representative.

- 4 Press 2 to play the message, and then listen to it.

- 5 Press 76 to delete the message.

Result: CallPilot plays the following prompt: `Message 1 deleted.`

ATTENTION

If you do not hear the exact message, `Message 1 deleted`, this indicates that the wrong prompts have been installed or that CallPilot did not install properly.

If you do not hear the correct message, contact your Nortel customer support representative.

- 6 Press 83 and then hang up the phone.

Verifying that each call channel and multimedia channel is functioning properly

These tests verify that the call channels and multimedia (DSP) channels are functioning properly.

The call channel is the channel that carries the call signal from the CS 1000 system to CallPilot. The multimedia channel is the CallPilot channel that processes the call and provides voice, fax, or speech recognition capability.

These tests consist of the following procedures:

- “To test call channels and voice channels” on page 136 (Skip this procedure if you do not have voice channels installed.)
- “To test call channels and fax channels” on page 137 (Skip this procedure if you do not have fax channels installed.)
- “To test call channels and speech recognition channels” on page 139 (Skip this procedure if you do not have speech recognition channels installed.)
- “To restore the SDN Table and put all channels back in service” on page 140

Note: These tests require that you access the Channel Monitor, Multimedia Monitor, and Service Directory Number pages in CallPilot Manager. If you need additional instructions for these CallPilot Manager pages, refer to the CallPilot Manager online Help, or to the *CallPilot Administrator's Guide (555-7101-301)*. You must also access the System Monitor utility. The System Monitor utility is described in the chapter “Using CallPilot system utilities” in the *CallPilot Server Maintenance and Diagnostics guide* for your server.

To test call channels and voice channels

Note: If CallPilot has no voice channels, go to “To test call channels and fax channels” on page 137. If CallPilot also has no fax channels, go to “To test call channels and speech recognition channels” on page 139.

- 1 In CallPilot Manager, click System -> Service Directory Number.

Result: The Service Directory Number page appears.

- 2 Ensure that the Voice Messaging Service DN is set to the ACD DN.

Note: If the Voice Messaging Service DN is not set to the ACD DN, then select the defined Service DN and click File / Properties. Make the required changes, and then click Save.

- 3 In the Application Name box, ensure that Voice Messaging is selected.

- 4 In the Media Type box, ensure that Voice is selected.

- 5 Click Maintenance / Multimedia Monitor.

Result: The Multimedia Monitor appears.

- 6 Select and start a maximum of eight voice channels for testing.

Note: Nortel recommends that you test a maximum of eight voice channels at one time. For example, if you have a 96-channel system, start only eight voice channels. When those eight voice channels are tested, stop them and start another set of voice channels.

- 7 Stop all fax and speech recognition channels, if these channels are present.

- 8 Verify that all voice channels are in Idle state.

- 9 In CallPilot Manager, click Maintenance / Channel Monitor.
Result: The Channel Monitor appears.
- 10 Select the whole system and stop all channels.
- 11 Select and start the same number of call channels as voice channels that you started.
Example: If you have started eight voice channels, then start eight call channels.
- 12 On the CallPilot server desktop, click Start -> Programs -> CallPilot -> System Utilities -> System Monitor.
Result: Result: The CallPilot System Monitor window appears. By default, the Channel Monitor tab appears on top.
- 13 Observe the System Monitor window and verify that all the required multimedia (DSP) and call channels are in Idle state, and that all other channels are Off Duty (out of service).
- 14 Use a telephone to dial the service DN that you entered in the SDN table for Voice Messaging.
- 15 Verify that CallPilot answers the call and that the CallPilot greeting plays.
- 16 Observe the System Monitor and record which call channel and which voice channel change to Active states.
- 17 Hang up the telephone.
- 18 Repeat steps 14 to 17 until all the selected voice and call channels are tested.
Note: If the calls are not cycling through all voice and call channels, then stop the tested voice and call channels. This forces the next call to go to the untested voice and call channels. When you stop the channels, there may be a short delay before the channels go to Off Duty state. This is because stopped channels go into a 1-minute standby mode so they are ready for the next call.
- 19 Stop the voice and call channels that were tested.
- 20 Repeat steps 5 to 19 until all voice channels and the same number of call channels are tested.

To test call channels and fax channels

Note: If CallPilot has no fax channels, go to “To test call channels and speech recognition channels” on page 139.

- 1 In CallPilot Manager, click System -> Service Directory Number.
Result: The Service Directory Number page appears.
- 2 In the Service Directory Number page, click the Voice Messaging Service DN that you have been using for testing.

Result: Result: The SDN Detail page appears showing the properties of the Voice Messaging Service DN.

- 3 In the Media Type box, select Fax.

Note: You can leave the Application Name as Voice Messaging.

- 4 Click Save.
- 5 Click Maintenance -> Multimedia Monitor.

Result: The Multimedia Monitor appears.

- 6 In the Multimedia Monitor page, select and start a maximum of eight fax channels for testing.

Note: Nortel recommends that you test a maximum of eight fax channels at one time. For example, if you have a 96-channel system, start only eight fax channels. When those eight fax channels are tested, stop them and start another set of fax channels.

- 7 Stop all voice and speech recognition channels, if these channels are present.
- 8 Verify that all fax channels are in Idle state, and leave the Multimedia Monitor page open so that you can observe when channels change to Active state.
- 9 In CallPilot Manager, click Maintenance -> Channel Monitor.

Result: The Channel Monitor appears.

- 10 Select the whole system and stop all channels.
- 11 Select and start the same number of call channels as fax channels that you started.

Example: If you have started 8 fax channels, then start eight call channels.

Note: Ensure that you select and start call channels that have not already been tested (for example, as part of the voice channel test).

- 12 On the CallPilot server desktop, click Start -> Programs -> CallPilot -> System Utilities -> System Monitor.

Result: The CallPilot System Monitor window appears. By default, the Channel Monitor tab appears on top.

- 13 Observe the System Monitor window and verify that all the required multimedia (DSP) and call channels are in Idle state, and that all other channels are Off Duty (out of service).
- 14 Use a telephone to dial the service DN that you entered in the SDN table.
- 15 Verify that CallPilot answers the call and that the CallPilot greeting plays.
- 16 Observe the System Monitor and record which call channel and which fax channel change to Active states.
- 17 Hang up the phone.
- 18 Repeat steps 14 to 17 until all the selected fax and call channels are tested.

Note: If the calls are not cycling through all fax and call channels, then stop the tested fax and call channels. This forces the next call to go to the untested fax and call channels. When you stop the channels, there may be a short delay

before the channels go to Off Duty state. This is because stopped channels go into a 1-minute standby mode so they are ready for the next call.

- 19 Stop the fax and call channels that were tested.
- 20 Repeat steps 5 to 19 until all fax channels and the same number of call channels are tested.

To test call channels and speech recognition channels

- 1 In CallPilot Manager, click System -> Service Directory Number.
Result: Result: The Service Directory Number page appears.
- 2 In the Service Directory Number page, click the Voice Messaging Service DN that you have been using for testing.
Result: The SDN Detail page appears showing the properties of the Voice Messaging Service DN.
- 3 In the Media Type box, select Speech Recognition.
Note: You can leave the Application Name as Voice Messaging.
- 4 Click Save.
- 5 Click Maintenance -> Multimedia Monitor.
Result: The Multimedia Monitor appears.
- 6 In the Multimedia Monitor page, select and start a maximum of eight speech recognition channels for testing.
Note: Nortel recommends that you test a maximum of eight speech recognition channels at one time. For example, if you have a 96-channel system, start only eight speech recognition channels. When those eight channels are tested, stop them and start another set of speech recognition channels.
- 7 Stop all fax and voice channels, if these channels are present.
- 8 Verify that all speech recognition channels are in Idle state, and leave the Multimedia Monitor page open so that you can observe when channels change to Active state.
- 9 In CallPilot Manager, click Maintenance -> Channel Monitor.
Result: The Channel Monitor appears.
- 10 Select the whole system and stop all channels.
- 11 Select and start the same number of call channels as speech recognition channels that you have started.
Example: If you started eight speech recognition channels, then start eight call channels.
Note: Ensure you select and start call channels that have not already been tested (for example, as part of the voice or fax channel test).
- 12 On the CallPilot server desktop, click Start -> Programs -> CallPilot -> System Utilities -> System Monitor.

Result: The CallPilot System Monitor window appears. By default, the Channel Monitor tab appears on top.

- 13 Observe the System Monitor window and verify that all the required multimedia (DSP) and call channels are in Idle state, and that all other channels are Off Duty (out of service).
- 14 Use a telephone to dial the service DN that you entered in the SDN table.
- 15 Verify that CallPilot answers the call and that the CallPilot greeting plays.
- 16 Observe the System Monitor and record which call channel (on the Channel Monitor page) and which speech recognition channel (on the Multimedia Monitor page) change to Active states.
- 17 Hang up the phone.
- 18 Repeat steps 14 to 17 until all the selected speech recognition and call channels are tested.

Note: If the calls are not cycling through all speech recognition and call channels, then stop the tested speech recognition and call channels. This forces the next call to go to the untested speech recognition and call channels. When you stop the channels, there may be a short delay before the channels go to Off Duty state. This is because stopped channels go into a 1-minute standby mode so they are ready for the next call.

- 19 Stop the speech recognition and call channels that were tested.
- 20 Repeat steps 5 to 19 until all speech recognition channels and the same number of call channels are tested.

To restore the SDN Table and put all channels back in service

- 1 In CallPilot Manager, click System -> Service Directory Number.

Result: The Service Directory Number page appears.

- 2 In the Service Directory Number page, select the check box for the Voice Messaging Service DN that you have been using for testing.
- 3 Click Delete Selected.

Result: The Service DN is deleted.

Note: If you are ready to begin CallPilot administration, you can choose to keep this Service DN. However, ensure that the Service DN is configured as required for normal operation. For example, do not leave the Service DN set to the ACD DN.

- 4 In CallPilot Manager, click Maintenance / Channel Monitor.

Result: The Channel Monitor appears.

- 5 In the Channel Monitor page, select the whole system and start all channels.
- 6 Verify that all call channels are in Idle state.
- 7 Click Maintenance / Multimedia Monitor.

Result: The Multimedia Monitor appears.

- 8 In the Multimedia Monitor page, select the whole system and start all channels.
- 9 Verify that all multimedia channels are in Idle state.

Result: The CallPilot tests are completed.

What's next

Once your testing indicates that the server upgrade, new installation, configuration, platform migration, or system rebuild is successful, perform a full system backup. Refer to “*Backing up and restoring CallPilot information,*” in the *CallPilot Administrator's Guide (555-7101-301)* for more information.

Communication Server 1000 Meridian and Call-Pilot Server Configuration

CallPilot
4.0

Document Number: 555-7101-510

Document Version: Standard 1.16

January 2007

All Rights Reserved.

To provide feedback or report a problem in this document, go to

www.nortel.com/documentfeedback.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

*Nortel Networks, the Nortel Networks logo, and the Globemark are trademarks of Nortel Networks.

*Microsoft, MS, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

All other trademarks and registered trademarks are the property of their respective owners.

