



# **Avaya CallPilot® 1002rp Server Hardware Installation**

5.0  
NN44200-300, 01.04  
December 2010

## Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

## Documentation disclaimer

"Documentation" means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya generally makes available to users of its products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

## Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

## Warranty

Avaya provides a limited warranty on its Hardware and Software ("Product(s)"). Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this Product while under warranty is available to Avaya customers and other parties through the Avaya Support Web site: <http://support.avaya.com>. Please note that if you acquired the Product(s) from an authorized Avaya reseller outside of the United States and Canada, the warranty is provided to you by said Avaya reseller and not by Avaya.

## Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO/](http://support.avaya.com/licenseinfo/) ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

## Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, or Hardware provided by Avaya. All content on this site, the documentation and the Product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

## Third-party components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: <http://support.avaya.com/Copyright>.

## Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation and Product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation and Product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners, and "Linux" is a registered trademark of Linus Torvalds.

## Downloading Documentation

For the most current versions of Documentation, see the Avaya Support Web site: <http://support.avaya.com>.

## Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your Product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: <http://support.avaya.com>.

## Japan Denan statement

The following applies to server models 1006r, 1005r, 703t, and 1002rp:

---

 **Warning**

---

Please be aware of the following while installing the equipment:

- Please use the connecting cables, power cord, and AC adaptors shipped with the equipment or specified by Avaya to be used with the equipment. If you use any other equipment, it may cause failures, malfunctioning or fire.
  - Power cords shipped with this equipment must not be used with any other equipment. If the above guidelines are not followed, it may lead to death or severe injury.
- 

 **警告**

---

本製品を安全にご使用頂くため、以下のことにご注意ください。

- 接続ケーブル、電源コード、ACアダプタなどの部品は、必ず製品に同梱されております添付品または指定品をご使用ください。添付品・指定品以外の部品をご使用になると故障や動作不良、火災の原因となることがあります。
- 同梱されております付属の電源コードを他の機器には使用しないでください。上記注意事項を守らないと、死亡や大怪我など人身事故の原因となることがあります。

#### Japan VCCI statement

The following applies to server models 1006r, 1005r, 703t, 201i, and 1002rp:

この装置は、情報処理装置等電波障害自主規制協議会 (VCCI) の規定に基づくクラスA装置です。この装置を家庭環境で使用すると電波障害を引き起こすことがあります。この場合には使用者が適切な対策を取るようにより要求されることがあります。

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may occur, in which case, the user may be required to take corrective action.



# Contents

<b>Chapter 1: Customer service</b> .....	<b>9</b>
Getting technical documentation.....	9
Getting product training.....	9
Getting help from a distributor or reseller.....	9
Getting technical support from the Avaya Web site.....	10
<b>Chapter 2: 1002rp server description</b> .....	<b>11</b>
In this chapter.....	11
Server features.....	11
Introduction.....	11
Server dimensions and weight.....	11
Environmental specifications.....	12
Front panel features (front view without the front bezel).....	12
Alarm board.....	13
Rear panel diagram.....	13
Overhead view of empty server showing PCI and ISA connectors.....	14
Slot assignments.....	15
Introduction.....	15
Slot definition and slot numbering.....	16
Network connectivity.....	17
Introduction.....	17
Reference Documents.....	18
Sample network setup: Meridian 1.....	20
Sample network setup: Communication Server 1000.....	21
Switch connectivity.....	22
CallPilot ELAN subnet and Avaya server subnet setup.....	22
Meridian 1 or Communication Server 1000 systems.....	22
Network requirements.....	22
Remote access connectivity.....	23
Supported peripheral devices.....	23
Introduction.....	23
<b>Chapter 3: Preparing for installation</b> .....	<b>25</b>
In this chapter.....	25
Installation overview.....	25
Introduction.....	25
Installation checklist.....	25
Conventions for warnings.....	27
Unpacking the 1002rp server.....	28
Introduction.....	28
What is next?.....	28
Removing the front bezel and server cover.....	29
Introduction.....	29
What is next?.....	31
Inspecting the server interior.....	31
Introduction.....	31
<b>Chapter 4: Power supply installation</b> .....	<b>33</b>
In this chapter.....	33

Safety precautions.....	33
Equipment handling guidelines.....	33
Safety information.....	33
Installing the second power supply module (AC or DC).....	34
Introduction.....	34
AC versus DC systems.....	34
About the power supply module.....	34
To install the power supply module.....	35
What is next?.....	36
DC wire gauge tables.....	36
Introduction.....	36
Cabinet and module DC feed recommended wire gauge specifications.....	36
Metric wire conversion.....	37
DC rack cabling.....	37
Rack power and grounding.....	39
-48 V DC power distribution rationale.....	39
About the power distribution unit.....	40
Introduction.....	40
PDU power and grounding.....	40
Multiple PDUs.....	40
PDU terminal blocks and wiring diagram.....	41
DC power input.....	41
Bringing power and ground into the PDU.....	42
Introduction.....	42

**Chapter 5: Installing the server and connecting the peripheral devices.....43**

In this chapter.....	43
Installing the server.....	43
Introduction.....	43
To install the server.....	44
Preparing the modem.....	44
Introduction.....	44
Required equipment.....	44
Modem DIP switches.....	45
To set the modem DIP switches.....	45
What is next?.....	47
Connecting peripherals to the server.....	48
Rear panel connectors.....	48
What is next?.....	50
Connecting the server to the ELAN subnet.....	50
Introduction.....	50
Media Access Control address.....	50
What is next?.....	51
Connecting the server to the Avaya server subnet (optional).....	52
Introduction.....	52
Media Access Control address.....	52
What is next?.....	53
Installing the Avaya software feature dongle.....	53
Introduction.....	53
Requirements.....	54
What is next?.....	55

Connecting the server to power.....	55
Before you begin.....	55
<b>Chapter 6: EMC emission level protection for the 1002rp Server.....</b>	<b>59</b>
<b>Index.....</b>	<b>61</b>



# Chapter 1: Customer service

Visit the Avaya Web site to access the complete range of services and support that Avaya provides. Go to [www.avaya.com](http://www.avaya.com) or go to one of the pages listed in the following sections.

## Navigation

- [Getting technical documentation](#) on page 9
- [Getting product training](#) on page 9
- [Getting help from a distributor or reseller](#) on page 9
- [Getting technical support from the Avaya Web site](#) on page 10

---

## Getting technical documentation

To download and print selected technical publications and release notes directly from the Internet, go to [www.avaya.com/support](http://www.avaya.com/support).

---

## Getting product training

Ongoing product training is available. For more information or to register, you can access the Web site at [www.avaya.com/support](http://www.avaya.com/support). From this Web site, you can locate the Training contacts link on the left-hand navigation pane.

---

## Getting help from a distributor or reseller

If you purchased a service contract for your Avaya product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

---

## Getting technical support from the Avaya Web site

The easiest and most effective way to get technical support for Avaya products is from the Avaya Technical Support Web site at [www.avaya.com/support](http://www.avaya.com/support).

# Chapter 2: 1002rp server description

---

## In this chapter

[Server features](#) on page 11

[Slot assignments](#) on page 15

[Network connectivity](#) on page 17

[Network connectivity](#) on page 17

[Supported peripheral devices](#) on page 23

[Reference Documents](#) on page 18

---

## Server features

---

### Introduction

This section provides a general overview of the 1002rp server.

---

### Server dimensions and weight

Height	320 mm (12.5 in.)
Width	483 mm (19 in.)
Depth (distance from front to back)	
• without front bezel	495 mm (19.5 in.) 533 mm (21 in.)
• with front bezel	

---

Weight of fully loaded system	45.5 kg (100 lb)
-------------------------------	------------------


---

## Environmental specifications

Environmental condition	Specification
Operating temperature	10°C to 35°C (50°F to 95°F) Maximum rate of change must not exceed 10°C (50°F) per hour.
Non-operating (storage) temperature	-40°C to 70°C (-40°F to 158°F)
Non-operating humidity	95%, non-condensing at 30°C (86°F)
Altitude	1829 m (6000 ft)
Electrostatic discharge	15 kV or more
Acoustic noise	50 dBA in a typical office ambient temperature (18°C to 25°C [64.4°F to 77°F])
Operating shock	No errors with a half sine wave shock of 2G (with 1 millisecond duration)
Handling drop	Operational after a free fall from 450 mm to 600 mm (18 in. to 24 in.) (depending on weight)

## Front panel features (front view without the front bezel)

The front view of the 1002rp server chassis shows redundant dual fans to the left and the right of the status panel. The left drive bay holds six SCSI hard drives with hot-pluggable carriers. The media drive bay, located to the right, houses the CD-ROM, tape drive, and floppy disk drive.




---


## Alarm board

The alarm board is located under the baseboard. It connects to the status display panel on the front.

---

## Rear panel diagram


The following diagram shows the slot locations in the rear panel, and the power switch and power input for an AC server. The rest of the diagram is the same for AC or DC servers.



G101648

## Overhead view of empty server showing PCI and ISA connectors

The following diagram shows the location of the PCI, SBC, and ISA connectors inside the server. The view in the diagram is from the rear of the server. For slot assignments, see [Slot assignments](#) on page 15. You must be able to identify slot locations for later steps in the Avaya CallPilot® installation.




---

## Slot assignments

---

### Introduction

The slot assignment tables show the following:

- the physical location of boards inside the server, relative to other boards
- the order in which boards are installed (for example, board #1, 2, 3)
- how the boards are represented in some CallPilot Manager applications (such as the Maintenance Administration page)
- the maximum capacity for each switch connectivity

**\* Note:**

Your server can vary depending on what was ordered from Avaya. Therefore, your server may not have all of the slots populated.

## Slot definition and slot numbering

In these tables, the term slot refers to the available slot openings in the chassis, not the PCI or ISA connectors inside the server.

Look at the server from the rear (see [Rear panel diagram](#) on page 13). The slots are numbered from right to left, 1 to 20. Now, look at the server from the front. The slots are numbered from left to right.

 **Note:**

For Meridian 1 and Communication Server 1000, the first MPB16-4 board must be installed in slot 11. You can install up to a maximum of two MPB16-4 boards.

**Table 1: 1002rp slot assignments**

Slot number	Avaya CallPilot- assigned board label <sup>a</sup>	Meridian 1*/ Communication Server* 1000	T1/SMDI
Slot 1	BRD01	Not used	Not used
Slot 2	BRD02	Not used	Not used
Slot 3	BRD03	Not used	Not used
Slot 4	BRD04	Not used	Not used
Slot 5	BRD05	Not used	Not used
Slot 6	BRD06	Not used	Not used
Slot 7	BRD07	Reserved for COM2 I/O bracket	Reserved for COM2 I/O bracket
Slot 8 <sup>b</sup>	BRD08	Single board computer	Single board computer
Slot 9 (PCI Slot 1)	BRD09	Reserved for COM1 and parallel port I/O bracket	Reserved for COM1 and parallel port I/O bracket
Slot 10 (PCI Slot 2)	BRD10	PCI RAID controller	PCI RAID controller
Slot 11 (PCI Slot 3)	BRD11	MPB16-4 #1 or MPB96 #1	MPB96 board #1
Slot 12 (PCI Slot 4)	BRD12	MPB16-4 #2 (optional)	D/480JCT-2T1
Slot 13 (PCI Slot 5)	BRD13	MPB16-4 #2 (optional)	D/480JCT-2T1

Slot number	Avaya CallPilot- assigned board label <sup>a</sup>	Meridian 1*/ Communication Server* 1000	T1/SMDI
Slot 14 (PCI Slot 6)	BRD14	MPB16-4 #2 (optional) or MPB96 #2 (optional)	MPB96 board #2 (optional)
Slot 15 (PCI Slot 7)	BRD15	MPB16-4 #2 (optional)	D/480JCT-2T1 (optional)
Slot 16 (PCI Slot 8)	BRD16	MPB16-4 #2 (optional)	D/480JCT-2T1 (optional)
Slot 17 (PCI Slot 9)	BRD17	MPB16-4 #2 (optional) or MPB96 #3 (optional)	MPB96 #3 (optional)
Slot 18 (PCI Slot 10)	BRD18	MPB16-4 #2 (optional)	Not used
Slot 19 (PCI Slot 11)	BRD19	Not used	Not used
Slot 20 (PCI Slot 12)	BRD20	Not used	Not used

a. On some CallPilot Manager screens, the CallPilot-assigned board label is displayed. This label corresponds to the slot number. For example, BRD12 refers to the board in slot 12.

b. The SBC card includes two onboard NICs (for connection to the ELAN subnet, and the Avaya server subnet) and an onboard video card. The NIC and monitor connectors are on the SBC faceplate.

---

## Network connectivity

---

### Introduction

This section describes how the 1002rp server can be integrated into your network. The integration depends on the type of switch you are using.

 **Important:**

To secure the CallPilot server from unauthorized access, ensure that the CallPilot network is inside your organization's firewall.

---

## Reference Documents

For a list of all CallPilot documents, see the following CallPilot Customer Documentation Map.

**Table 2: Call Pilot Customer Documentation Map**

Fundamentals
Fundamentals Guide (NN44200-100)
Library Listing (NN44200-117)
Planning and Engineering
Planning and Engineering Guide (NN44200-200)
Network Planning Guide (NN44200-201)
Converging the Data Network with VoIP Guide (NN43001-260)
Solution Integration Guide for Communication Server 1000/Call Pilot/Contact Center/Telephony Manager (NN49000-300)
Installation and Configuration
Upgrade and Platform Migration Guide (NN44200-400)
High Availability: Installation and Configuration (NN44200-311)
Geographic Redundancy Application Guide (NN44200-322)
Installation and Configuration Task List Guide (NN44200-306)
Quickstart Guide (NN44200-313)
Installer Roadmap (NN44200-314)
Server Installation Guides
201i Server Hardware Installation Guide (NN44200-301)
202i Server Hardware Installation Guide (NN44200-317)
202i Installer Roadmap (NN44200-319)
703t Server Hardware Installation Guide (NN44200-304)
1002rp Server Hardware Installation Guide (NN44200-300)
1002rp System Evaluation (NN44200-318)
1005r Server Hardware Installation Guide (NN44200-308)
1005r System Evaluation (NN44200-316)
1006r Server Hardware Installation Guide (NN44200-320)
600r Server Hardware Installation Guide (NN44200-307)

600r System Evaluation (NN44200-315)

#### Configuration and Testing Guides

Meridian 1 and CallPilot Server Configuration Guide (NN44200-302)

T1/SMDI and CallPilot Server Configuration Guide (NN44200-303)

Communication Server 1000 System and CallPilot Server Configuration Guide (NN44200-312)

#### Unified Messaging Software Installation

Desktop Messaging and My CallPilot Installation and Administration Guide (NN44200-305)

#### Administration

Administrator Guide (NN44200-601)

Software Administration and Maintenance Guide (NN44200-600)

Meridian Mail to CallPilot Migration Utility Guide (NN44200-502)

Application Builder Guide (NN44200-102)

Reporter Guide (NN44200-603)

#### Maintenance

Troubleshooting Reference Guide (NN44200-700)

Preventative Maintenance Guide (NN44200-505)

#### Server Maintenance and Diagnostics

201i Server Maintenance and Diagnostics Guide (NN44200-705)

202i Server Maintenance and Diagnostics Guide (NN44200-708)

703t Server Maintenance and Diagnostics Guide (NN44200-702)

1002rp Server Maintenance and Diagnostics Guide (NN44200-701)

1005r Server Maintenance and Diagnostics Guide (NN44200-704)

1006r Server Maintenance and Diagnostics Guide (NN44200-709)

600r Server Maintenance and Diagnostics Guide (NN44200-703)

Contact Center Manager Communication Server 1000/Meridian 1 & Voice Processing Guide (297-2183-931)

#### End User Information

##### End User Cards

Unified Messaging Quick Reference Card (NN44200-111)

Unified Messaging Wallet Card (NN44200-112)

A-Style Command Comparison Card (NN44200-113)


S-Style Command Comparison Card (NN44200-114)  
Menu Interface Quick Reference Card (NN44200-115)  
Alternate Command Interface Quick Reference Card (NN44200-116)  
Multimedia Messaging User Guide (NN44200-106)  
Speech Activated Messaging User Guide (NN44200-107)  
Desktop Messaging User Guide for Microsoft Outlook (NN44200-103)  
Desktop Messaging User Guide for Lotus Notes (NN44200-104)  
Desktop Messaging User Guide for Novell Groupwise (NN44200-105)  
Desktop Messaging User Guide for Internet Clients (NN44200-108)  
Desktop Messaging User Guide for My CallPilot (NN44200-109)  
Voice Forms Transcriber User Guide (NN44200-110)

---

## Sample network setup: Meridian 1


The following diagram shows a CallPilot server sample network setup with a Meridian 1 switch. The Meridian 1 switch can be one of the following:

- Option 11C or Option 11C Mini
- Option 51C
- Option 61C
- Options 81 and 81C



## Sample network setup: Communication Server 1000

The following diagram shows a CallPilot server network setup with a Communication Server 1000 system.



## Switch connectivity

For more details about how the 1002rp server and switch connection is established, refer to the Installation and Configuration Task List (NN44200-306).

---

## CallPilot ELAN subnet and Avaya server subnet setup

The 1002rp server provides 10/100Base-T Ethernet connectivity through NICs installed in the server. See [Slot assignments](#) on page 15 for details on the location of NICs. The function of the NIC varies based on switch connectivity, as described below:

---

## Meridian 1 or Communication Server 1000 systems

- One NIC provides connectivity to the ELAN subnet.

For information about the purpose and requirements of the ELAN, see the Planning and Engineering Guide (NN44200-200).

- A second NIC is optional.

This optional NIC is required only for Meridian 1 or Communication Server 1000 systems that require a connection to the Avaya server subnet (in addition to the ELAN subnet connection). The Avaya server subnet provides data connectivity between desktop and Web messaging clients, Web-enabled administrative PCs, and the CallPilot server.

---

## Network requirements

Appropriate networking equipment must be available for both the Avaya server subnet and ELAN subnet.

The Avaya server subnet and ELAN subnet must be properly configured for correct CallPilot operation. To ensure correct configuration, Avaya recommends that you consult a network specialist.

---

## Remote access connectivity

The RS-232 COM1 connector on the rear of the 1002rp server provides the connection to an external modem. The modem allows administrators and technical support personnel to administer the 1002rp server from a remote location.

pcAnywhere is used to establish the remote access connection to the server.

---

## Supported peripheral devices

---

### Introduction

This section identifies external devices that are supported by the 1002rp server.

Device	Description
Modem	<p>A 56-Kbit/s external modem (NTRH9078) provides remote access to the 1002rp server. The modem connects to the RS-232 COM1 connector on the rear of the server. Since the modem is an external device, it requires its own AC power source referenced to the same ground as the 1002rp server and the switch to which it is connected.</p>
Ethernet hub or switch	<p>A 10Base-T Ethernet hub or switch provides the ELAN subnet connection between the 1002rp server and the Meridian 1 switch or Communication Server 1000 system. The customer can supply an ethernet hub or switch from third-party vendors or from Avaya. Since the ethernet hub or switch is an external device, it requires an AC power source.</p> <p> <b>Important:</b></p> <p>To comply with EMC radiation requirements, a Class A hub must be located 10 m (33 ft) away from the 1002rp server. Shielded Ethernet cables must be used.</p>
Monitor, keyboard, and mouse	<ul style="list-style-type: none"> <li>15-in. monitor: NTRH9011 or N0038380 LCD monitor.</li> </ul>

Device	Description
	<p>Since the monitor is an external device, it requires its own AC power source.</p> <ul style="list-style-type: none"><li>• Keyboard: NTRH9013</li><li>• Mouse: NTRH9014</li></ul>

# Chapter 3: Preparing for installation

---

## In this chapter

[Installation overview](#) on page 25

[Unpacking the 1002rp server](#) on page 28

[Removing the front bezel and server cover](#) on page 29

[Inspecting the server interior](#) on page 31

---

## Installation overview

---

### Introduction

This section provides an overview of the steps required to install the 1002rp server and peripheral devices.

---

### Installation checklist

The following checklist identifies the tasks that must be performed when installing the Avaya CallPilot® server. For detailed instructions, see [Installing the server](#) on page 43. When you are finished with the installation, continue with the *Installation and Configuration Task List* (NN44200-306).

Step	Description	Check
1	Ensure that you have reviewed the "Installing the Avaya CallPilot server" section in the <i>Installation and Configuration Task List</i> (NN44200-306), and completed stage 1 of the "Installation checklist."	<input type="checkbox"/>

---

Step	Description	Check
2	Unpack the server, and ensure you have all the items you need (see <a href="#">Unpacking the 1002rp server</a> on page 28). Complete the following checklists that are provided in the <i>Installation and Configuration Task List</i> (NN44200-306): <ul style="list-style-type: none"> <li>• "CallPilot software media and documentation checklist"</li> <li>• "CallPilot server hardware checklist"</li> </ul>	□
3	Remove the front bezel and server cover, and inspect the interior (see pages <a href="#">Removing the front bezel and server cover</a> on page 29 and <a href="#">Inspecting the server interior</a> on page 31).	□
4	Replace the server cover.	□
5	Install the power supply modules in the server (see <a href="#">Installing the second power supply module (AC or DC)</a> on page 34).	□
6	For a DC-powered server, set up the DC power source (see <a href="#">DC wire gauge tables</a> on page 36).	□
7	Place the 1002rp server in the chosen location (see <a href="#">Installing the server</a> on page 43).	□
8	Replace the front bezel (see page <a href="#">Inspecting the server interior</a> on page 31).	□
9	Set the DIP switches on the modem (see <a href="#">Preparing the modem</a> on page 44).	□
10	Connect the 1002rp server and devices as follows: <ul style="list-style-type: none"> <li>Connect the monitor, keyboard, and mouse (see <a href="#">Connecting peripherals to the server</a> on page 48). □</li> <li>Connect the modem (see <a href="#">Preparing the modem</a> on page 44). □</li> <li>Connect the 1002rp server to the ELAN hub or switch (Meridian 1 or Communication Server 1000 only) (see <a href="#">Connecting the server to the ELAN subnet</a> on page 50). □</li> </ul>	□
	<div style="margin-left: 20px;">  <b>Important:</b>                      To comply with EMC radiation requirements, a Class A hub must be located 10 m (33 ft.) away from the 1002rp server. Shielded Ethernet cables must be used.                 </div>	
	<div style="margin-left: 20px;">  <b>Note:</b>                      If you are connecting the optional Avaya server subnet, do not power up unless your antivirus programs and Avaya security updates are installed first.                      Connect the 1002rp server to the CLAN hub or switch (optional) (see <a href="#">Connecting the server to the Avaya server subnet (optional)</a> on page 52).                 </div>	

Step	Description	Check
	<p> <b>Important:</b> To comply with EMC radiation requirements, a Class A hub must be located 10 m (33 ft.) away from the 1002rp server. Shielded Ethernet cables must be used.</p> <p>Install the software feature dongle (see <a href="#">Installing the Avaya software feature dongle</a> on page 53).</p> <p>Connect the power cords for all devices, and then power them up.</p>	<p><input type="checkbox"/></p> <p><input type="checkbox"/></p>
11	Start the 1002rp server (see <a href="#">Connecting the server to power</a> on page 55).	<input type="checkbox"/>

## Conventions for warnings

You may encounter the following types of warnings in this guide. Do not ignore them.



### **Voltage:**

Risk of electric shock

Warns you of an immediate electrical hazard which, if not avoided, can result in shock, serious injury, or death.



### **Warning:**

Risk of personal injury

Warns you of a situation in which you can be injured if instructions are not followed exactly as stated.



### **Caution:**

Risk of equipment damage

Alerts you to situations where data can be lost or damaged, equipment can be damaged, actions can result in service interruption, and productive time can be lost.



### **Important:**

Provides information that is essential to the completion of a task.

---

# Unpacking the 1002rp server

---

## Introduction

Follow this procedure to unpack the server and peripherals.



**Warning:**

Risk of personal injury

The 1002rp CallPilot server weighs approximately 34 kg (75 lb) as shipped from manufacturing. To prevent personal injury, have someone help you to unpack and position the server.

### To unpack the equipment

1.



**Important:**

As you unpack each item, check it off against the packing list, as well as against the following checklists provided in the Installation and Configuration Task List (NN44200-306):

- "CallPilot software media and documentation checklist"
- "CallPilot server hardware checklist"

Carefully open the cardboard carton containing the server.

2. Remove the server from the carton; set it on the floor.
3. Carefully open the cartons containing the monitor, keyboard, mouse, modem, and ELAN hub (if supplied), and set the peripherals aside.
4. Put all manuals, CD-ROMs, operating system disks, and any disks for peripherals in a safe place.
5. Save all packing materials and cartons in case you must return any equipment to the carrier.

---

## What is next?

Remove the server cover so that you can inspect the interior of the server. See [Removing the front bezel and server cover](#) on page 29.

---

# Removing the front bezel and server cover

---


## Introduction

To access the server interior, you must remove both the front bezel and the server cover.

Two locked doors, located on the front of the server, cover the front panel, including the CD-ROM drive and tape drive. These doors are part of the front bezel. You must unlock the front bezel doors before you can remove the bezel.

### To remove the front bezel

1.  **Caution:**  
Risk of equipment damage  
  
Do not attempt to move or lift the server before removing the front bezel; the server can disengage from the bezel and fall.  
  
Unlock and open the double doors of the front bezel. See A in the diagram below.
2. Firmly grasp the front bezel by the hand-holds on either side of the chassis, and pull the front bezel from the chassis.



G101733

### To remove the server cover

1.  **Voltage:**  
Risk of electric shock  
High current inside the chassis can cause severe injury.  
  
 **Caution:**  
Risk of equipment damage  
Take precautions to protect internal components. Electrostatic discharge (ESD) can render boards damaged or unusable. Wear an ESD wrist strap.  
Remove the front bezel (see [To remove the front bezel](#) on page 29).
2. Loosen the three thumbscrews at the rear of the top cover.
3. Remove the server cover by pulling the cover toward the rear of the chassis, and then lifting it up and off.
4. Clip the lead from your ESD wrist strap to an unpainted metal section of the chassis.

---

## What is next?

Continue with [Inspecting the server interior](#) on page 31.

---

## Inspecting the server interior

---

### Introduction

You should perform a visual inspection for loose components, foreign matter, or shipping damage inside the server.



**Caution:**

Risk of equipment damage

When working with interior components, use an ESD wrist strap to protect static-sensitive components.

#### To inspect the server interior

1. Carefully check all the cards to ensure they are fully seated on the baseboard.
2. Check for any loose wires or foreign objects, such as loose screws, inside the chassis.
3. Review the slot locations (see [Slot assignments](#) on page 15).
4. Do one of the following:

IF	THEN
you observe any damage	contact your Avaya technical support representative.
components have become loose	secure them. Refer to the procedures in the Installation and Configuration Task List (NN44200-306).
you are satisfied that the 1002rp server has arrived at your site undamaged	replacethe server cover and proceed with the hardware installation. See <a href="#">Installation checklist</a> on page 25.

**IF** **THEN**

**\* Note:**


Do not reinstall the front bezel until the server is in its final location and the CallPilot installation is complete.

**To replace the front bezel after installation is complete**

When the CallPilot server installation is complete and the server is in its final location, replace the front bezel.

- 1. Align the front bezel with the ball studs located at each faceplate corner.

See the diagram below:



- 2. Apply pressure evenly until the bezel snaps onto each ball stud.
- 3. Close and lock the double doors of the front bezel.

# Chapter 4: Power supply installation

---

## In this chapter

[Safety precautions](#) on page 33

[Installing the second power supply module \(AC or DC\)](#) on page 34

[DC wire gauge tables](#) on page 36

[DC rack cabling](#) on page 37

[About the power distribution unit](#) on page 40

[Bringing power and ground into the PDU](#) on page 42

---

## Safety precautions

---

## Equipment handling guidelines

External power equipment, such as an uninterruptible power supply (UPS), is usually very heavy. This equipment requires special handling procedures and additional personnel for unloading and installation. Be aware of weight distribution, and prevent the equipment room floor from being overly stressed.

---

## Safety information

In DC systems, locate the service panel near the entry to the room containing the DC power system that supplies the server.



**Danger:**

Risk of electric shock

Procedures involving electrical connections must be performed only by qualified personnel.  
Ensure that you obey all displayed warning notices on power equipment and connections.

---

## Installing the second power supply module (AC or DC)

---

### Introduction

One power supply module is shipped installed. The second power supply module must be installed on-site.

---

### AC versus DC systems

The power supply modules are similar in appearance for both AC and DC 1002rp servers. The procedures in this section apply to both AC and DC 1002rp servers.


---

### About the power supply module

After the server is powered up (later in this guide), the power supply module LED indicates its status.

A green LED on the power supply module indicates that the module is working properly. If the LED is unlit or red, the module is failing or has failed. A problem with the power supply module is also indicated if an alarm sounds or the power supply LED on the front of the server turns red.

The diagram below shows the location of the power supply modules in a server that has two power supply modules installed:



## To install the power supply module

**⚠ Danger:**

Risk of electric shock

High current inside the chassis can cause severe injury.

The server is shipped with one power supply module installed in the bottom power supply bay. You must install the second power supply module, as described here:

1. Align the power supply module with the top power supply bay.
2. Slide the power supply module into the bay until the module is secured by its connector.  
Use some force, if necessary.
3. Secure the power supply module to the chassis with two thumbscrews at the corners of the power supply faceplate.

## What is next?

Do one of the following:

IF	THEN
this is an AC-powered server	continue with <a href="#">Installing the server</a> on page 43 on page <a href="#">Installing the server</a> on page 43.
this is a DC-powered server	continue with <a href="#">DC wire gauge tables</a> on page 36.

## DC wire gauge tables

### Introduction

The tables in this section specify the DC power feed wire requirements.

## Cabinet and module DC feed recommended wire gauge specifications

Length	#10 AWG	#8 AWG	#6 AWG	Junction box #4 AWG	Junction box #4 AWG
0-30 m (100 ft)	yes	yes	yes	yes	yes
0-45 m (150 ft)	no	yes	yes	yes	yes
0-75 m (250 ft)	no	no	yes	yes	yes
0-135 m (450 ft)	no	no	no	yes	yes
0-210 m (700 ft)	no	no	no	no	yes
Over 210 m (700 ft)	no	no	no	no	no

Length	#10 AWG	#8 AWG	#6 AWG	Junction box #4 AWG	Junction box #4 AWG
--------	---------	--------	--------	---------------------------	---------------------------

## Notes:

1. The cabinet and module ground wire specification is #10 AWG insulated green safety ground wire.
2. The cabinet conduit can be 19.1 mm (0.75-in.) or 31.8 mm (1.25-in.), and must be insulated from the cabinet ground.

---

## Metric wire conversion


AWG No.	Industry standard nominal (sq mm)	Resistance at 20 C (Ohm/100 m)
2	35	0.05
4	25	0.08
6	16	0.13
8	10	0.20
10	6	0.33
12	4	0.63
14	2.5	1.00
16	1.5	1.40
18	1	2.00
20	0.75	2.90
22	0.5	4.60

---

## DC rack cabling

The following photograph shows typical rack power cabling:


## Power supply installation



### \* Note:

The cables are marked with Red and Green tape. The cables with the Red tape connect to the Negative (-) Red side (on the left in the photograph), and the cables with the Green tape connect to the Positive (+) Green side (on the right in the photograph). The sides are identified on the power connections. The ground wire enters at the lower right and attaches to the ground lug.

Main panel wiring diagram with product number.



---

## Rack power and grounding

To ensure a complete power and grounding installation:

- In rackmount server installations, ensure the Avaya CallPilot® server chassis and equipment racks are isolated from other foreign sources of ground. Acceptable isolation methods include: isolation pads, grommeted washers, chassis side rail strips, and non-conducting washers.
- In rackmount server installations where other equipment is also installed in the same 19" rack, ensure that all equipment derives ground from the same service panel as Avaya CallPilot and the switch, whether or not the equipment is AC- or DC-powered.

---

## -48 V DC power distribution rationale

- Minimum installation is one power distribution unit (PDU) with four 48 V DC branch circuits fused at 20 amperes.
- The customer must be able to shut off any branch to ensure every unit at the site continues to function properly.
- DC-powered configuration fits into this scheme as follows:
  - Each PDU receives four branch circuits.
  - Each server receives a feed from each PDU and a different branch circuit.
- In this fashion, with dual hot-swappable power supplies, there is no single point of failure in the power system. For example, you can remove any power supply, including a PDU, and everything continues to work.
- This is applicable to either North American or European installation sites (with a 230 V AC inverter).
- The secondary rack supports four servers and follows a similar scheme.

---

## About the power distribution unit

---

### Introduction

A PDU is installed in a rack that has DC-powered servers. Power from the DC supply source enters the PDU and can then be distributed to one or more servers. A single PDU can supply DC power to four DC power supply modules. A server can have either one or two power supply modules installed. You can determine the number of PDUs to install in a rack by counting the number of power supply modules in each rack.

---

### PDU power and grounding

To ensure a complete power and grounding installation:

In rackmount DC-powered server installations, ensure the PDU (Power Distribution Unit for DC applications) is installed on the same rack as the CallPilot server. This is required since the main ground wire for the PDU is not insulated from the metal enclosure.

---

### Multiple PDUs

A server operates on a single power supply module. Its total capacity is two installed power supply modules. The second power supply module is the redundant power supply module.

A PDU can distribute power to a maximum of four power supply units that can be installed in two or more servers. Therefore, if there are three or four servers installed in a rack, then you must install a second PDU.

 **Note:**

The power supply module installs in the server. It does not refer to a UPS, which is a separate unit on the rack.

## PDU terminal blocks and wiring diagram

A PDU consists of eight terminal blocks within a metal enclosure. Before installing the PDU, connect the terminal blocks so that each output connector receives power from a separate -48 V dc branch circuit, as shown in the following diagram. Use AWG 10 wires for these connections.




Figure 1: Single PDU wiring diagram

## DC power input

DC power input into the distribution unit connects BAT-1 to BAT-4 and BR-1 to BR-4. Refer to the preceding diagrams for the location of these terminals. Connect the input wires before installing the PDU on the rack.

---

## Bringing power and ground into the PDU

---

### Introduction

Install BAT/BATRTN wires in pairs. Each pair of wires supplies voltages to a module through a power harness. The module harnesses are installed in the cabinet PDU and connected to the modules at the factory. See [About the power distribution unit](#) on page 40.

#### To bring DC power and ground into the PDU

1. If you are using a conduit, terminate the 32 mm (1-1/4 in.) or 19 mm (3/4 in.) conduit at the top rear of the cabinet or at the bottom front of the cabinet using the knockouts provided. The number of wire pairs you can run in each conduit depends on the wire gauge.

 **Note:**

To preserve ground integrity, the conduit must be insulated.

2. Select a power feed with a circuit breaker dedicated to each module, and identify it with an appropriate tag.
3. Select a wire size to suit the required feed length from the power source (see [DC wire gauge tables](#) on page 36).
4. Use pliers to strip 6 mm (1/4 in.) to 13 mm (1/2 in.) of the insulation from one end of all power and ground feed wires.
5. Undo the terminal block screws at (-) positions 0, 1, 2, and 3.
6. Insert the red wires into terminal block positions 0, 1, 2, and 3.
7. Secure the wires in the terminal block by tightening the screws.
8. Undo the terminal block screws at (+) positions 0, 1, 2, and 3.
9. Insert the black wires into terminal block positions 0, 1, 2, and 3.
10. Secure the wires in the terminal block by tightening the screws.
11. Select a #10 AWG green wire safety ground and attach it to the cabinet.
12. Measure the module ground continuity by touching one multimeter lead to any BATRTN terminal block connector and the other end to the GND terminal block connector. Ensure the measurement is between 0-0.5 ohms.

# Chapter 5: Installing the server and connecting the peripheral devices

---

## In this chapter

[Installing the server](#) on page 43

[Preparing the modem](#) on page 44

[Connecting peripherals to the server](#) on page 48

[Connecting the server to the ELAN subnet](#) on page 50

[Connecting the server to the Avaya server subnet \(optional\)](#) on page 52

[Installing the Avaya software feature dongle](#) on page 53

[Connecting the server to power](#) on page 55

---

## Installing the server

---

### Introduction

Before you install the 1002rp server, ensure that the chosen location meets the requirements identified on the "Site inspection checklist" provided in the Installation and Configuration Task List (NN44200-306).

## To install the server

Place the 1002rp server in its chosen location. If you are installing the server in a rack cabinet, follow the instructions that are provided with the slide rails.

Connect peripheral devices as described in the remainder of this chapter.



**Warning:**

Do not connect the server to the power yet.

---

## Preparing the modem

---

### Introduction

You require a modem to support remote dial-up access to the Avaya CallPilot® server. The modem also enables Avaya technical support to connect to your Avaya CallPilot server for troubleshooting purposes. Avaya connects to your server only when you request technical assistance.

---

## Required equipment

To install the modem, you need the following equipment:

- an RJ-11 analog phone cord
- a power adapter cord
- an analog line jack
- tweezers, or a screwdriver small enough to use to adjust DIP switches

The following modem is provided with your server:

an analog external U.S. Robotics 56-Kbit/s modem (NTRH9078) that includes a 25-pin male to 9-pin female shielded serial cable for your modem

**\* Note:**

Ensure that you have the correct cable for your modem, as follows:

56-Kbit/s modem: A0841984


## Modem DIP switches

Set the modem DIP switches before you connect the modem to the CallPilot server.

**\* Note:**

This section applies only to the U.S. Robotics 56-Kbit/s external Sportster modem. If your modem is different, refer to the documentation for your modem.

The following diagram shows the key components of the external modem, including the location and required settings of the DIP switches:



## To set the modem DIP switches

Use a pair of tweezers or a small screwdriver to set the DIP switches as described in the Change to column of the following table:

 **Note:**

ON is down. OFF is up.

DIP switch	Default setting	Change to	Function
1	OFF	OFF	Data Terminal Ready (DTR) override <ul style="list-style-type: none"> <li>• OFF: Normal DTR operations. (The computer must provide a DTR signal for the modem to accept commands. If DTR is dropped, the call is terminated.)</li> <li>• ON: The modem ignores DTR (override).</li> </ul>
2	OFF	OFF	Verbal/numeric result codes <ul style="list-style-type: none"> <li>• OFF: Verbal (word) results.</li> <li>• ON: Numeric results.</li> </ul>
3	ON	ON	Result code display <ul style="list-style-type: none"> <li>• OFF: Suppresses result codes.</li> <li>• ON: Enables result codes.</li> </ul>
4	OFF	OFF	Command mode local echo suppression <ul style="list-style-type: none"> <li>• OFF: Displays keyboard commands.</li> <li>• ON: Suppresses echo.</li> </ul>
5	ON	ON	Auto answer suppression <ul style="list-style-type: none"> <li>• OFF: The modem answers on the first ring, or higher if specified in NVRAM.</li> <li>• ON: Disables auto answer.</li> </ul>
6	OFF	OFF	Carrier Detect (CD) override <ul style="list-style-type: none"> <li>• OFF: The modem sends a CD signal when it connects with another modem; it drops the CD on disconnect.</li> <li>• ON: CD is always ON (override).</li> </ul>
7	OFF	OFF	Power-on and ATZ reset software defaults <ul style="list-style-type: none"> <li>• OFF: Loads Y or Y1 configuration from user-defined NVRAM.</li> <li>• ON: Loads &amp;F0-Generic template from read-only memory (ROM).</li> </ul>
8	ON	ON	AT command set recognition

DIP switch	Default setting	Change to	Function
			<ul style="list-style-type: none"><li>• OFF: Disables command recognition (dumb mode).</li><li>• ON: Enables recognition (smart mode).</li></ul>

---


---

## What is next?

Continue with [Connecting peripherals to the server](#) on page 48.

## Connecting peripherals to the server

### Rear panel connectors



**\* Note:**

The above diagram shows the power switch and power input for an AC server. The rest of the diagram is the same for AC or DC servers. For peripheral device connections, this picture applies to AC and DC servers.

## To connect the mouse, keyboard, and monitor to the server

1. Place the monitor, keyboard, and mouse in the same location as the server.
2. Plug the keyboard/mouse dual cable into the PS/2 connector on the SBC card faceplate (see the diagram above).
3. Plug the keyboard and mouse into the appropriate connectors on the keyboard/mouse dual cable.
4. Plug the monitor into the monitor connector on the SBC card. Tighten the screws on the connector.
5. Ensure that a single-point ground reference is available for all the power outlets serving the CallPilot server and its peripherals. Before the CallPilot server installation, a qualified electrician must implement the single-point ground reference requirement between the power outlets of the CallPilot server and the power outlets of the switch.
6. Connect the power cord to the monitor and plug the other end into a wall receptacle or power bar.

**Note:**

Ensure that the power source is consistent with the SBC for all ancillary equipment.

7. Turn on the monitor.

## To connect the modem to the server

1. Ensure that the modem AC power cord is not plugged in.
2. Connect the large 25-pin male connector to the back of the modem. Tighten the connector screws.
3. Connect the 9-pin female connector to COM1 at the rear of the server. Tighten the connector screws.
4. Connect one end of the telephone cable to the modem RJ-11 jack labeled LINE.
5. Connect the other end of the telephone cable to the RJ-11 jack in the wall.
6. Ensure that a single-point ground reference is available for all the power outlets serving the CallPilot server and its peripherals. Before the CallPilot server installation, a qualified electrician must implement the single-point ground reference requirement between the power outlets of the CallPilot server and the power outlets of the switch.
7. Connect the power cord to the modem, and plug the other end into a wall receptacle or power bar.

**Note:**

Ensure that the power source is consistent with the SBC for all ancillary equipment.

8. Turn on the modem.

## What is next?

Continue with [Connecting the server to the ELAN subnet](#) on page 50.

---

## Connecting the server to the ELAN subnet

---

### Introduction

 **Important:**

This section applies only if the 1002rp server connects to a Meridian 1 switch or Communication Server 1000 system.

Connect the CallPilot server to the Meridian 1 switch or Communication Server 1000 system using the ELAN interface.

 **Important:**

For important considerations about using the ELAN subnet in your network, see the CallPilot Planning and Engineering Guide (NN44200-306).

 **Important:**

To comply with EMC radiation requirements, a Class A hub must be located 10 m (33 ft.) away from the 1002rp server. Shielded Ethernet cables must be used.

---

### Media Access Control address

The Media Access Control (MAC) address is a unique number assigned to network cards and controllers. The procedure below asks you to record the ELAN MAC address. The MAC address is recorded on a label affixed to the back of the chassis.

## To connect the server to the ELAN subnet

1. See the diagram on page [Rear panel connectors](#) on page 48 to locate the ELAN Ethernet connector.
2. Locate the MAC address label on the back of the chassis that identifies the ELAN controller MAC address.
3. Record the MAC address on the Configuration Wizard worksheet that is provided in the Installation and Configuration Task List (NN44200-306).

You need the MAC address to identify the ELAN when running the Configuration Wizard to configure the CallPilot server.

4. Connect an RJ-45 network cable from the ELAN hub or switch to the ELAN connector on the server.

 **Note:**

The ELAN hub or switch is optional if you use a cross-over network cable to make a direct point-to-point connection from the server to the switch. However, if you choose to establish a direct point-to-point ELAN connection, no other device can connect to the ELAN.

5. At the switch, connect the ELAN network cable to an MAU (Ethernet) transceiver for a Meridian 1, or to the RJ45 ELAN connector for a CS1000. Then complete the connection from the transceiver to the switch.

 **Danger:**

Risk of the fire hazard

MAU model NTRH9069 is not suitable for installation in ducts, plenums, or other spaces used for environmental air. Do not install it above a false ceiling or below a raised floor, unless it can be confirmed that these spaces are not used to convey environmental air.

---

## What is next?

the server will	THEN
be connected to the Avaya server subnet	continue with <a href="#">Connecting the server to the Avaya server subnet (optional)</a> on page 52
not be connected to a Avaya server subnet	continue with installing the software feature dongle. See <a href="#">Installing the Avaya software feature dongle</a> on page 53.

---

## Connecting the server to the Avaya server subnet (optional)

---

### Introduction

This section provides instructions to connect the server to the Avaya server subnet.

 **Note:**

The Avaya server subnet is optional. However, a Avaya server subnet is required to support desktop and Web messaging users.

 **Important:**

To comply with EMC radiation requirements, a Class A hub must be located 10 m (33 ft.) away from the 1002rp server. Shielded Ethernet cables must be used.

---

### Media Access Control address

The MAC address is a unique number assigned to network cards and controllers. The procedure below asks you to record the CLAN MAC address. The MAC address is recorded on a label affixed to the back of the chassis.

#### To connect the server to the Avaya server subnet

1. See the diagram on page [Rear panel connectors](#) on page 48 to locate the CLAN network card.
2. Locate the MAC address label on the back of the chassis that identifies the CLAN controller MAC address.
3. Record the MAC address on the Configuration Wizard worksheet that is provided in the Installation and Configuration Task List (NN44200-306).

You need the MAC address to identify the CLAN when running the Configuration Wizard to configure the CallPilot server.

 **Note:**

When connecting the optional Avaya server subnet, do not power up unless your antivirus programs and Avaya security updates are installed first.

4. Connect an RJ-45 network cable from the CLAN hub or switch to the CLAN connector.

---

## What is next?

Continue with [Installing the Avaya software feature dongle](#) on page 53.

---


## Installing the Avaya software feature dongle

---

### Introduction

The software feature key is a security device that stores the unique serial number of the server. The feature key is embedded in the Avaya software feature dongle, which plugs into the parallel port.

An illustration of the software feature key embedded in the software feature dongle is shown below:



G101738

## Requirements

For installation, you require a Phillips No. 1 screwdriver.

### To install the software feature dongle

1. Ensure that there is no cable connected to the parallel port.

 **Note:**

The parallel port is also known as the printer port or LPT1. It is located at the back of the server. See the diagram on page [Rear panel connectors](#) on page 48.

2. If the software feature key is not preinstalled in the dongle, remove it from the plastic bag, and carefully insert it into the software feature slot on the dongle. Make sure that the clips secure it properly and that the Avaya logo faces outwards.
3. Plug the male end of the adapter into the parallel port.
4. Tighten the connector screws.

---

## What is next?

Continue with [Connecting the server to power](#) on page 55.

---

## Connecting the server to power

---

### Before you begin

Ensure that proper power and grounding are available for all the power outlets serving the CallPilot server and its associated peripherals. Power for these devices must be wired and fused independently of all other receptacles, and referenced to the same ground as the PBX system.

A qualified electrician must implement the single-point ground reference as required between the power outlets of the CallPilot server and the power outlets of the switch.


Provide a sufficient number of properly grounded power outlets or power bars for all equipment. For more information, refer to grounding and power requirements in this document and in the CallPilot Planning and Engineering Guide (NN44200-200).

The single-point ground (SPG) required by the system can be an isolated ground (IG) bus or AC equipment ground (ACEG) bus in the service panel or transformer. The system must be connected to safety ground/protective earth in accordance with NEC requirements. For international use, the system must be connected to safety ground/protective earth in accordance with Paragraph 2.5 of EN60950/IEC950.

 **Note:**

Refer to Large System: Planning and Engineering (553-3021-120) for a complete description of approved ground sources and methods. Insulated ground wire must be used for system grounding.

Before you connect the server to the power source, review the following diagram to ensure that all peripheral hardware devices are in place.



G250018

**\* Note:**

For details on the DC power source for 1002rp DC servers, see [Installing the second power supply module \(AC or DC\)](#) on page 34

**To connect the 1002rp AC server to power**

1.

**⚠ Warning:**

Risk of personal injury, risk of hardware failure

The power outlets used by the CallPilot server and its peripheral devices must be connected to the same single-point ground reference as the one used by the switch with MGate cards (NTRB18CA) connected to the CallPilot server. If this requirement is not met, power transients can cause personal injury, or hardware failure, or both. Refer to the Installation and Configuration Task List (NN44200-306) for more information on single-point grounding requirements.

Plug the server AC power cord into the server rear panel.

2. Plug the other end into a wall receptacle or power bar.


## To connect the 1002rp DC server to power

1.  **Danger:**  
Risk of electrical shock
  - Only qualified personnel can alter electrical connections.
  - Ensure the power distribution unit (PDU) is turned off until you are instructed to turn it on.

Connect the DC power cable to the server.

2. Connect the other end of the DC power cable to the PDU. Use the supplied clips and screws to secure the plugs.

The following photograph shows the keyed plug of the DC power cable. This plug connects to the PDU:



 **Note:**

If you are not using a Avaya-supplied PDU, have a qualified electrician connect the cable appropriately to your DC power plant. The 1002rp uses a negative 48 V power supply, therefore the red cable is negative (-48 V) and the black cable is the ground (GND).

3. Turn on the PDU.

## To start the server

1. Press the server power switch to start the server.
2. Observe the Power-On Self Test (POST) and initialization messages on the monitor.
3. Let the mini-setup sequence run until you are prompted to login to the operating system.

 **Note:**

The system may perform multiple reboots. This is normal.

4. Ensure that the operating system logon window appears on the monitor.

 **Note:**

If the logon window does not appear, refer to the 1002rp Server Maintenance and Diagnostics (NN44200-701) guide for troubleshooting instructions.

# Chapter 6: EMC emission level protection for the 1002rp Server

To lower the EMC emission level, ferrite cores are installed with one loop (see diagram below) on the following external cables:


- Ferrite Core (TDK and part number ZCAT3035-1330) — for the triple DS30X I/O cable (Avaya and part number NTRH2014), at each end of the cable
- Ferrite Core (TDK and part number ZCAT1325-0530) — for the modem power supply cable, at each end of the cable
- Ferrite Core (Fair Rite and part number 0431164181) — for the Trenton combined keyboard and mouse Y connector cable, at the server end of the cable
- Ferrite Core (part number WE 742 7111) — for Ethernet port cat5 UTP cable, at the server end of the cable



**Caution:**

Risk of equipment damage

The ferrite cores are preinstalled on these customer provided cables. It is not the customer's responsibility to attach these ferrite cores to these cables. However, the customer should ensure that these ferrites are in place to keep the EMC emission levels low.



**Figure 2: Ferrites secured to an external cable**

The ferrites are secured to the appropriate cable with plastic enclosure clips. Ty wraps are added to the cable loop.

## Index

---

### Numerics

- 703t server
  - environmental specifications .....[12](#)

---

### A

- adapter
  - software feature key, illustration .....[53](#)
- alarm board .....[13](#)

---

### C

- checklist
  - installation .....[25](#)
- CLAN
  - media access control address .....[52](#)
- Communication Server 1000 and CallPilot server
  - network diagram .....[21](#)
- connecting peripherals to the server .....[48](#)
- connecting the server .....[55](#)
- connectivity
  - Ethernet .....[22](#)
  - remote .....[23](#)
- Customer LAN
  - see CLAN .....[52](#)
- customer service .....[9](#)

---

### D

- DC power .....[39](#)
- DC power and ground .....[42](#)
- DC power input .....[41](#)
- DC wire gauge tables .....[36](#)
- devices, peripheral
  - Ethernet hub .....[23](#)
  - keyboard .....[23](#)
  - modem .....[23](#)
  - monitor .....[23](#)
  - mouse .....[23](#)
- diagram
  - connection
    - network, Communication Server 1000 and CallPilot server .....[21](#)
    - network, M1 and CallPilot server .....[20](#)
  - front panel .....[12](#)

- PCI and ISA connectors .....[14](#)
  - rear panel
    - slot locations .....[13](#)
  - server connections for the power cord and peripherals .....[48](#)
- DIP switches
  - modem, function .....[45](#)
- DIP switches, setting
  - modem .....[45](#)
- distributor .....[9](#)
- documentation .....[9](#)
- dongle .....[53](#)

---

### E

- ELAN
  - Media Access Control address .....[50](#)
- environmental specifications, 703t server .....[12](#)
- equipment
  - unpacking .....[28](#)
- Ethernet hub
  - description .....[23](#)

---

### F

- fax modem
  - illustration .....[45](#)
  - required equipment .....[44](#)
- features
  - server .....[11](#)
- features, front panel
  - diagram .....[12](#)
- front bezel .....[29](#)

---

### G

- grounding guidelines .....[36](#)

---

### I

- illustration
  - modem .....[45](#)
  - software feature key adapter .....[53](#)
  - TLAN .....[21](#)
- inspecting

server interior .....	<a href="#">31</a>
installation checklist .....	<a href="#">25</a>
IRQ mapping table .....	<a href="#">17</a>

---

## K

keyboard	
connecting to the server .....	<a href="#">48</a>
description .....	<a href="#">23</a>
keylock .....	<a href="#">53</a>

---

## M

M1 and CallPilot server network diagram .....	<a href="#">20</a>
Metric wire conversion .....	<a href="#">37</a>
modem	
connecting to the server .....	<a href="#">48</a>
description .....	<a href="#">23</a>
DIP switches, setting .....	<a href="#">45</a>
illustration .....	<a href="#">45</a>
required equipment .....	<a href="#">44</a>
monitor	
connecting to the server .....	<a href="#">48</a>
description .....	<a href="#">23</a>
mouse	
connecting to the server .....	<a href="#">48</a>
description .....	<a href="#">23</a>

---

## N

network	
protocols, supported .....	<a href="#">22</a>
network interface cards .....	<a href="#">22</a>

---

## P

part number	
Ethernet hub .....	<a href="#">23</a>
keyboard .....	<a href="#">23</a>
modem .....	<a href="#">23</a>
monitor .....	<a href="#">23</a>
mouse .....	<a href="#">23</a>
PCI and ISA connectors	
diagram .....	<a href="#">14</a>
PDU .....	<a href="#">40, 41</a>
multiple PDUs .....	<a href="#">41</a>
power and grounding .....	<a href="#">40</a>
single PDU wiring diagram .....	<a href="#">41</a>
peripheral devices	
Ethernet hub .....	<a href="#">23</a>
keyboard .....	<a href="#">23</a>

modem .....	<a href="#">23</a>
monitor .....	<a href="#">23</a>
mouse .....	<a href="#">23</a>
peripherals	
connecting to the server .....	<a href="#">48</a>
power connection	
AC server .....	<a href="#">55</a>
DC server .....	<a href="#">55</a>
power distribution rationale .....	<a href="#">39</a>
power distribution unit	
See PDU .....	<a href="#">40</a>
power guidelines .....	<a href="#">36</a>
power supply	
bringing power and ground into the PDU .....	<a href="#">42</a>
DC wire gauge tables .....	<a href="#">36</a>
grounding guidelines .....	<a href="#">36</a>
Metric wire conversion .....	<a href="#">37</a>
module installation .....	<a href="#">35</a>
module location .....	<a href="#">34</a>
overview .....	<a href="#">34</a>
PDU .....	<a href="#">40</a>
power distribution rationale .....	<a href="#">39</a>
rack power and grounding .....	<a href="#">39</a>
protocols, supported network .....	<a href="#">22</a>

---

## R

rack power and grounding .....	<a href="#">39</a>
remote access	
connectivity .....	<a href="#">23</a>
removing	
front bezel .....	<a href="#">29</a>
server cover .....	<a href="#">29</a>
replacing	
server cover .....	<a href="#">31</a>
reseller .....	<a href="#">9</a>

---

## S

safety information .....	<a href="#">33</a>
serial number of the server .....	<a href="#">53</a>
server	
connecting peripherals .....	<a href="#">48</a>
environmental specifications .....	<a href="#">12</a>
power connection .....	<a href="#">55</a>
serial number .....	<a href="#">53</a>
setting	
modem DIP switches .....	<a href="#">45</a>
slot assignments .....	<a href="#">15</a>
slot definition .....	<a href="#">16</a>
slot numbering .....	<a href="#">16</a>

software feature key .....	<a href="#">53</a>	illustration .....	<a href="#">21</a>
specifications, environmental .....	<a href="#">12</a>	training .....	<a href="#">9</a>
switches, setting DIP modem .....	<a href="#">45</a>		
<hr/>		<hr/>	
<b>T</b>		<b>U</b>	
tables, slot assignment .....	<a href="#">15</a>	unpacking equipment .....	<a href="#">28</a>
TLAN			

