



Avaya CallPilot® 703t Server Maintenance and Diagnostics

5.0
NN44200-702, 01.09
December 2010

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya generally makes available to users of its products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on its Hardware and Software ("Product(s)"). Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this Product while under warranty is available to Avaya customers and other parties through the Avaya Support Web site: <http://support.avaya.com>. Please note that if you acquired the Product(s) from an authorized Avaya reseller outside of the United States and Canada, the warranty is provided to you by said Avaya reseller and not by Avaya.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO/](http://support.avaya.com/licenseinfo/) ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, or Hardware provided by Avaya. All content on this site, the documentation and the Product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Third-party components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: <http://support.avaya.com/Copyright>.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation and Product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation and Product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners, and "Linux" is a registered trademark of Linus Torvalds.

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support Web site: <http://support.avaya.com>.

Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your Product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: <http://support.avaya.com>.

Japan Denan statement

The following applies to server models 1006r, 1005r, 703t, and 1002rp:

 **Warning**

Please be aware of the following while installing the equipment:

- Please use the connecting cables, power cord, and AC adaptors shipped with the equipment or specified by Avaya to be used with the equipment. If you use any other equipment, it may cause failures, malfunctioning or fire.
 - Power cords shipped with this equipment must not be used with any other equipment. If the above guidelines are not followed, it may lead to death or severe injury.
-

 **警告**

本製品を安全にご使用頂くため、以下のことにご注意ください。

- 接続ケーブル、電源コード、ACアダプタなどの部品は、必ず製品に同梱されております。添付品または指定品をご使用ください。添付品・指定品以外の部品をご使用になると故障や動作不良、火災の原因となることがあります。
- 同梱されております付属の電源コードを他の機器には使用しないでください。上記注意事項を守らないと、死亡や大怪我など人身事故の原因となることがあります。

Japan VCCI statement

The following applies to server models 1006r, 1005r, 703t, 201i, and 1002rp:

この装置は、情報処理装置等電波障害自主規制協議会 (VCCI) の規定に基づくクラスA装置です。この装置を家庭環境で使用すると電波障害を引き起こすことがあります。この場合には使用者が適切な対策を取るようにより要求されることがあります。

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may occur, in which case, the user may be required to take corrective action.

Contents

Chapter 1: Customer service	11
Getting technical documentation	11
Getting product training	11
Getting help from a distributor or reseller	11
Getting technical support from the Avaya Web site	12
Chapter 2: About this guide	13
In this chapter	13
Maintenance and diagnostics overview	13
Replacement parts	13
Preparing for maintenance activities	14
Customer Documentation Map	14
Chapter 3: Troubleshooting your Avaya CallPilot® system	19
In this chapter	19
Overview	19
Interpreting front panel LEDs	20
LED locations	20
Network LED states	21
Hard drive LED states	22
Power/sleep LED states	23
System status LED	23
Tape drive LED states	24
CD-ROM drive LED states	25
Interpreting rear panel LEDs	25
MPB96 DS30 connection link LED states	25
Blue LED	26
Interpreting internal LEDs	26
MPB96 LED states	26
PCI FPGA Done LED (closest to the I/O card bracket)	27
DSP FPGA Done LED	27
CTbus FPGA Done LED (furthest from the I/O card bracket)	27
RAID controller LED states	27
To check if RAID board is working properly	27
Interpreting POST diagnostics	28
Types of beep codes	28
SCSI controller diagnostics	30
BIOS initialization	30
RAID controller diagnostics	30
What to do when the server fails to boot into service	31
When the 703t server does not boot and there are no audible beeps	31
When the 703t server does not boot and the system board LED is red	32
When the 703t server does not boot and makes audible beeps	32
If beeps are short	32
If beeps are long	33
When the 703t server boots to the operating system and makes audible beeps	33
When the 703t server boots to the operating system but does not boot to CallPilot	33

Chapter 4: Using Windows online diagnostic tools.....	35
In this chapter.....	35
Overview.....	35
Operating system Event Viewer.....	35
TCP/IP diagnostics.....	36
chkdsk utility.....	36
Viewing event logs.....	36
Types of event logs.....	37
To use the operating system Event Viewer.....	37
Using TCP/IP diagnostic tools.....	39
The ipconfig command.....	40
Ipconfig default.....	40
Ipconfig command syntax.....	40
To run the ipconfig command from Windows.....	40
The ping command.....	41
Ping command syntax.....	41
To run the ping command from Windows.....	41
The tracert command.....	42
How tracert works.....	42
Tracert syntax.....	42
To run the tracert command from Windows.....	43
The arp command.....	43
Arp command syntax.....	43
To run the arp command from Windows.....	44
The nbtstat command.....	45
Nbtstat command syntax.....	45
To run the nbtstat command from Windows.....	46
The netstat command.....	46
Netstat command syntax.....	46
To run the netstat command from Windows.....	47
Using the chkdsk utility.....	47
Chkdsk utility syntax.....	47
To run the chkdsk utility from Windows.....	48
Chapter 5: Using serial port diagnostic tools.....	49
In this chapter.....	49
Overview.....	49
Shutting down services.....	49
Service to stop for COM 1 testing.....	50
Services to stop for COM 2 testing.....	50
Net Stop command.....	50
Net Stop command syntax.....	50
To invoke the Net Stop command from Windows.....	51
Conducting TSTSERIO tests.....	51
TSTSERIO command syntax.....	51
TSTSERIO internal loopback diagnostic subtests.....	52
To invoke the TSTSERIO /P command from Windows.....	52
TSTSERIO external loopback plug subtests.....	53
To invoke the TSTSERIO /S command from Windows.....	53
Conducting TSTSERIO tests with the loopback plug.....	53
9-pin connector plug.....	54

Restarting services.....	54
Service to restart after COM 1 testing.....	54
Services to restart after COM 2 testing.....	54
Net Start command.....	55
To invoke the Net Start command from Windows.....	55

Chapter 6: Using CallPilot Manager to monitor hardware.....57

In this chapter.....	57
Understanding fault management.....	57
Event processing.....	58
Alarm notification.....	58
Component dependencies.....	58
Detecting hardware problems.....	59
Alarm Monitor.....	59
About alarms.....	59
To investigate using the Alarm Monitor.....	60
Event Browser.....	60
About events.....	60
To investigate using the Event Browser.....	61
Channel and Multimedia Monitors.....	61
Disabling call channels.....	62
The Maintenance page.....	62
What the Maintenance page provides.....	62
Maintenance activities for each component.....	63
Viewing component states.....	64
Component states.....	64
Alert icons.....	65
To view the state of a hardware component.....	65
Starting and stopping components.....	66
Stop versus Courtesy stop.....	66
Courtesy stop.....	66
Stop.....	67
Components that can be started and stopped.....	67
To start or stop a component.....	67
Running integrated diagnostics.....	68
Before you begin.....	69
Diagnostic tests available for each component.....	69
Components that have diagnostic tests available.....	69
If a diagnostic test fails or cannot be run.....	69
To run a diagnostic test.....	70
Viewing the last diagnostic results.....	71
To view the last diagnostics result.....	71
Working with the Multimedia Monitor.....	72
To view or work with multimedia channel states.....	72
Working with the Channel Monitor.....	73
To view or work with call channel states.....	73

Chapter 7: Using Avaya CallPilot® system utilities.....75

In This chapter.....	75
Overview.....	75
Accessing the system utilities.....	76
Diagnostics Tool.....	76

To access the Diagnostics Tool.....	76
To enable startup diagnostics.....	76
To disable startup diagnostics.....	77
PEP Maintenance utility.....	77
To access the PEP Maintenance utility.....	77
To view a list of all installed PEPs.....	77
Session Trace.....	78
To access the session trace tool.....	78
To find a session.....	79
System Monitor.....	79
To access the System Monitor.....	80
Channel Monitor tab.....	80
CallPilot services.....	81
DSPs.....	82
DS30X links.....	82
System Info tab.....	82
Legend/Help tab.....	83

Chapter 8: Replacing basic chassis components.....85

In this chapter.....	85
Preparing the server for hardware maintenance.....	85
To disconnect the power and peripheral device cables.....	86
Removing the side cover.....	88
To remove the side cover.....	88
Removing and replacing the upper fan holder foam.....	90
To remove the upper fan holder foam.....	91
To replace the upper fan holder foam.....	91
Replacing the side cover.....	91
To replace the side cover.....	92
Cooling fans description.....	93
Replaceable fan locations.....	94
Fan labels.....	96
Replacing a front system fan.....	96
To remove a front system fan.....	97
Replacing a rear system fan.....	99
To remove a rear system fan.....	99
Replacing the processor fan.....	101
To remove the processor fan.....	101

Chapter 9: Replacing media drives.....105

SCSI and IDE drive cabling.....	105
Cabling diagram.....	105
Replacing a faulty hard drive.....	106
Hard drive description.....	107
SCSI drive cabling.....	107
Hard drive configuration.....	107
Filler panels and EMI shields.....	108
To remove a hard drive from the server.....	109
To install the hard drive.....	111
Replacing the tape drive.....	113
Filler panels and EMI shields.....	113
Tape drive configuration.....	113

To remove the tape drive.....	114
To install a replacement tape drive.....	115
Replacing the CD-ROM drive.....	117
To remove the CD-ROM drive.....	117
To install a replacement CD-ROM drive.....	118
Replacing the floppy disk drive.....	119
To remove the floppy disk drive.....	120
To install a replacement floppy disk drive.....	121
Chapter 10: RAID operations.....	125
In this chapter.....	125
RAID overview.....	125
RAID configuring and splitting.....	125
Verifying the RAID firmware.....	126
To verify the RAID firmware version.....	126
To upgrade or downgrade the RAID firmware.....	127
Configuring RAID using LSI Elite 1600 controller and Ctrl+M.....	128
To configure an LSI Elite 1600 RAID system.....	128
Replacing the LSI1600 or LSI320-2 card with LSI320-2.....	130
Verifying consistency on the drives.....	131
To perform a consistency check.....	132
RAID splitting.....	132
Full data backup.....	133
To split the RAID.....	133
Perform a CallPilot software upgrade.....	134
To synchronize the RAID after a successful upgrade.....	134
To synchronize RAID after an unsuccessful upgrade.....	135
Task summary for configuring RAID.....	136
Task summary for RAID splitting.....	137
Chapter 11: Replacing or adding voice processing boards.....	141
In this chapter.....	141
DSP numbering and location.....	141
DSP numbering on MPB96 boards.....	141
Replacing MPB96 boards.....	142
Requirements.....	143
To replace an MPB96 board.....	144
Chapter 12: Working with DIMMs and the CPU.....	147
In this chapter.....	147
Replacing or adding baseboard DIMMs.....	147
DIMM sizes and compatibility.....	147
To remove baseboard DIMMs.....	148
To install baseboard DIMMs.....	149
Replacing the CPU.....	150
CPU replacement package contents.....	150
To remove the faulty CPU.....	151
To install a new CPU.....	154
Chapter 13: Working with the Avaya CallPilot® server BIOS.....	161
In this chapter.....	161
Overview.....	161

BIOS release.....	161
To determine the BIOS release.....	161
BIOS settings.....	162
Main.....	162
Advanced.....	163
Security.....	164
Server.....	164
Boot.....	165
Updating and configuring the BIOS.....	166
BIOS update availability.....	166
To configure the BIOS.....	166
Recovering from corrupted CMOS and BIOS.....	167
To recover from a corrupted CMOS.....	168
Chapter 14: 703t description reference.....	171
In this appendix.....	171
Server features.....	171
Front panel features.....	172
Rear panel diagram.....	174
Slot assignments.....	176
Slot definition and numbering.....	176
IRQ mapping table.....	177
Index.....	179

Chapter 1: Customer service

Visit the Avaya Web site to access the complete range of services and support that Avaya provides. Go to www.avaya.com or go to one of the pages listed in the following sections.

Navigation

- [Getting technical documentation](#) on page 11
- [Getting product training](#) on page 11
- [Getting help from a distributor or reseller](#) on page 11
- [Getting technical support from the Avaya Web site](#) on page 12

Getting technical documentation

To download and print selected technical publications and release notes directly from the Internet, go to www.avaya.com/support.

Getting product training

Ongoing product training is available. For more information or to register, you can access the Web site at www.avaya.com/support. From this Web site, you can locate the Training contacts link on the left-hand navigation pane.

Getting help from a distributor or reseller

If you purchased a service contract for your Avaya product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

Getting technical support from the Avaya Web site

The easiest and most effective way to get technical support for Avaya products is from the Avaya Technical Support Web site at www.avaya.com/support.

Chapter 2: About this guide

In this chapter

[Maintenance and diagnostics overview](#) on page 13

Maintenance and diagnostics overview

The maintenance and diagnostic activities discussed in this guide are divided into two groups of activities:

- troubleshooting and diagnostics (identifying the cause of and resolving system problems)
- hardware maintenance

This guide is for administrators, technicians, and engineers responsible for maintaining an Avaya CallPilot® server. This guide assumes that you have basic computing skills, and are familiar with necessary safety procedures. If you are not able to resolve your problem with the resources described in this guide, you can also refer to the following document:

Troubleshooting Guide (NN44200-700)

 **Note:**

Avaya continually updates the Troubleshooting Guide. You can obtain the latest version from www.avaya.com/support.

The Installation and Configuration Task List (NN44200-306) explains how to restart, shut down, and power up the Avaya CallPilot server. When you purchased your CallPilot server, it came preinstalled with the operating system and CallPilot server software. If your CallPilot server no longer functions because of a software problem, you may need to reinstall the CallPilot software or rebuild the system.

Replacement parts

Before replacing any parts on your server, refer to the Avaya product catalog for the part codes.



Caution:

Risk of system damage

The use of parts that are not supplied by Avaya can cause serious system problems or void your Avaya warranty.

Preparing for maintenance activities

Before you proceed with hardware maintenance activities, review the Installation and Configuration Task List (NN44200-306) and the 703t Server Hardware Installation Guide (NN44200-304) guide for the following information:

- required tools and equipment
- recommended safety precautions for electrostatic discharge, handling cards, and handling your server
- instructions for shutting down your 703t server or for taking it out of service

Customer Documentation Map

The following diagram shows the overall organization and content of the CallPilot documentation suite.

Table 1: CallPilot Customer Documentation Map

Fundamentals
Avaya CallPilot® Fundamentals Guide (NN44200-100)
Avaya CallPilot® Library Listing (NN44200-117)
Planning and Engineering
Avaya CallPilot® Planning and Engineering Guide (NN44200-200)
Avaya CallPilot® Network Planning Guide (NN44200-201)
Avaya Communication Server 1000 Converging the Data Network with VoIP Fundamentals (NN43001-260)
Solution Integration Guide for Avaya Communication Server 1000/CallPilot®/NES Contact Center/Telephony Manager (NN49000-300)
Installation and Configuration
Avaya CallPilot® Upgrade and Platform Migration Guide (NN44200-400)

Avaya CallPilot® High Availability: Installation and Configuration (NN44200-311)

Avaya CallPilot® Geographic Redundancy Application Guide (NN44200-322)

Avaya CallPilot® Installation and Configuration Task List Guide (NN44200-306)

Avaya CallPilot® Quickstart Guide (NN44200-313)

Avaya CallPilot® Installer Roadmap (NN44200-314)

Server Installation Guides

Avaya CallPilot® 201i Server Hardware Installation Guide (NN44200-301)

Avaya CallPilot® 202i Server Hardware Installation Guide (NN44200-317)

Avaya CallPilot® 202i Installer Roadmap (NN44200-319)

Avaya CallPilot® 703t Server Hardware Installation Guide (NN44200-304)

Avaya CallPilot® 1002rp Server Hardware Installation Guide
(NN44200-300)

Avaya CallPilot® 1002rp System Evaluation (NN44200-318)

Avaya CallPilot® 1005r Server Hardware Installation Guide
(NN44200-308)

Avaya CallPilot® 1005r System Evaluation (NN44200-316)

Avaya CallPilot® 1006r Server Hardware Installation Guide
(NN44200-320)

Avaya CallPilot® 600r Server Hardware Installation Guide
(NN44200-307)

Avaya CallPilot® 600r System Evaluation (NN44200-315)

Configuration and Testing Guides

Avaya Meridian 1 and Avaya CallPilot® Server Configuration Guide
(NN44200-302)

Avaya T1/SMDI and Avaya CallPilot® Server Configuration Guide
(NN44200-303)

Avaya Communication Server 1000 System and Avaya CallPilot® Server
Configuration Guide (NN44200-312)

Unified Messaging Software Installation

Avaya CallPilot® Desktop Messaging and My CallPilot Installation and
Administration Guide (NN44200-305)

Administration

Avaya CallPilot® Administrator Guide (NN44200-601)

Avaya CallPilot® Software Administration and Maintenance Guide (NN44200-600)

Avaya Meridian Mail to Avaya CallPilot® Migration Utility Guide (NN44200-502)

Avaya CallPilot® Application Builder Guide (NN44200-102)

Avaya CallPilot® Reporter Guide (NN44200-603)

Maintenance

Avaya CallPilot® Troubleshooting Reference Guide (NN44200-700)

Avaya CallPilot® Preventative Maintenance Guide (NN44200-505)

Server Maintenance and Diagnostics

Avaya CallPilot® 201i Server Maintenance and Diagnostics Guide (NN44200-705)

Avaya CallPilot® 202i Server Maintenance and Diagnostics Guide (NN44200-708)

Avaya CallPilot® 703t Server Maintenance and Diagnostics Guide (NN44200-702)

Avaya CallPilot® 1002rp Server Maintenance and Diagnostics Guide (NN44200-701)

Avaya CallPilot® 1005r Server Maintenance and Diagnostics Guide (NN44200-704)

Avaya CallPilot® 1006r Server Maintenance and Diagnostics Guide (NN44200-709)

Avaya CallPilot® 600r Server Maintenance and Diagnostics Guide (NN44200-703)

Avaya NES Contact Center Manager Communication Server 1000/ Meridian 1 & Voice Processing Guide (297-2183-931)

End User Information

End User Cards

Avaya CallPilot® Unified Messaging Quick Reference Card (NN44200-111)

Avaya CallPilot® Unified Messaging Wallet Card (NN44200-112)

Avaya CallPilot® A-Style Command Comparison Card (NN44200-113)

Avaya CallPilot® S-Style Command Comparison Card (NN44200-114)

Avaya CallPilot® Menu Interface Quick Reference Card (NN44200-115)

Avaya CallPilot® Alternate Command Interface Quick Reference Card (NN44200-116)

Avaya CallPilot® Multimedia Messaging User Guide (NN44200-106)

Avaya CallPilot® Speech Activated Messaging User Guide (NN44200-107)

Avaya CallPilot® Desktop Messaging User Guide for Microsoft Outlook (NN44200-103)

Avaya CallPilot® Desktop Messaging User Guide for Lotus Notes
(NN44200-104)

Avaya CallPilot® Desktop Messaging User Guide for Novell Groupwise
(NN44200-105)

Avaya CallPilot® Desktop Messaging User Guide for Internet Clients
(NN44200-108)

Avaya CallPilot® Desktop Messaging User Guide for My CallPilot
(NN44200-109)

Avaya CallPilot® Voice Forms Transcriber User Guide (NN44200-110)

The Map was created to facilitate navigation through the suite by showing the main task groups and the documents contained in each category. It appears near the beginning of each guide, showing that guide's location within the suite.

About this guide

Chapter 3: Troubleshooting your Avaya CallPilot® system

In this chapter

[Overview](#) on page 19

[Interpreting front panel LEDs](#) on page 20

[Interpreting rear panel LEDs](#) on page 25

[Interpreting internal LEDs](#) on page 26

[Interpreting POST diagnostics](#) on page 28

[SCSI controller diagnostics](#) on page 30

[RAID controller diagnostics](#) on page 30

[What to do when the server fails to boot into service](#) on page 31

Overview

This section describes the startup diagnostics available on the 703t server and the methods for troubleshooting startup problems. The following topics are covered:


- Hardware LED states starting on [Interpreting front panel LEDs](#) on page 20
- Power-On Self-Test (POST) diagnostics on [Interpreting POST diagnostics](#) on page 28
- SCSI controller diagnostics on [SCSI controller diagnostics](#) on page 30
- RAID controller diagnostics [RAID controller diagnostics](#) on page 30
- What to do when the server fails to boot into service on [What to do when the server fails to boot into service](#) on page 31

Interpreting front panel LEDs

This section describes LED states visible on the 703t server front panel.

LED locations

[Figure 1: LED locations](#) on page 21 shows where the LEDs are located.



G101784

Figure 1: LED locations

The server LEDs, from top to bottom and left to right, indicate the status of the following:

- the ELAN and CLAN network interfaces
- hard drive
- power/sleep
- system

LEDs are also provided on the SCSI tape drive faceplate, floppy disk drive faceplate, and the IDE CD-ROM drive faceplate.

Network LED states

The network LEDs are green and are located as follows:

LED position	Controller name	Controller type	LAN type
Left	NIC1	10/100Base-T	ELAN
Right	NIC2	10/100/1000Base-T	CLAN

IF the network interface LED is	THEN
off	<p>a valid hardware connection with the network has not been established.</p> <p>Ensure that the Ethernet cable is connected to both the Ethernet connector on the server and the respective network hub. If the cable is connected, ensure that the cable is serviceable.</p>
on	<p>a valid hardware connection with the network has been established.</p> <p> Note: Before the 703t server can receive or transmit data, you must configure valid IP settings on the 703t server.</p>
blinking rapidly	<p>activity is occurring on the network.</p> <p> Note: This does not mean that the 703t server is actually transmitting or receiving packets.</p>

Hard drive LED states

The hard drive LED (the first LED in the row of LEDs below the power button on the 703t server front panel) is not used because the 703t server is actually equipped with two hard drives. There are no LEDs on the hard drives.

If hard drive faults occur on the 703t server, you can investigate them by reviewing events in the following:

- operating system Event Viewer (see [Viewing event logs](#) on page 36)
- Avaya CallPilot Event Browser (see [Event Browser](#) on page 60)

You can also view the status of each hard drive in the MegaRAID Client. For instructions on accessing and using this utility, see [RAID operations](#) on page 125

Power/sleep LED states

The power/sleep LED is the middle LED in the row of LEDs below the power button on the 703t server's front panel (see "Status LEDs" in the diagram on [LED locations](#) on page 20). The LED is green.

IF the power/sleep status LED is	AND	THEN
green	steady	the server is powered on.
off	not applicable	the server is powered off.

**Note:**

The Avaya CallPilot operating system does not support sleep mode on the server.

System status LED

The system status LED is the right LED in the row of LEDs below the power button on the 703t server's front panel (see "Status LEDs" in the diagram on [LED locations](#) on page 20).

**Note:**

If the status LED indicates a problem, you can learn more about the problem by using the server's event log. For more information, see [Viewing event logs](#) on page 36.

IF the system status LED is	AND	THEN
green	steady	the server is operating normally.
	blinking	the server's processor or memory is disabled.
amber	steady	<ul style="list-style-type: none"> a critical temperature or voltage fault has occurred. the CPU is not installed or is not functioning.

IF the system status LED is	AND	THEN
	blinking	<ul style="list-style-type: none"> • a power fault has occurred. • a fan is faulty. • a non-critical temperature or voltage fault has occurred.
	off	a fatal error occurred during the power-on status test (POST).

Tape drive LED states

The 703t server is equipped with an SLR60 tape drive. Three LEDs are located on the drive's front panel. They are referred to as left, center, and right in the following table:

Table 2: SLR60 LEDs

Left - Ready Green	Center - Activity Green	Right - Error Amber	Description
On	On	On	LED test (2 seconds at power on) is running.
Blinking	Off	Off	<ul style="list-style-type: none"> • Power-up self-test is running. • Diagnostic cartridge activity is running.
Off	Off	Off	<ul style="list-style-type: none"> • Cartridge is not inserted • Tape is not loaded
On	Off	Off	<ul style="list-style-type: none"> • Cartridge is not inserted • Tape is loaded but is not moving
On	Blinking	Off	<ul style="list-style-type: none"> • Tape is loaded and moving • Tape is loading or unloading • Cartridge is ejecting
Off	Off	On	<ul style="list-style-type: none"> • Cleaning is required • Cartridge/tape is not loaded
On	Off	On	<ul style="list-style-type: none"> • Cleaning is required • Tape is loaded but not moving

Left - Ready Green	Center - Activity Green	Right - Error Amber	Description
On	Blinking	On	<ul style="list-style-type: none"> • Cleaning is required • Tape is loaded and moving • Tape is loading or unloading • Cartridge is ejecting
Off	Blinking	On	Cleaning is in progress
Off	Off	Blinking	<ul style="list-style-type: none"> • Unrecoverable tape drive failure has occurred. • Cartridge has failed • Microcode download failure has occurred

**Note:**

If the LED states indicate an error, contact your Avaya technical support representative.

CD-ROM drive LED states

The CD-ROM drive's status LED is located on the drive's front panel. Refer to the following table when interpreting the CD-ROM drive's status:

IF the CD-ROM drive LED is	THEN
off	the CD-ROM drive is idle.
on	the CD-ROM drive is being accessed.

Interpreting rear panel LEDs

This section describes LED states visible at the back of the 703t server.

MPB96 DS30 connection link LED states

Refer to [Slot definition and numbering](#) on page 176 for the slot position of the MPB96 boards in your server.

[Figure 26: MPB96 board](#) on page 142 shows the location of three green LEDs on the MPB96 card bracket.

When	THEN
all three are On	the cables are connected properly.
one or more are Off	<ul style="list-style-type: none">• there is no connection to the switch.• the connection to the switch is intermittent.• the DS30 clock signal coming from the MGate card (NTRB18CA) is not working correctly. You should: <ul style="list-style-type: none">• check each of the three individual branches of the DS30 cable for faults, or replace the cable.• check for a faulty MGate card (NTRB18CA) in the switch.

Blue LED

The blue LED in the back of the 703t system is not used in CallPilot. It comes on for only a moment during a server reboot.

Interpreting internal LEDs

This section describes LED states visible inside of the 703t server cabinet.

MPB96 LED states

There are three LEDs on the top of the MPB96 board. They are visible even from outside the server cabinet, through the rear grill.

PCI FPGA Done LED (closest to the I/O card bracket)

This LED should go ON at power up and then OFF right away. This LED activity indicates that the board is working properly and was correctly detected by the system.

If the LED stays ON after power up, the card is faulty, and you must replace the board.

DSP FPGA Done LED

This LED comes on at power up and stays ON until the CallPilot drivers are loaded just before the diagnostic screen starts.

If this LED stays ON after the system has booted in the operating system and the CallPilot diagnostic screen has started, either the board is faulty or there is a problem with the CallPilot DSP and Windows Bus drivers.

CTbus FPGA Done LED (furthest from the I/O card bracket)

This LED works in tandem with the "DSP FPGA Done" LED, and should go on and off at the same times.

RAID controller LED states

Refer to [Slot definition and numbering](#) on page 176 for the slot position of the RAID boards in your server.

There is one red LED and a row of eight small LEDs at the back of the RAID board.

To check if RAID board is working properly

1. The red LED comes on briefly at power up, then goes off. This indicates that the card was accessed for detection successfully.

At the same time, all eight LEDs at the back will light.

2. Four of the eight LEDs will then go off and stay that way.

There are four LEDs lit when the RAID card is working properly.

If all eight LEDs stay on after power up and boot, the card was not detected or is faulty.

Interpreting POST diagnostics

The Power-On-Self-Test (POST) is a system diagnostic program (stored in the BIOS) that runs each time the 703t server is started. The function of POST is to test system components and then to display status messages.

POST reports on the system status using POST beep codes. If an error occurs before video initialization, POST emits beep codes that indicate errors in hardware, software, or firmware.

A beep code is a series of separate tones, each equal in length. Record the beep codes that you hear before calling your Avaya customer support representative.



Important:

Some POST beep codes are critical and require you to replace your motherboard. Refer to the tables in this section for more information about beep codes.

Types of beep codes

There are three types of beep codes on the 703t server:

- BIOS recovery beep codes (during a BIOS recovery procedure)
- bootblock error beep codes (for normal operation)
- bootblock error 3-beep codes (for normal operation)

Table 3: BIOS recovery beep codes

Beeps	Error message	Description
1	Recovery started	Recovery process started.
2	Recovery boot error	Unable to boot from floppy disk drive or CD-ROM drive. Recovery process will retry.
Series of low-pitched single beeps	Recovery failed	Unable to process valid BIOS recovery images. BIOS has already passed control to the operating system and flash utility.

Beeps	Error message	Description
2 long high-pitched beeps	Recovery complete	BIOS recovery succeeded. Ready for power-down or restart.
3	Recovery failed	Recovery failed. Disk is not bootable or the disk is not inserted.

Table 4: Bootblock error beep codes

Number of beeps	Error message	Error message and conditions
1	Refresh Timer Failure	The memory refresh circuitry on the motherboard is faulty.
2	Parity Error	Parity cannot be reset.
3	Boot Block Failure	See Table 5: Bootblock error 3-beep codes on page 29.
4	System Timer	System timer not operational.
5	Processor Failure	Processor is faulty.
6	Keyboard Gate A20 Failure	Keyboard may be bad.
7	Processor Exception Int error	Processor generated an exception interrupt.
8	Display Memory Read/Write Error	Video adapter is missing or faulty. This is not a fatal error.
9	ROM checksum error	BIOS checksum error has occurred.
10	Shutdown register error	Shutdown register read/write error has occurred.
11	Invalid BIOS	General BIOS error has occurred.

Table 5: Bootblock error 3-beep codes

Number of beeps	POST code	Expansion card/controller
3	00h	No memory was found in the system.
3	01h	Memory of mixed types was detected.
3	02h	EDO is not supported.
3	03h	First row memory test has failed.
3	04h	Mismatched DIMMs are in a row.
3	05h	Base memory test failed

Number of beeps	POST code	Expansion card/controller
3	06h	Decompressing post module failed.
3	07-0Dh	Generic memory error has occurred.
3	0Eh	SMBus protocol error has occurred.
3	0Fh	Generic memory error has occurred.
3	DDh	CPU microcode cannot be found for processor in slot 0.
3	EEh	CPU microcode cannot be found for processor in slot 1.

SCSI controller diagnostics

BIOS initialization

Most information about SCSI is displayed as part of the BIOS initialization screen.

During BIOS initialization, check to make sure that the tape drive is listed correctly. If the tape drive is not listed correctly:

- Ensure that internal cable connections are made properly.
- Check that tape drive settings are correct.
- Check tape drive termination.

For more information refer to:

- [SCSI and IDE drive cabling](#) on page 105
- [Replacing the tape drive](#) on page 113

RAID controller diagnostics

Most diagnostic information about RAID is available through beep warnings and status LEDs when the server is rebooting.

For more information refer to:

- [Hard drive LED states](#) on page 22
- [RAID controller LED states](#) on page 27
- [When the 703t server does not boot and makes audible beeps](#) on page 32
- [When the 703t server boots to the operating system and makes audible beeps](#) on page 33

What to do when the server fails to boot into service

The following sections suggest tasks you can perform to determine why the 703t server fails the bootup cycle.

To investigate server boot problems

1. Ensure that you accurately record any diagnostic codes and error messages that occur.
2. Try restarting the server by pressing the power button on the server.
3. During the boot sequence, view the diagnostic codes on the monitor for failures.

 **Note:**

Allow 5 minutes for the boot cycle to complete.

4. If errors indicate a hardware problem with a failure to boot to the operating system or if the server boots to the operating system, but fails to boot into CallPilot, refer to the CallPilot Troubleshooting Guide
5. If you still cannot find the cause of the boot failure after performing the tasks described in the following sections, call your Avaya technical support representative.

When the 703t server does not boot and there are no audible beeps

To check why server fans are not turning when server does not boot

1. Ensure that the power cord is properly connected into an electrical outlet.
2. If the problem continues, ensure that there is power to the electrical outlet.

To check why server does not boot with fans turning

1. Ensure that the monitor is turned on.
2. If the problem continues, ensure that the internal power supply to the boards is connected correctly.

When the 703t server does not boot and the system board LED is red

If the right-most status LED on the front of the 703t server is red, this is usually due to failure of the Board Management Controller.

The most likely cause is changing boards without completely powering down the 703t server and disconnecting the power cable.

To check why server does not boot and system board LED is red

1. Shut down the 703t server
2. Disconnect the power cable.
3. Wait 1 minute.
4. Reconnect the power cable and attempt to restart the 703t server.
5. If the problem continues, contact your Avaya technical support representative for assistance.

When the 703t server does not boot and makes audible beeps

If beeps are short

If the beeps are short in length, they are from the system board.

Typically, you will not see any video displayed on the monitor, and the right-most status LED on the front of the 703t server will show a blinking or steady amber.

To check why server does not boot and makes beeps

1. Make a note of the number of beeps and any error messages or POST codes.
2. Refer to [Table 4: Bootblock error beep codes](#) on page 29 and [Table 5: Bootblock error 3-beep codes](#) on page 29, and use the collected information to identify the cause of the failure.
3. Replace any component that is indicated as faulty.

If beeps are long

If the beeps are a series of high-pitched, long beeps, they are from the RAID system.

Typically, you will see messages displayed on the monitor indicating that the system is in a critical state.

1. Ensure that internal hard drive cables are properly connected.
2. If the problem continues, RAID BIOS may be corrupted.
3. If the problem continues, the drive is faulty. Replace the hard drive as described in [Replacing a faulty hard drive](#) on page 106.

When the 703t server boots to the operating system and makes audible beeps

If the 703t server boots to the operating system but still makes audible beeps, one of the hard drives is in critical condition.

To check if server has a hard drive in critical condition

Rebuild the hard drive as soon as the operating system has finished loading. Refer to [RAID splitting](#) on page 132.

When the 703t server boots to the operating system but does not boot to CallPilot

If the 703t server does not boot to CallPilot, it may be due to the failure of a multimedia board.

To check if multimedia board has failed

1. Check the diagnostic screen that is displayed immediately after you reboot the system, and view the event logs. For instructions, see [Viewing event logs](#) on page 36.
2. If the diagnostic or event log information indicates failure of a multimedia board, replace the card as described in [Replacing MPB96 boards](#) on page 142.
3. If the diagnostic or event log information does not indicate failure of a multimedia board, a software failure is the likely cause.

Refer to the Software Administration and Maintenance Guide (NN44200-600) for instructions on how to reinstall software.

Chapter 4: Using Windows online diagnostic tools

In this chapter

[Overview](#) on page 35

[Viewing event logs](#) on page 36

[Using TCP/IP diagnostic tools](#) on page 39

[Using the chkdsk utility](#) on page 47

Overview

This section describes how to access the runtime online diagnostic tools provided by the Windows server software. Use these tools when a serious problem prevents the use of the Avaya CallPilot® diagnostic tools that are available in CallPilot Manager.



Caution:

Risk of software corruption

Do not run any utilities that are not documented in this guide.

Operating system Event Viewer

The operating system Event Viewer provides event logs to help you diagnose and debug system problems.

TCP/IP diagnostics

The following TCP/IP diagnostic tools are described in this chapter:

- ipconfig on [The ipconfig command](#) on page 40
- ping on [The ping command](#) on page 41
- tracert on [The tracert command](#) on page 42
- arp on [The arp command](#) on page 43
- nbtstat on [The nbtstat command](#) on page 45
- netstat on [The netstat command](#) on page 46

These utilities help you to verify network connectivity. They help you to thoroughly test the network interface and isolate any configuration problems. Network connectivity is essential to CallPilot operation.

chkdsk utility

The chkdsk utility checks a specified disk on the server and displays a status report. It is an online utility, but it reduces system performance while it is running.

Viewing event logs

When the server startup cycle is complete, and if the CallPilot server has been configured (refer to the Installation and Configuration Task List (NN44200-306), messages in dialog boxes on the monitor indicate that CallPilot is ready to accept calls.

If one or more messages appears on the monitor, the message may contain information about an event, or a fault may have occurred. To determine what happened, you can use the following:

- operating system Event Viewer on the 703t server
- CallPilot Event Browser or Alarm Monitor in CallPilot Manager

 **Note:**

The Event Browser and Alarm Monitor include online Help for events, which may help you to resolve the problem. If you cannot log on to the CallPilot system using a web browser due to server problems, then use the Event Viewer.

Types of event logs

Three types of event logs are available from the Event Viewer, as follows:

Log type	Description
System	Logs events by Windows components, including RRAS or other Windows services.
Security	Logs security events, such as logons, logoffs and illegal access. This option is available only to users with Administrative access.
Applications	Logs events by application, such as database file errors.

To use the operating system Event Viewer

1. Click Start → Programs → Administrative Tools → Event Viewer.

Result: The Event Viewer window appears.




Figure 2: Event viewer window

2. To view a log, click the name of the log in the left frame of the window.




Figure 3: Application Log.




Figure 4: System log.



Note:

The Security log available only to administrators is not shown.

3. Look for error codes flagged with either of the following icons that have occurred since the last startup.



 **Note:**

Each error is date and time stamped.



Indicates major or critical errors



Indicates minor errors



Indicates information

- To determine the cause of the error, select and then double-click the error.

Result: A description of the error appears in an Event detail dialog box. Use the description to help determine how to resolve errors.

 **Note:**

If the error persists or does not suggest a solution, contact your Avaya support representative.

- Click OK.

Result: The event log reappears.

- Click File → Exit.

Result: The Event Viewer closes.

Using TCP/IP diagnostic tools

This section describes the following TCP/IP diagnostic tools available for the network adapter:

- ipconfig
- ping
- tracert
- arp
- nbtstat
- netstat

These utilities help you to verify network connectivity, test the network interface, and isolate configuration problems.

The ipconfig command

The ipconfig command displays IP configuration information.

Ipconfig default

If you run the command without flags, it displays the IP address, subnet mask, and default gateway for each adapter bound to TCP/IP.

Ipconfig command syntax

```
ipconfig [/ ]
```

The following flags are available for the ipconfig command:

Flag	Description
<i>/?</i>	Displays Help information.
<i>/all</i>	Displays full configuration information.
<i>/release</i>	Releases the IP address for the specified adapter.
<i>/renew</i>	Renews the IP address for the specified adapter.

To run the ipconfig command from Windows

1. Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
2. At the Command prompt, type ipconfig <with appropriate parameters>.
Example: ipconfig /all
3. Press Enter.
Result: The system runs the ipconfig utility.
4. Type Exit to exit the Command Prompt window and return to Windows.

The ping command

The ping command sends an echo request to a specified host. Use this command to verify network connectivity to the remote device.

Ping command syntax

The ping command uses the following syntax:

```
ping [-t] [-a] [-n count] [-l size] [-f] [-i TTL] [-v TOS] [-r count]
[-s count] [[-j host-list] | [-k host-list]] [-w timeout]
destination-list
```

Table 6: Ping command parameters

Parameter	Description
-t	Pings the specified host until interrupted.
-a	Resolves addresses to host names.
-n count	Specifies the number of echo requests to send.
-l size	Sends buffer size.
-f	Sets Don't Fragment flag in packet.
-i TTL	Sets Time-To-Live
-v TOS	Sets Type Of Service
-r count	Records route for count hops
-s count	Shows time stamp for count hops
-j host-list	Shows loose source route along host list
-k host-list	Shows strict source route along host list
-w timeout	Sets time-out in milliseconds to wait for each reply

To run the ping command from Windows

1. Click Start → Programs → Accessories → Command Prompt.

Result: The Command Prompt window appears.

2. At the Command prompt, type ping <destination IP address> (for example, ping 200.286.32.0), or ping <computer name>.
3. Press Enter.

Result: The system displays the ping results.

4. Type Exit to exit the Command Prompt window and return to Windows.

The tracert command

This utility determines the route taken to a destination.

How tracert works

The tracert utility follows several steps to complete its task:

- Tracert sends Internet Control Message Protocol (ICMP) echo packets with varying Time-To-Live (TTL) values to the destination.
- Each router along the path must decrement the TTL on a packet by at least one before forwarding it, so the TTL is effectively a hop count.
- When the TTL on a packet reaches zero, the router sends back an ICMP Time Exceeded message to the source system.
- Tracert determines the route by sending the first echo packet with a TTL of one, and incrementing the TTL by one on each subsequent transmission until the target responds, or the maximum TTL is reached.
- Tracert then examines the ICMP Time Exceeded messages sent back by intermediate routers.

Tracert syntax

The tracert command uses the following syntax:

```
tracert [-d] [-h maximum_hops] [-j host_list] [-w timeout]
target_name
```

Table 7: Tracert parameters

Parameter	Description
-d	Specifies not to resolve addresses to hostnames.
-h maximum_hops	Specifies the maximum number of hops to search for the target.
-j host-list	Specifies a loose source route along the host list.
-w timeout	Waits the number of milliseconds specified by the time-out for each reply.
target_name	Shows the name of the target host.

To run the tracert command from Windows

1. Click Start → Programs → Accessories → Command Prompt.

Result: The Command Prompt window appears.

2. At the Command prompt, type the following command:

```
tracert [-d] [-h maximum_hops] [-j host_list] [-w timeout]
[target_name]
```

Example: tracert 200.286.0.32

3. Press Enter.

Result: The system runs the tracert utility.

4. Type Exit to exit the Command Prompt window and return to Windows.

The arp command

The arp command displays and modifies the IP-to-physical address translation tables used by Address Resolution Protocol (arp).

Arp command syntax

The arp command uses the following syntax:

```
arp -s inet_addr eth_addr [if_addr]
```

```
arp -d inet_addr [if_addr]  
arp -a [inet_addr] [-N if_addr]
```

Table 8: Arp parameters

Parameter	Description
-a	Displays current arp entries by interrogating the current protocol data. If inet_addr is specified, the IP and physical addresses for only the specified computer appear. If more than one network interface uses arp, entries for each arp table appear.
-g	Same as -a.
inet_addr	Specifies an Internet address.
if_addr	Specifies the Internet address of the interface whose address translation table should be modified. If not present, the first applicable interface is used.
eth_addr	Specifies a physical address.
-N if_addr	Displays the arp entries for the network interface specified by if_addr.
-d	Deletes the host specified by inet_addr.
-s	Adds the host and associates the Internet address inet_addr with the Physical address eth_addr. The physical address is given as six hexadecimal bytes separated by hyphens. The entry is permanent.

To run the arp command from Windows

1. Click Start → Programs → Accessories → Command Prompt.

Result: The Command Prompt window appears.

2. At the Command prompt, type arp with the required parameters (for example, arp -g 200.286.0.32).
3. Press Enter.

Result: The system runs the arp command.

Type Exit to exit the Command Prompt window and return to Windows.

The nbtstat command

The nbtstat command displays protocol statistics and current TCP/IP connections using NBT.

Nbtstat command syntax

The nbtstat command uses the following syntax:

```
nbtstat [-a remotename] [-A IP address] [-c] [-n] [-R] [-r] [-S] [-s]
[interval]
```

Table 9: Nbtstat parameters

Parameter	Description
-a remotename	Lists the remote computer's name table using its name.
-A IP address	Lists the remote computer's name table using its IP address.
-c	Lists the contents of the NetBIOS name cache giving the IP address of each name.
-n	Lists local NetBIOS names. Registered indicates that the name is registered by broadcast (Bnode) or WINS (other node types).
-R	Reloads the LMHOSTS file after purging all names from the NetBIOS name cache.
-r	Lists name resolution statistics for Windows networking name resolution. On a Windows computer configured to use WINS, this option returns the number of names resolved and registered through broadcast or through WINS.
-S	Displays both client and server sessions, listing the remote hosts by IP address only.
-s	Displays both client and server sessions, and attempts to convert the remote host IP address to a name using the HOSTS file.
interval	Displays selected statistics, pausing interval seconds between each display. Press Ctrl+C to stop displaying statistics. Without this parameter, nbtstat prints the current configuration information once.

To run the nbtstat command from Windows

1. Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
2. At the Command prompt, type nbtstat with the required parameters.
3. Press Enter.
Result: The system runs the nbtstat utility.
Type Exit to exit the Command Prompt window and return to Windows.

The netstat command

The netstat command displays current TCP/IP network connections and protocol statistics.

Netstat command syntax

The netstat command uses the following syntax:

```
netstat [-a] [-e] [-n] [-s] [-p proto] [-r] [interval]
```

Table 10: Netstat parameters

Parameter	Description
-a	Displays all connections and listening ports.
-e	Displays Ethernet statistics. This can be combined with the -s option.
-n	Displays addresses and port numbers in numerical form.
-s	Displays per-protocol statistics.
-p proto	Shows connections for the protocol specified by proto. Proto can be tcp or udp. If used with the -s option, proto can be tcp, udp, or ip.
-r	Displays the contents of the routing table.
interval	Redisplays selected statistics, pausing between each display. Press Ctrl+C to stop redisplaying.

To run the netstat command from Windows

1. Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
2. At the Command prompt, type netstat with the required parameters.
3. Press Enter.
Result: The system runs the netstat utility.
4. Type Exit to exit the Command Prompt window and return to Windows.

Using the chkdsk utility

The chkdsk utility checks a specified disk on the server and displays a status report. It can be run on drives C, D, E, or F. It is an online utility, but it reduces system performance while it is running.

The chkdsk utility checks for problems at the Windows file system level. Any problems existing at this level can cause problems for CallPilot. Even if there are no problems at the Windows file system level, CallPilot can still be affected by problems at the CallPilot file system level.

 **Note:**

A version of this utility, called autocheck, automatically runs during Windows startup. Output from this utility appears on the blue startup screen.

Chkdsk utility syntax

The chkdsk utility uses the following syntax:

```
chkdsk [drive:][path]filename [/F] [/V] [/R]
```

Table 11: Chkdsk parameters

Parameter	Description
drive:	Enter the drive letter of the drive that you want to check.
filename	Enter the names of files to check for fragmentation.

Parameter	Description
/F	Add this parameter to fix errors on the disk.
/V	Add this parameter to display the full pathname of every file on the disk.
/R	Add this parameter to locate bad sectors and to recover readable information.

To run the chkdsk utility from Windows

1. Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
2. At the Command prompt, type chkdsk <drive letter:> (for example, chkdsk c:).
3. Press Enter.
Result: The system runs the chkdsk utility.
4. Type Exit to exit the Command Prompt window and return to Windows.

Chapter 5: Using serial port diagnostic tools

In this chapter

[Overview](#) on page 49

[Shutting down services](#) on page 49

[Conducting TSTSERIO tests](#) on page 51

[Conducting TSTSERIO tests with the loopback plug](#) on page 53

[Restarting services](#) on page 54

Overview

You may want to test the serial ports when remote access does not work.

This chapter describes how to run serial port diagnostics on the Avaya CallPilot® server using the TSTSERIO command. Direct the TSTSERIO command to serial ports on the server after services on these ports have been shut down manually, as described in this chapter.

Shutting down services

This section describes how to shut down a service using a specific serial port. Use the following procedures before invoking the TSTSERIO local loopback tests.

 **Caution:**

Risk of communications loss

By stopping the services on COM 1 or COM 2, you lose the support access feature.

 **Caution:**

Risk of stopping call processing

By stopping the services on COM 2, you stop call processing on Avaya CallPilot.

Service to stop for COM 1 testing

Services to stop for COM 2 testing

- CallPilot SLEE Service
- CallPilot MWI Service
- CallPilot Access Protocol Emulator
- CallPilot Blue Call Router
- CallPilot Call Channel Router
- CallPilot Time Service
- Routing and Remote Access

Net Stop command

Use the Net Stop command to stop a specified service on a serial port.

Net Stop command syntax

The Net Stop command uses the following syntax:

```
net stop "service_name"
```



Important:

You must restart the services that you shut down through the Net Start command after running the diagnostic. For details, see [Restarting services](#) on page 54.

To invoke the Net Stop command from Windows

1. Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
2. At the Command prompt, type net stop "service_name", and then press Enter.

 **Note:**

The quotation marks are required, as in the example above.

Result: The system runs the Net Stop command utility.

3. Type Exit, and then press Enter to exit the Command Prompt window.

Conducting TSTSERIO tests

The TSTSERIO command performs local loopback tests of the serial communication ports from the server runtime environment.

 **Note:**

Before conducting these tests, shut down the appropriate services. See [Shutting down services](#) on page 49.

 **Caution:**

Risk of communications loss

By stopping the services on COM 1 or COM 2, you lose the support access feature.

 **Caution:**

Risk of stopping call processing

By stopping the services on COM 2, you stop call processing on CallPilot.

TSTSERIO command syntax

The syntax for the TSTSERIO command is as follows:

```
TSTSERIO [/?] /P:comport [/S:substname] [/L:loops]
```

Flag	Requirement	Description
?	n/a	Displays Help.
/P:comport	Required	Specifies the symbolic port name assigned to the port you want to test.
/S:substname	Optional	Specifies a TSTSERIO subtest. See the table below for a description of the available subtests.
/L:loops	Optional	Specifies the number of times (up to a maximum of 65 535) to execute the requested test. The default number of tests is 1. A value of 0 infinitely loops until you enter Ctrl+C.

TSTSERIO internal loopback diagnostic subtests

The following internal loopback subtests are available for the TSTSERIO command. For each of these tests, the communications resource must be available:

Subtest name	Description
idat	Internal data bus loopback
imsr	Internal modem status register
baud	Internal data bus loopback at various baud rates
word	Test 5-, 6-, 7-, and 8-bit data lengths
stop	Test 1, 1.5, and 2 stop bits
pari	Test odd/even parity
fifo	Test that device can operate in fifo mode

To invoke the TSTSERIO /P command from Windows

1. Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
2. At the Command prompt, type `tstserio` with the required parameters, and then press Enter.

For example, type TSTSERIO /P com1 or TSTSERIO /P com 2, and then press Enter.

3. Type Exit, and then press Enter to exit the Command Prompt window.

TSTSERIO external loopback plug subtests

The following external loopback subtests are available for the TSTSERIO command. For each of these tests, an external loopback connector must be used. For more information, see [Conducting TSTSERIO tests with the loopback plug](#) on page 53.

Subtest name	Description
edat	External data bus loopback. This test requires an external loopback connector.
emsr	External modem status register. This test requires an external loopback connector.
eint	Test ability of device to generate interrupts. This test requires an external loopback connector.

To invoke the TSTSERIO /S command from Windows

1. Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
2. At the Command prompt, type tstserio with the required parameters, and then press Enter.
For example, type TSTSERIO /P com1 /S extr, and then press Enter.
3. Type Exit, and then press Enter to exit the Command Prompt window.

Conducting TSTSERIO tests with the loopback plug

The TSTSERIO command requires an external loopback connector plug for its edata, emsr, and eint subtests.

9-pin connector plug

The standard serial loopback connector is a female 9-pin D-sub connector. This connector has the following pins wired together:

- CTS (pin 8) wired to (pin 7) RTS
- SIN (pin 2) wired to (pin 3) SOUT
- DTR (pin 4) wired to (pin 6) DSR

Once the plug is installed on the serial port, TSTSERIO can be invoked according to the [To invoke the TSTSERIO /P command from Windows](#) on page 52.

Restarting services

This section describes how to restart the services for COM 1 or COM 2 after invoking the TSTSERIO local loopback tests.

Service to restart after COM 1 testing

Services to restart after COM 2 testing

- CallPilot SLEE Service
- CallPilot MWI Service
- CallPilot Access Protocol Emulator
- CallPilot Blue Call Router
- CallPilot Call Channel Router
- CallPilot Time Service
- Routing and Remote Access

Net Start command

Use the Net Start command to restart a specified service on a serial port. The syntax for the Net Start command is as follows:

```
net start "[service-name]"
```

To invoke the Net Start command from Windows

1. Click Start → Programs → Accessories → Command Prompt.
Result: The Command Prompt window appears.
2. At the Command prompt, type net start "service_name", and then press Enter.

 **Note:**

The quotation marks are required, as in the example above.

3. Type Exit, and then press Enter to exit the Command Prompt window.

Chapter 6: Using CallPilot Manager to monitor hardware

In this chapter

[Understanding fault management](#) on page 57

[Alarm Monitor](#) on page 59

[Event Browser](#) on page 60

[Channel and Multimedia Monitors](#) on page 61

[The Maintenance page](#) on page 62

[Viewing component states](#) on page 64

[Starting and stopping components](#) on page 66

[Running integrated diagnostics](#) on page 68

[Viewing the last diagnostic results](#) on page 71

[Working with the Multimedia Monitor](#) on page 72

[Working with the Channel Monitor](#) on page 73

Understanding fault management

Fault management is a term that describes how the Avaya CallPilot® server detects and notifies you of potential or real hardware problems (faults). The server processes events to detect hardware problems and raises alarms to notify you when these problems occur.

Event processing

An event is any change in system configuration or operational state. An event is also any action taken by the system that requires user notification. Events can be as insignificant as a user logon attempt or as serious as a faulty MPB switching to disabled status.

All events are reported to the fault management server, a subsystem within the CallPilot server. The fault management server enables the server to listen and respond to its clients. The interaction is called event processing and is the means by which the server detects hardware faults.

Alarm notification

Alarms are warnings generated by events. Alarms communicate the same information as events. However, alarms are reported in the Alarm Monitor instead of the Event Browser, and are managed differently than events.

When an alarm appears in the Alarm Monitor, you must investigate the problem, isolate it, and then fix the cause of the problem. When you fix the problem, ensure that the alarm is cleared from the Alarm Monitor.

 **Note:**

You may be required to clear the alarm manually.

Component dependencies

The status of some components is dependent on the operational status of other components. If a component fails or is stopped, the dependent components go out of service.

 **Note:**

Based on the CallPilot server type, and the type of switch connected to CallPilot, some of these components may not appear on your system.

Component	Dependent components
Media Bus	All MPBs and all multimedia and call channels.
MPB board	All multimedia and call channels associated with the MPB board.

Component	Dependent components
Time Switch	All multimedia and call channels associated with the same MPB as the time switch.
DS30X	All DS30X channels associated with the DS30X link.

Detecting hardware problems

Typically, you first become aware of a hardware problem when an alarm is raised. All hardware faults produce an alarm (or series of alarms, depending on the problem) in the Alarm Monitor. Other indications of a hardware problem include the following:

- user complaints
- call processing difficulties, such as busy signals, static, dropped calls, connection problems, and cross talk (hearing other conversations)
- system administrator logon difficulties
- alert icons on the Maintenance screen

Alarm Monitor

Use the Alarm Monitor to investigate one or more raised alarms.

About alarms

Alarms are warnings generated by events. Alarms communicate the same information as events. However, alarms are reported in the Alarm Monitor instead of the Event Browser, and are managed differently than events:

- Alarms appear in the Alarm Monitor only for Minor, Major, and Critical events (not Information events). All events can be reported in the Event Browser (depending on filtering criteria defined in the Event Browser).
- The first time an event occurs, it generates an alarm that appears in the Alarm Monitor. If the same event continues to occur, a new alarm is not generated. Instead, the time and date assigned to the original generated alarm is updated.
- Alarms can be cleared from the Alarm Monitor, but the event that generated the alarm is not cleared from the event log or the Event Browser.

Each alarm in the Alarm Monitor has Help text that often provides a solution to the problem. If the solution is not apparent, use the Event Browser or the Maintenance screen to further investigate the problem.

To investigate using the Alarm Monitor

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click System → Alarm Monitor.
Result: The Alarm Monitor window appears.
3. Click the Event Code for the first critical or major alarm.
Result: A description of the event appears in a new web browser window.
4. Review the description and recovery action.
5. Repeat steps [3](#) on page 60 and [4](#) on page 60 for a more alarms, if necessary.
6. If the solution to the problem is not apparent, obtain the return code of the first event and continue the investigation by using the Event Browser (see [Event Browser](#) on page 60).

 **Note:**

For information on how to use the Alarm Monitor, refer to the Administrator's Guide (NN44200-601), or the CallPilot Manager online Help.

Event Browser

Use the Event Browser to investigate a series of events that occurred around the time an alarm was raised. The event listing can help you determine the root cause of a problem.

About events

The Event Browser displays events that have been recorded in the server log. Each event identifies the time the event occurred, the object that generated the event, and the cause of the event.

Events are classified as Information, Minor, Major, or Critical. By default, the Event Browser displays only the latest 100 critical events.

 **Note:**

Avaya recommends that you change the Event Browser filter criteria to display Minor and Major events as well. Minor and Major events can indicate significant system problems.

To investigate using the Event Browser

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click System → Event Browser.
Result: The Event Browser window appears
3. Click an event that appears to be related to the problem, or an event that occurred near the time the alarm was raised.
Result: A description of the event appears in a new web browser window.
4. View the description and recovery action.
5. Repeat steps [3](#) on page 61 and [4](#) on page 61 for more events, if necessary.
6. If the solution to the problem is not apparent, contact your Avaya technical support representative.

 **Note:**

For information on how to use the Event Browser, refer to the Administrator's Guide (NN44200-601), or the CallPilot Manager online Help.

Channel and Multimedia Monitors

The Channel Monitor shows the status of call channels. The call channels are the connections between the server and the switch that carry the call signals to CallPilot.

The Multimedia Monitor shows the status of multimedia channels. The multimedia channels are the DSP ports that process the calls. They are the voice, fax, and speech recognition channels.

Disabling call channels

If you must take the CallPilot system out of service to perform software or hardware maintenance, Avaya recommends that you disable all call channels first. There are two ways to disable the call channels:

- Courtesy stop the channels (preferred method).

When you courtesy stop call channels, CallPilot waits until the channels are no longer active before disabling them, instead of suddenly terminating active calls.

- Stop the channels.

When you stop channels, you suddenly disable them and terminate all active calls.

The Maintenance page

Use the Maintenance page in CallPilot Manager to do the following:

- Obtain general information about components.
- View component states.
- Start and stop components.
- Run integrated diagnostic tests.
- View the results of the last diagnostic test run against a component.

What the Maintenance page provides

The Maintenance page identifies the server platform and switch connectivity type. It also provides a tree that, when expanded, lists the physical and logical hardware components down the left side of the screen. To list the server hardware components, click the plus sign (+) at the top of the tree. To list the subcomponents for each component, click the plus sign (+) beside the component.

 **Note:**

The components that are listed on the Maintenance page are based on the CallPilot server type and the switch that is connected to CallPilot.

When you click a component, the page refreshes to show the details about that component.

Table 12: Maintenance page section details

Section	Description
General	<p>This section shows general technical information about the selected component. This typically includes the following details:</p> <ul style="list-style-type: none"> • the name, class, type, series, or version of a CallPilot server • various capabilities of a component (for example, whether a component is removable) <p> Note: This section does not appear for all components.</p>
Maintenance	<p>This section shows the state of the selected component. Use this section to start and stop a component before running a diagnostic test.</p> <p>This section appears only for components on which you are allowed to perform maintenance administration. For more information about working with component states, see the following sections:</p> <ul style="list-style-type: none"> • Viewing component states on page 64 • Starting and stopping components on page 66
Diagnostics	<p>Use the Diagnostics section to run one or more diagnostic tests, or to view the results of the last diagnostic tests that were run on the selected component.</p> <p>This section appears only for components on which you are allowed to run diagnostics. For more information about running diagnostics, see the following sections:</p> <ul style="list-style-type: none"> • Running integrated diagnostics on page 68 • Viewing the last diagnostic results on page 71

Maintenance activities for each component

[Table 13: Maintenance activities](#) on page 63 identifies the maintenance activities you can perform for each component listed in the component tree.

Table 13: Maintenance activities

Component	Start, stop?	Courtesy stop?	Diagnostics available?	Replaceable ?
Media Bus	Yes	No	No	No
MPB board	Yes	No	Yes	Yes

Component	Start, stop?	Courtesy stop?	Diagnostics available?	Replaceable ?
Time Switch	No	No	No	No
Multimedia channels	Yes	Yes	No	No
Call channels	Yes	Yes	No	No
DS30X link	Yes	No	No	No



Note:

The MGate card and DS30X cable are replaceable. If you are having problems with the DS30X link, determine if either one or both of those items are causing the problem and need to be replaced.

Viewing component states

View a component state to determine the general condition of the component, including whether the component is disabled or off duty. The component state is shown in the Maintenance section of the Maintenance screen.

Component states

You can determine the state of a component by looking at the State box in the Maintenance section.

State	Description
Active	The component is working and currently involved in processing a call.
Disabled	The diagnostic failed.
Idle	The component is working but not currently involved in processing a call.
InTest	A diagnostic is running on the component.
Loading	The component has been started, which takes it out of the Off Duty state. This state occurs quickly and is immediately followed by Idle.
No resources	The hardware required for the component to operate is not installed or is not operating properly.

State	Description
Not Configured	The component is not configured in CallPilot. For example, a multimedia channel is not being used because it was not allocated in the Configuration Wizard.
Off Duty	The component has been stopped.
Remote Off Duty	The component has been taken out of service at the switch.
Shutting Down	The component is in the process of stopping. This state occurs quickly and is immediately followed by Off Duty.
Uninitialized	The call processing component has not initialized the resource.

Alert icons

If one of the following icons appears next to a component in the tree, then the component or one of its subcomponents is experiencing a problem:

Icon	Description
	A problem exists with a subcomponent of the selected component. Expand the tree to locate the subcomponent with the problem.
	A problem exists with the selected component.

To view the state of a hardware component

1. Run CallPilot Manager and login.
2. In CallPilot Manager, click Maintenance → Maintenance Admin.
Result: The Maintenance screen appears.
3. Click the plus sign (+) beside the CallPilot server to expand the component tree.
4. Continue clicking the plus sign (+) until the component with which you want to work is visible.
5. Click the hardware component with which you want to work.
Result: The Maintenance screen refreshes to show details about the component.
6. Scroll down to the Maintenance section.
7. View the state of the selected component in the State box.

Starting and stopping components

When you stop a component, you take it out of service and prevent it from operating. You must stop a component before you can replace it (if the component is replaceable) or run a diagnostic test on it.

To bring an out-of-service component back into service, you must start it.

Start and stop components from the Maintenance section on the Maintenance screen.



Important:

Avaya recommends that, if possible, you courtesy stop a component. Courtesy stop is available only at the individual channel level.

To courtesy down CallPilot, use the following:

- Multimedia Monitor - to courtesy stop a range of multimedia channels
- Channel Monitor - to courtesy stop a range of call channels:
 - DS30X channels (also known as DS0 channels)

Stop versus Courtesy stop

The following two methods of taking a component out of service allow you to choose how active calls are affected:

Courtesy stop

A Courtesy stop is the recommended way to take the component out of service only after the component has finished processing an active call. Courtesy stop is preferred over a regular Stop.

- If the component is processing a call, the call is not dropped; the component remains active until the call is finished.
- If the component is not in use, it is taken out of service immediately.

Stop

A Stop takes the component out of service immediately, regardless of whether the component is currently processing calls. All active calls are dropped. Perform a Stop only when severe problems affecting a large number of incoming calls occur or if your organization determines a special need for it.

Components that can be started and stopped

The following components can be started and stopped when connected to a Meridian 1* or Avaya Communication Server 1000* switch:

 **Note:**

If you want to start or stop more than one or two multimedia or call (DS30X) channels, use the Multimedia Monitor or Channel Monitor. For instructions, see [Channel and Multimedia Monitors](#) on page 61.

Component	Effect of stopping
Media Bus	Takes all call processing resources out of service.
MPB board	Takes all call processing resources on the selected board out of service.
Time Switch	You cannot perform maintenance administration on the time switch.
Multimedia Channel	Takes the selected Multimedia Channels out of service.
DS30X link	Takes the selected DS30X link and the channels that belong to that link out of service.
Channels	Takes the selected DS30X channel out of service.

To start or stop a component

1. Run CallPilot Manager and login.
2. In CallPilot Manager, click Maintenance → Maintenance Admin.

Result: The Maintenance screen appears.

3. Click the plus sign (+) beside the CallPilot server to expand the component tree.
4. Continue clicking the plus sign (+) until the component with which you want to work is visible.
5. Click the hardware component that you want to start or stop.

Result: The Maintenance screen refreshes to show details about the component.

6. Scroll down to the Maintenance section.
7. Click Courtesy Stop, Stop, or Start as required.

Button	Description
Start	If the selected component is out of service, click this button to put it into service.
Courtesy Stop	<p>Click this button to take the selected component out of service. CallPilot waits for the call to be completed before disabling the component.</p> <p> Important: If you are courtesy stopping all components (that is, you are taking the entire system down), ensure that you inform all administrators, desktop messaging users, and web messaging users so that they can log off their sessions before you proceed. The system asks you to confirm the Courtesy stop. If you click OK, the component is put out of service after all calls are finished.</p>
Stop	<p>Click this button to take the selected component out of service immediately. All calls that are in progress are disconnected immediately.</p> <p> Important: If you are stopping all components (that is, you are taking the entire system down), ensure that you inform all administrators, desktop messaging users, and web messaging users so that they can log off their sessions before you proceed.</p>

Running integrated diagnostics

Run diagnostic tests from the Diagnostics section on the Maintenance screen in the following circumstances:

- You want to ensure that a component is operating properly after installing or reinstalling it.
- The CallPilot server has trouble processing incoming calls, and you hope that diagnostic results can tell you why.

Problems include static, dropped calls, and cross talk (hearing another conversation).

Before you begin



Important:

Take the component out of service before you run the diagnostic test. See [Starting and stopping components](#) on page 66.

Diagnostic tests available for each component

The diagnostic tests that are available for each component are listed in the Diagnostic section of the Maintenance screen. To view the list of diagnostic tests for a particular component, click the component in the component tree.

Components that have diagnostic tests available

The following table identifies the components on which you can run diagnostics when connected to a Meridian 1 switch or Communication Server 1000.

Table 14: Diagnostics tests available for components

Component	Diagnostics available?	Replaceable?
Media Bus	No	No
MPB board	Yes	Yes
Time Switch	No	No
Multimedia Channels	No	Yes (via MPB96 board)
DS30X link	No	No
Channels	No	No

If a diagnostic test fails or cannot be run

If a warning message appears, the diagnostic test cannot be run because a prerequisite condition has not been met. If a diagnostic test fails, a message appears in a new browser window (see the example on page step [9](#) on page 70).

In both cases, check the Alarm Monitor to determine the reason and the appropriate action to take.

If the Alarm Monitor and Event Browser do not provide a solution to a hardware problem, you may need to replace or service a component. If the problem is with a component that is not replaceable because it is not a physical entity (such as the Time Switch), you must either replace its parent component or contact your Avaya technical support representative, depending on the component.

To run a diagnostic test

Important:

Avaya recommends that you courtesy stop rather than stop a component if possible. For instructions, see [Starting and stopping components](#) on page 66.

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click Maintenance → Maintenance Admin.
Result: The Maintenance screen appears.
3. Click the plus sign (+) beside the CallPilot server to expand the component tree.
4. Continue clicking the plus sign (+) until the component with which you want to work is visible.
5. Click the hardware component for which you want to run diagnostics.
Result: The Maintenance screen refreshes to show details about the component.
6. Scroll down to the Maintenance section, and ensure that the component is out of service.

Note:

For instructions on taking the component out of service, see [To start or stop a component](#) on page 67.

7. Scroll down to the Diagnostics section.
8. Check the check box for each diagnostic that you want to run.

Note:

If you want to run all of the diagnostics, check the Diagnostic Description check box at the top of the list.

9. Click Run.

Result: A new web browser window opens to display the progress and results of the diagnostics. The Diagnostic Results box in the Diagnostics section displays diagnostic results when you click Get Last Result.

Viewing the last diagnostic results

You can review the results of previously run diagnostics by clicking the Get Last Results button for a component.

To view the last diagnostics result

Important:

Avaya recommends that you courtesy stop rather than stop a component if possible. For instructions, see [Starting and stopping components](#) on page 66.

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click Maintenance → Maintenance Admin.
Result: The Maintenance screen appears.
3. Click the plus sign (+) beside the CallPilot server to expand the component tree.
4. Continue clicking the plus sign (+) until the component with which you want to work is visible.
5. Click the hardware component for which you want to run diagnostics.
Result: The Maintenance screen refreshes to show details about the component.
6. Scroll down to the Diagnostics section.
7. Check the check box for each diagnostic for which you want to review results.
8. Click Get Last Result.

Result: The results appear in the Diagnostic Results box with the following information:

- diagnostic title
- diagnostic result: pass or fail
- the date and time the test was completed

Working with the Multimedia Monitor

The Multimedia Monitor shows the status of multimedia channels. The multimedia channels are the DSP ports that process the calls. They are the voice, fax, and speech recognition channels.

To view or work with multimedia channel states

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click Maintenance → Multimedia Monitor.

Result: The Multimedia Monitor screen appears, showing the channels associated with each DSP

 **Note:**

For an explanation of the channel states, refer to the CallPilot Manager online Help.

3. Do one of the following:

IF you want to stop or start	THEN
all of the channels associated with a DSP	check the check box to the left of the DSP that you want to stop or start. Repeat this step for each DSP.
only one or several channels that are associated with a DSP	check the check box for each channel that you want to stop or start.

4. Click Courtesy Stop, Stop, or Start as required.

Result: If you clicked Courtesy Stop or Stop, you are asked to confirm the Courtesy Stop or Stop. Click OK.

The selected channels change to idle or on-duty status, according to the action you chose.

If the buttons are not available, wait a few seconds for the screen to refresh:

- The Start button is available only when a component is in the Idle state.
- The Courtesy Stop and Stop buttons are available only when a component is in one of the following states: Idle, Active, Remote Alarm, Local Alarm.

Working with the Channel Monitor

The Channel Monitor shows the status of call channels. The call channels are the connections between the server and the switch that carry the call signals to CallPilot.

To view or work with call channel states

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click Maintenance → Channel Monitor.

Result: The Channel Monitor screen appears, showing the channels associated with each link.



Note:

For an explanation of the channel states, refer to the CallPilot Manager online Help.

3. Do one of the following:

IF you want to stop or start	THEN
all of the channels associated with a link	check the check box to the left of the link that you want to stop or start. Repeat this step for each link.
only one or several channels that are associated with a link	check the check box for each channel that you want to stop or start.

4. Click Courtesy Stop, Stop, or Start, as required.

Result: If you clicked Courtesy Stop or Stop, you are asked to confirm the Courtesy Stop or Stop. Click OK.

The selected channels change to idle or on-duty status, according to the action you chose.

If the buttons are not available, wait a few seconds for the screen to refresh:

- The Start button is available only when a component is in the idle state.
- The Courtesy Stop and Stop buttons are available only when a component is in one of the following states: Idle, Active, Remote Alarm, Local Alarms.

Chapter 7: Using Avaya CallPilot® system utilities

In This chapter

[Overview](#) on page 75

[Diagnostics Tool](#) on page 76

[PEP Maintenance utility](#) on page 77

[Session Trace](#) on page 78

[System Monitor](#) on page 79

Overview

Table 15: Avaya CallPilot system utilities

Utility	Description
Diagnostics Tool	Allows CallPilot startup diagnostics to be enabled or disabled (turned on or off).
PEP Maintenance	Displays a list of installed PEPs and enables PEP uninstall.
Session Trace	Provides detailed information about the activity in a user's mailbox and the state of the message waiting indicator (MWI).
System Monitor	Displays the following information: <ul style="list-style-type: none">• the status of all CallPilot channels• the status of all CallPilot services. Note that this status is more accurate than the status that Windows provides in the Services control panel.• particulars about the CallPilot 5.0 system, such as names, keycodes, serial numbers, IP addresses, and system numbers

Accessing the system utilities

All CallPilot utilities are accessible from the CallPilot server in the Start → Programs → CallPilot → System Utilities menu.

Diagnostics Tool

The Diagnostics Tool allows you to enable or disable CallPilot startup diagnostics. CallPilot startup diagnostics automatically identify hardware problems that may exist when the system and its services are started. Diagnostics are displayed for:

Media Bus, MPB board, MPC/DSP (for Meridian 1 and Communication Server 1000)

When you disable startup diagnostics, you can save time during system maintenance operations where restarts or Call Processing services restarts are required.

There are three recommended steps:

1. Use the Diagnostics Tool to turn off CallPilot startup diagnostics.
2. Perform system maintenance.
3. Use the Diagnostics tool to turn on CallPilot startup diagnostics.

To access the Diagnostics Tool

On the Windows desktop, click Start → Programs → CallPilot → System Utilities → Diagnostic Tool.

Result: The Diagnostics Tool window appears.

To enable startup diagnostics

From the Diagnostics Tool window, select Configuration → Maintenance Startup Diag → Enable.

To disable startup diagnostics

 **Important:**

Avaya recommends that you leave the startup diagnostics turned on. When you disable CallPilot startup diagnostics, you prevent CallPilot from automatically identifying hardware problems that may exist when the system and its services are started.

On the Diagnostics Tool window, select Configuration → Maintenance Startup Diag → Disable.

PEP Maintenance utility

The PEP Maintenance utility displays a list of all installed PEPs on the server and enables you to uninstall PEPs. For information on installing or uninstalling PEPs, refer to the Installation and Configuration Task List (NN44200-306).

To access the PEP Maintenance utility

From the Windows desktop, click Start → Programs → CallPilot → System Utilities → PEP Maintenance Utility.

Result: The DMI Viewer window appears.

To view a list of all installed PEPs

1. Click the component for which you want to display the PEP list.
2. Click Show PEPs.
Result: A list of all installed PEPs appears in the left pane.
3. If you want to review the readme file associated with a PEP, click the PEP, and then click Read.

Result: The readme file opens in Notepad.

Session Trace

The Session Trace tool displays detailed information about the activity in a user's mailbox and the state of the message waiting indicator (MWI). The session information includes

- voice messaging
- call answering
- express messaging activity (messages composed and sent, or left in a mailbox)
- the number of messages played or not played at the beginning, middle, and end of a session
- the number of deleted read messages
- the number of deleted unread messages
- messages and personal distribution lists restored into a mailbox
- the last change to the MWI (turned on or off, or untouched)

This session information allows an administrator or technician to study the state of a user's mailbox and the MWI, and to use that information to follow up on any user complaints. For example, a user may report that the MWI was on, but no voice messages were in the mailbox when the user logged on. The session information can tell the administrator why the MWI was turned on.

 **Warning:**

The Session Trace Tool is a resource intensive tool. It is strongly recommended to use this utility during off-peak hours. If the CP database or OMs are large, it may require a significant amount of time to perform this activity. To minimize the search time, OM data should be collected for no more than 1–2 days.

To access the session trace tool

From the Windows desktop, click Start → Programs → CallPilot → System Utilities → Session Trace Tool.

Result: The MCE Session Trace window appears.

To find a session

1. From the Session Type drop-down menu, choose the type of session. To display a list of all session types, select All Session Types.
2. Enter as much information in the search criteria boxes to identify the session you want to view. To display a list of all users for the selected Session Type, leave the search criteria boxes blank.
3. Click Search to initiate the search.
 - a. If you did not enter any user information, a list of users matching the Session Type appears at the bottom of the window. To select a user from the list, double-click the user name to display session type information.
 - b. If you selected All Session Types for a user, the session type information appears to the right of the window.
4. Double-click the session type to display the session information.

Result: The Session Type information appears at the bottom of the window. The following example shows Call Answering session type information.




Figure 5: Call Answering session Type

System Monitor

The System Monitor consists of three tabs, as described in the following table:

Tab	Description
Channel Monitor	Shows the status of all CallPilot services, multimedia channels, and call channels (DS30X channels in Meridian 1 and Communication Server 1000).
System Info	Displays details about the CallPilot 5.0 system, such as features purchased, keycode, serial number, and CallPilot server IP addresses.
Legend/Help	Provides a description of icons and terminology displayed in the System Monitor window.

System Monitor is a non-destructive tool that does not alter the behavior of any CallPilot components.

To access the System Monitor

On the Windows desktop, click Start → Programs → CallPilot → System Utilities → System Monitor.

Result: The CallPilot System Monitor window appears. By default, the Channel Monitor tab appears on top. Click the other tabs to view the information on those tabs.

Channel Monitor tab




Figure 6: Channel Monitor tab.

CallPilot services

The Service Name pane shows the status of services from a CallPilot perspective. The status shown in the Windows Services Control Panel may state that a service is running, but it may not actually be fully running or in service from a CallPilot perspective. Refer to the System Monitor tool Channel Monitor tab for the true status.

The services listed under Service Name should be either running or in full service when CallPilot is functioning optimally. If any CallPilot services are stopped, investigate the cause of this. If you need assistance, call Avaya technical support.

 **Note:**

While any stopped services should be investigated, some services are not critical. CallPilot may continue to handle call processing even with some services stopped.

The critical services that are needed for basic CallPilot call answering are listed in the following table. For your reference, the equivalent names as they appear in the Windows Control Panel are also listed.

CallPilot System Monitor	Windows Control Panel equivalent
CTMS Service	CTMS Server
Telephony (TAPI)	Telephony
MCE SLEE	CallPilot SLEE Service
MCE Notification	CallPilot MWI Service
MAS Notification	CallPilot Notification Service
MAS CCR	CallPilot Call Channel Router
MAS BCR	CallPilot Blue Call Router
SQL Anywhere	Adaptive Server Anywhere - %ComputerName%_SQLANY
MAS MltmediaCache	CallPilot Multimedia Cache
MAS MltmediaVol1	CallPilot Multimedia Volume 1
MAS MltmediaVol2 (TRP only)	CallPilot Multimedia Volume 2 (TRP only)
MAS MltmediaVol3 (TRP only)	CallPilot Multimedia Volume 3 (TRP only)
MAS Rsrc. Pckg. 1	CallPilot Resource Package1

DSPs

In the DSP pane, each DSP is represented in a separate row. Each box in the row is one DSP channel or multimedia channel. Click the Legend/Help tab to view descriptions of the multimedia channel icons.

On the 703t server, 12 DSPs are embedded on each MPB96 board.

DS30X links

In the DS30X link pane, each DS30 row represents a separate DS30X link (also referred to as a DS30 link). Each box in the row represents one DS30X channel.

The DS30X links connect the CallPilot server to the MGate card (NTRB18CA) in the Meridian 1 switch or Communication Server 1000 system.

System Info tab




Figure 7: System Info tab.

 **Note:**

The screen sample above was acquired from a 1001rp server, but provides the same type of information for any CallPilot server model.

The numbered items provide information about the features purchased. Information about the underlying operating system, including the server IP addresses, is provided in the top right corner.

PEP information and configured Service DNs are listed in the bottom part of the window.

Legend/Help tab

[Figure 8: Legend/Help tab](#) on page 83 shows the Legend/Help tab. Consult this tab for descriptions of the icons found in the Channel Monitor tab.




Figure 8: Legend/Help tab

Chapter 8: Replacing basic chassis components

In this chapter

[Preparing the server for hardware maintenance](#) on page 85

[Removing the side cover](#) on page 88

[Removing and replacing the upper fan holder foam](#) on page 90

[Replacing the side cover](#) on page 91

[Cooling fans description](#) on page 93

[Replacing a front system fan](#) on page 96

[Replacing a rear system fan](#) on page 99

[Replacing the processor fan](#) on page 101

Preparing the server for hardware maintenance

 **Danger:**

Risk of electric shock

Before you begin working inside the server, do the following:

1. Power off and disconnect all peripheral devices that are connected to the Avaya CallPilot® server.
2. Power off the server and disconnect the power cord.

For more information, see Preparing the server for hardware maintenance.

 **Caution:**

Risk of electrical damage

- Wear an antistatic ESD wrist strap when handling cards or boards, or when working inside the server.
- Place hardware components on an antistatic surface until you are ready to install them.
- Do not touch the components or gold-edge connectors of cards or boards.

 **Caution:**

Risk of equipment damage

Place the server on its side to prevent the server from accidentally falling over. This position provides greater stability. If you attempt to work with the server in its standing position, it may tip over when you remove or insert components.

If the server is equipped with chassis feet, do one of the following:

- Remove the feet so that the server lies flat on the working surface. For more information, see [Figure 10: Remove chassis feet](#) on page 88.
- Place stable material beneath the server to raise the feet away from the working surface. The bottom of the server then lies flat on the working surface.
- Pull the server forward so that the feet hang over the edge of the working surface.

To disconnect the power and peripheral device cables

Before you access the server interior, do the following:

1. Courtesy stop and power off the server.

For instructions, see "Starting up and shutting down the CallPilot server" in the Installation and Configuration Task List (NN44200-306).

2. Label and disconnect the power cable and any other peripheral cables that may be in your way.

Refer to [Figure 9: Connectors on Server back plane](#) on page 87 to identify the connectors on the server's back panel.




Figure 9: Connectors on Server back plane

3. If desired, continue with [Figure 10: Remove chassis feet](#) on page 88.




Figure 10: Remove chassis feet

4. Place the server on it's side.
5. Remove the feet as shown in the above diagram.
6. Continue with [Removing the side cover](#) on page 88.

Removing the side cover

This section describes how to remove the server side cover so that you can work with interior components. The side cover is on the left side of the server when the server front panel is facing you.

To remove the side cover

⚠ Warning:

Risk of personal injury


To prevent personal injury, use caution when you handle the sharp edges of the side cover and chassis.

⚠ Caution:

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

[Figure 11: Remove server side panel](#) on page 89 shows how to remove the side cover. See the following instructions for removal.



G101761

Figure 11: Remove server side panel

1. Turn the two thumbscrews on the back of the server counter-clockwise to loosen them.

*** Note:**

The thumbscrews are not removable.

If a removable screw is present, remove it. This screw secures the cover to the server during shipping.

⚠ Caution:


Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

2. Place your fingertips in the depression on the side cover, and then, as you apply pressure, pull the cover approximately 2.5 cm (1 in.) away from the front of the server until it stops.
3. Use both hands to lift the cover away from the chassis.
4. Set the cover aside.

Removing and replacing the upper fan holder foam

The interior of the server contains two layers of fan holder foam, which secure and stabilize the cooling fans and add-in boards. The fan holder foam also maintains the space that is required between the boards for cooling. You may be required to remove the upper fan holder foam to access and work with some components.



G101783

Figure 12: Install fan holder foam

To remove the upper fan holder foam

 **Caution:**

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

1. Remove the server side cover.
2. Lift the upper fan holder foam out of the server.

To replace the upper fan holder foam

1. Ensure that the fan cables are in the slots in the lower fan holder foam.
2. Place the bottom end of the upper fan holder foam beneath the edge of the server chassis.
3. Align the slots on the underside of the foam with the fans and add-in boards.

Use your fingers on the underside of the upper fan holder foam to determine correct placement of the fans. The fans must sit straight inside the foam sockets. They must not align with the left side of the foam.

4. Press the foam into place.

You may need to wiggle the fans so that the upper fan holder foam sits flush with the bottom fan holder foam.

5. Ensure that the upper fan holder foam engages with the lip on the media drives cage and is securely seated.

Replacing the side cover

After you complete your work with the interior components of the server, replace the side cover. If you removed them, reinstall the chassis feet on the bottom of the server.

To replace the side cover

 **Caution:**

Risk of equipment damage

Before you replace the side cover, ensure that no tools or loose parts are inside the server chassis.

 **Caution:**

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

1. Hold the cover flat against the chassis.
2. Slide the cover toward the front of the server until it locks into place.
3. Tighten the two thumbscrews on the back of the server.
4. If you removed the chassis feet, reinstall them.
5. Connect all external peripheral device cables and the power cord to the back panel.
6. Power up the server.




Figure 13: Server side cover

Cooling fans description

For cooling and airflow, the system contains five fans that cool the interior of the server.

⚠ Warning:


Risk of equipment damage

Ensure that any cables in the proximity of the fans are kept away from the fans. If a cable is caught in a fan, the fan will break.

Replaceable fan locations

The server contains five replaceable fans:

- Three fans are located near the front of the server. Two fans draw air through the lower media drive bays and provide cooling to the add-in boards. The third fan provides cooling for the system's processor. See [Figure 14: Front system fans](#) on page 95.
- Two fans are located at the back of the server. These fans draw air through the upper media drive bays, cool the interior of the server, and assist in evacuating hot air through the back of the server. See [Figure 15: Rear system fans](#) on page 96.



G101781

Figure 14: Front system fans




Figure 15: Rear system fans

Fan labels

The following conditions indicate when fans are installed correctly:

- The printed label of the fan faces the back of the server.
- The arrows embossed on the fan casing face as follows:



Replacing a front system fan

Replace a malfunctioning fan with the same type as the one removed. For more information about replacing a fan, contact your Avaya customer service representative.

 **Note:**

The fan replacement kit contains four fans: two front fans and two rear fans.

To remove a front system fan

 **Caution:**

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

1. Prepare the server for front system fan replacement as follows:
 - a. Shut down the server, and then disconnect the power and peripheral device cables.
 - b. Place the server on its side.
 - c. Remove the side cover.
 - d. Remove the upper fan holder foam.

For instructions, see [Preparing the server for hardware maintenance](#) on page 85.

 **Warning:**

Risk of personal injury or equipment damage

Failure to follow the procedures in [Preparing the server for hardware maintenance](#) on page 85 can result in electrical shock or equipment damage.

2. Label and disconnect any cables that are attached to the voice processing boards.
3. Remove any add-in boards that block your access to the fan connectors on the motherboard.

 **Note:**

As you remove each board, label it with its slot number so that you can reinstall the board in the same slot.

4. Lift the fan out of its slot in the fan holder foam.
5. Disconnect the fan power cable connector from the server motherboard.




Figure 16: Install front system fan

6. Insert the fan into its slot in the bottom fan holder foam.

! Important:

To ensure proper cooling operation, ensure that the printed label of the fan is facing the back of the server, and the arrows embossed on the fan casing are facing as follows:.



7. Connect the fan's power cable as follows:
 - a. Insert the power cable of the fan into its slot on the bottom fan holder foam, and route the cable as shown in the preceding diagram.
 - b. Connect the power cable of the fan to its connector on the motherboard.
The connector is keyed so that it can be attached only one way.

 **Note:**

The fan closest to the top of the server connects to the connector labeled sysfan5. The fan closest to the bottom of the server connects to the connector that is labeled sysfan3.

8. Reinstall the add-in boards.
9. Reconnect any cables you disconnected to the add-in boards.
10. Ensure that any cables located near the fans are kept well away from the fans.

 **Caution:**

Risk of equipment damage

If a cable is caught in a fan, the fan will break.

11. Replace the upper fan holder foam.
For instructions, see [To replace the upper fan holder foam](#) on page 91.
12. Replace the side cover of the server.
13. Reconnect all peripheral device cables and power cord.
14. Power up the server.

Replacing a rear system fan

Replace a malfunctioning fan with the same type as the one removed. For more information about replacing a fan, contact your Avaya customer service representative.

 **Note:**

The fan replacement kit contains four fans: two front fans and two rear fans.

To remove a rear system fan

 **Caution:**

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

1. Prepare the server for rear system fan replacement as follows:
 - a. Shut down the server, and then disconnect the power and peripheral device cables.

- b. Place the server on its side.
- c. Remove the side cover.

For instructions, see [Preparing the server for hardware maintenance](#) on page 85.

⚠ Warning:

Risk of personal injury or equipment damage

Failure to follow the procedures in [Preparing the server for hardware maintenance](#) on page 85 can result in electrical shock or equipment damage.

- 2. Lift the tab on the bracket that holds the fan in place.
- 3. Angle the fan towards the interior of the server, and then lift it away from its slot.
- 4. Disconnect the power cable of the fan connector from the server's motherboard.




Figure 17: install rear system fan

- 5. Place the bottom edge of the fan on the support bracket at the back of the server.

! Important:

To ensure proper cooling operation, ensure that the printed label of the fan is facing the back of the server, and the arrows embossed on the fan casing are facing as follows:



6. Lift the brackets tab, align the fan with the server back wall, and then release the tab.
Ensure that the tab engages with the edge of the fan casing.
7. Connect the fan power cable to the motherboard.

***** Note:

The fan closest to the top of the server connects to the connector labeled sysfan1. The fan closest to the bottom of the server connects to the connector that is labeled sysfan2.

8. Wrap excess cable length with a twist tie or cable wrap, and ensure that it is placed away from the fans.

! Caution:

Risk of equipment damage

If a cable is caught in a fan, the fan will break.

9. Replace the server side cover.
10. Reconnect all peripheral device cables and power cord.
11. Power up the server.

Replacing the processor fan

Replace a malfunctioning fan with the same type as the one removed. For more information about replacing a fan, contact your Avaya customer service representative.

To remove the processor fan

! Caution:

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

1. Prepare the server for processor fan replacement as follows:
 - a. Shut down the server, and then disconnect the power and peripheral device cables.
 - b. Place the server on its side.
 - c. Remove the side cover.
 - d. Remove the upper fan holder foam.

For instructions, see [Preparing the server for hardware maintenance](#) on page 85.

⚠ Warning:

Risk of personal injury or equipment damage

Failure to follow the procedures in [Preparing the server for hardware maintenance](#) on page 85 can result in electrical shock or equipment damage.

2. Disconnect the fan power cable connector from the server's motherboard.
3. Use both hands to spread the fan bracket tabs apart, and then move the fan away from the posts that hold it in place.

Tip: You may need to lift the bottom fan holder foam slightly to create more space.
4. Lift the fan up and out of the server.




Figure 18: install processor fan

5. Use both hands to spread the fan bracket tabs apart.

Tip: You may need to lift the bottom fan holder foam slightly to create more space.

6. At the same time, slide the fan onto the supporting posts.

 **Important:**

To ensure proper cooling operation, ensure that the fan's printed label is facing the back of the server, and the arrows embossed on the fan casing are facing as follows..



- Ensure that the fan cable is inside the bracket tab. This secures the cable to prevent damage.
 - Ensure that the bracket tabs engage with the edges of the fan casing.
7. Connect the fan power cable to the connector labeled CPUfan1 on the motherboard. Secure the power cable by routing it between the heat sink housing and the capacitors.
 8. Ensure that any cables located near the fan are kept well away from the fan.

 **Caution:**

Risk of equipment damage

If a cable is caught in a fan, the fan will break.

9. Reseat the bottom fan holder foam.
10. Replace the upper fan holder foam. For instructions, see [To replace the upper fan holder foam](#) on page 91.
11. Replace the server side cover.
12. Reconnect all peripheral device cables and power cord.
13. Power up the server.

Chapter 9: Replacing media drives

In this chapter

[SCSI and IDE drive cabling](#) on page 105

[Replacing a faulty hard drive](#) on page 106

[Replacing the tape drive](#) on page 113

[Replacing the CD-ROM drive](#) on page 117

[Replacing the floppy disk drive](#) on page 119

SCSI and IDE drive cabling

Cabling diagram

[Figure 19: SCSI and IDE drive cabling.](#) on page 106 shows the following:

- cabling for and termination of SCSI devices (hard drives and tape drives)
- cabling for an IDE CD-ROM drive

Use the information in this section to assist you with the procedures for replacing a faulty hard drive, tape drive, or CD-ROM drive




Figure 19: SCSI and IDE drive cabling.

Replacing a faulty hard drive

If you need to replace a faulty hard drive, then do the following:

1. Review this entire section before proceeding to become familiar with the requirements and process.
2. Prepare the server for hard drive replacement as described in [Preparing the server for hardware maintenance](#) on page 85.

! Important:

Due to the confined space for media drive cabling inside the server, hard drive replacement is easiest when the server is laying on its side. Laying the server on its side helps to prevent damage to the server and internal components.

3. Remove the faulty drive as described in [To remove a hard drive from the server](#) on page 109.

! Important:

Replacement drives must be the same size or larger than the drives being replaced.

4. Install the new hard drive in the drive carrier as described in [7](#) on page 110.
5. Install the drive carrier assembly in the server as described in [To install the hard drive](#) on page 111.

Hard drive description

The server is equipped with two 36 Gbyte wide SCSI hard drives, each one inch high. The last bay must remain empty to ensure proper system cooling.

**Caution:**

Risk of equipment damage

The internal SCSI interface in this system supports only single-ended SCSI devices. Use Avaya authorized drives only.

SCSI drive cabling

The hard drive assembly package includes a standard 68-pin, 68 conductor, twisted-pair wide (16-bit) SCSI ribbon cable, with terminator. This cable has three connectors: the first is for the terminator, the second is for the hard drive, and the third is for connection to the RAID card.

Hard drive configuration

Ensure that the hard drives are configured as follows (for instructions, refer to the original equipment manufacturer documentation):

- termination power: Set the hard drive on each SCSI bus to provide termination power to the bus.
- term power jumper: enabled
- parity checking (if this setting is available): enabled on both drives
- all other settings: factory default

Table 16: RAID and SCSI settings

Location of hard drives in internal drive bays (from the top down)	RAID channel	SCSI ID	Hard drive label in the RAID software
Drive bay 4 (empty - used for airflow)	Not applicable	Not applicable	Not applicable
Drive bay 5 (Hard drive 1)	0	0	A0-0
Drive bay 6 (Hard drive 2)	1	0	A0-1
Drive bay 7 (empty)	Not applicable	Not applicable	Not applicable
Drive bay 8 (empty)	Not applicable	Not applicable	Not applicable
Drive bay 9 (bottom slot)	This slot must remain empty to ensure proper system cooling.		

Filler panels and EMI shields

System EMI integrity and cooling are both protected by drives that are installed in the bays or by filler panels and EMI shields that cover the bays. When installing drives, save the panel and shield to reinstall later, in case you remove the drive and do not reinstall one in the same bay.




Figure 20: Hard drive installation overview

To remove a hard drive from the server

⚠ Caution:

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

1. Prepare the server for hard drive replacement as follows:
 - a. Shut down the server, and then disconnect the power and peripheral device cables.
 - b. Remove the side cover.
 - c. Remove the upper fan holder foam.

For instructions, see [Preparing the server for hardware maintenance](#) on page 85.

 **Warning:**

Risk of personal injury or equipment damage

Failure to follow the procedures in [Preparing the server for hardware maintenance](#) on page 85 can result in electrical shock or equipment damage.

2. Open the front panel on the server.
3. Remove and save the two screws that secure the drive's carrier to the front of the chassis.
4. Pull the drive out slightly—about 1 cm (0.5 in.).

Pulling the drive out creates more space between the front system fans and the drives inside the server so that you can disconnect the cables.

5. If required (to provide more space), temporarily remove the front system fans from their slots in the bottom fan holder foam. (Do not disconnect the fans' power cables.)
6. Reach your fingers between the fan holder foam inside the server and the hard drives, and carefully disconnect the power and signal cables for both hard drives.

 **Note:**

If you are able to disconnect the cables for only the hard drive you want to remove, that is acceptable. You may find it easier, however, to disconnect the cables for both hard drives.

7. Pull the drive carrier out of the chassis, and then place it cage-side-up on an antistatic surface..

 **Caution:**

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

8. Remove the new drive from its protective wrapper, and place it on an antistatic surface.
9. Record the drive model and serial numbers in your equipment log.

 **Important:**

Replacement drives must be the same size or larger than the drives being replaced.

10. Set the hard drive settings as described in [Hard drive configuration](#) on page 107.

For instructions on changing the hard drive's settings, refer to the drive manufacturer's documentation.

11. If you are replacing an existing hard drive, remove the old drive from the drive carrier as follows:
 - a. Remove the four screws that attach the drive to the carrier.
 - b. Lift the carrier off of the hard drive.
 - c. Place the drive in an antistatic protective wrapper.
12. Position the new drive component-side down inside the drive carrier, and then attach the four screws that you removed earlier.

Ensure that the connectors on the back of the drive are flush with the rear of the drive carrier.

13. Continue with [To install the hard drive](#) on page 111.

To install the hard drive

Important:

The last bay must remain empty to ensure proper system cooling.

1. Slide the hard drive and drive carrier assembly (with the exposed drive facing up) into the server bay.

Important:

To provide more space inside the server so that you can connect the cables, do not push the drive all the way in (that is, until it clicks into place).

2. If not already done: Temporarily remove the front system fans from their slots in the bottom fan holder foam.

Do not disconnect the fans' power cables.

3. Connect the hard drive SCSI cable as follows (the end of the cable with two connectors is the hard drive end):

- a. Ensure that a terminator is connected to the last connector at the hard drive end of the cable.
- b. Connect the second connector on the cable to the hard drive.

Place one hand on the front of the hard drive to hold it in place while you connect the cable with the other hand.

Caution:

Risk of connector pin damage

To prevent damage to the connector pins, ensure that the cable connector aligns correctly with the hard drive connector before pushing it into place.

- c. Route the cable above the CPU through the vacant space at the top of the server.
- d. Connect the other end of the cable as follows:
 - Connect hard drive 1 to channel 0 on the RAID controller.
 - Connect hard drive 2 to channel 1 on the RAID controller.
- e. For proper cooling and airflow, neatly fold and secure the excess signal cable above the CPU. Use a tie wrap or cable clip to secure the cable.



Caution:

Risk of equipment damage

Ensure that any cables in the proximity of the fans are kept away from the fans. If a cable is caught in a fan, the fan will break.

If you need more information, see [SCSI and IDE drive cabling](#) on page 105.

4. Connect the hard drive's power cable.



Note:

The connector is keyed so that you cannot connect it upside down.

5. At the front of the server, slide the drive into the bay until it clicks into place.
6. Secure the drive carrier to the front of the server with the screws you removed earlier.

Tighten the screws firmly.
7. Ensure that all media drive cable connections are secure.



Note:

Connectors could be dislodged when you slide the hard drive all the way inside the bay.



Caution:

Risk of data loss, corruption, or system malfunction

If the hard drive cable connections are loose, data loss, data corruption, or system malfunction can occur.

8. Reinstall the fans (if removed) and upper fan holder foam.
 - For instructions on reinstalling the fans, see [Figure 16: Install front system fan](#) on page 98.

- For instructions on replacing the upper fan holder foam, see [To replace the upper fan holder foam](#) on page 91.
9. Reinstall the server side cover.
 10. Reconnect the peripheral device and power cables.
 11. Power up the server.
 12. Rebuild the drive in the RAID system pack.

The rebuild copies the data from the operating hard drive to the new hard drive. For instructions, see [RAID operations](#) on page 125

Result: Hard drive replacement is complete.

Replacing the tape drive

The tape drive is preinstalled at the factory. However, if it becomes faulty, follow the procedure in this section to replace it.



Caution:

Risk of electrical damage

Use only a tape drive that is supplied by Avaya.

Filler panels and EMI shields

System EMI integrity and cooling are both protected by drives installed in the bays or by filler panels and EMI shields covering the bays. When installing drives, save the panel and shield to reinstall later, in case you remove the drive and do not reinstall one in the same bay.

Tape drive configuration



Note:

Some settings may already be properly configured. If it is not clear from the drive manufacturer's documentation how to set jumpers, contact your Avaya technical support representative.


Ensure that the hard drives are configured as follows (for instructions, refer to the original equipment manufacturer documentation):

- SCSI ID: 2
- active terminators (Term Enable): disabled

*** Note:**

Termination is provided by an Active SCSI terminator that you connect to the end of the SCSI cable (see [SCSI and IDE drive cabling](#) on page 105).

- parity checking: enabled
- termination power (TPWR): enabled
- all other settings: factory default



G101772

Figure 21: Tape drive installation overview

To remove the tape drive

⚠ Caution:

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

 **Note:**

The tape drive is installed in the second bay from the top.

1. Prepare the server for tape drive replacement as follows:
 - a. Shut down the server, and then disconnect the power and peripheral device cables.
 - b. Remove the side cover.
 - c. Remove the upper fan holder foam.

For instructions, see [Preparing the server for hardware maintenance](#) on page 85.

 **Warning:**

Risk of personal injury or equipment damage

Failure to follow the procedures in [Preparing the server for hardware maintenance](#) on page 85 can result in electrical shock or equipment damage.

2. Disconnect the power and signal (SCSI) cables of the faulty drive.
3. Open the front panel on the server.
4. Remove and save the two screws that secure the tape drive to the front of the chassis.
5. Pull the tape drive out of the chassis, and then place it on an antistatic surface.

 **Note:**

If you plan to leave the bay empty, install a filler panel and stainless steel EMI shield on the bay.

6. Remove the four screws and two slide rails from the tape drive.
7. Place the drive in an antistatic protective wrapper.
8. Continue with "[To install a replacement tape drive](#) on page 115" below.

To install a replacement tape drive

1. Remove the new tape drive from its protective wrapper, and place it on an antistatic surface.
2. Record the drive model and serial numbers in your equipment log.
3. Set the settings of the tape drive as described in [Tape drive configuration](#) on page 113.

For instructions on changing the tape drive's settings, refer to the drive manufacturer's documentation.

4. Attach the slide rails to the replacement tape drive with the screws you removed earlier.
5. Slide the tape drive into the tape drive bay.
6. Secure the tape drive to the front of the server with the screws you removed earlier.
Tighten the screws firmly.
7. Refer to the [Cabling diagram](#) on page 105, and then connect the tape drive's SCSI cable as follows:
 - a. Connect one end of the SCSI cable to LVD (the wide SCSI controller of the server) on the server's motherboard.
 - b. If a terminator is not attached to the cable, attach a wide SCSI terminator to the other end of the SCSI cable.
 - c. Connect the second connector on the SCSI cable to the tape drive.
 - d. For proper cooling and air flow, neatly fold and secure the excess signal cable into the last bay (at the bottom of the server) so that the cable does not drape across the baseboard or add-in boards.



Caution:

Risk of equipment damage

Ensure that any cables in the proximity of the fans are kept away from the fans. If a cable is caught in a fan, the fan will break.

8. Connect the power cable of the tape drive.

Result: The tape drive is installed.

9. Replace the upper fan holder foam.

For instructions on replacing the upper fan holder foam, see [To replace the upper fan holder foam](#) on page 91.

10. Replace the side cover.
11. Reconnect the peripheral device and power cables.
12. Power up the server.
13. Test the tape drive.


Replacing the CD-ROM drive

The CD-ROM drive is preinstalled at the factory. However, if it becomes faulty, follow the procedure in this section to replace it.

⚠ Caution:

Risk of electrical damage

Use only a CD-ROM drive that is approved by Avaya.



G101773

Figure 22: CD-ROM drive installation overview

To remove the CD-ROM drive

⚠ Caution:

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.



The CD-ROM drive is installed in the top bay.

1. Prepare the server for CD-ROM drive replacement as follows:
 - a. Shut down the server, and then disconnect the power and peripheral device cables.
 - b. Remove the side cover.
 - c. Remove the upper fan holder foam.

For instructions, see [Preparing the server for hardware maintenance](#) on page 85.



Warning:

Risk of personal injury or equipment damage

Failure to follow the procedures in [Preparing the server for hardware maintenance](#) on page 85 can result in electrical shock or equipment damage.

2. Disconnect the faulty drive's power and signal (IDE) cables.
3. Open the front panel on the server.
4. Remove and save the two screws that secure the CD-ROM drive to the front of the chassis.
5. Pull the drive out of the chassis, and then place it on an antistatic surface.



Note:

If you plan to leave the bay empty, install a filler panel and stainless steel EMI shield on the bay.

6. Remove the four screws and two slide rails from the drive.
7. Place the drive in an antistatic protective wrapper.
8. Continue with [To install a replacement CD-ROM drive](#) on page 118".

To install a replacement CD-ROM drive



Caution:

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

1. Remove the new CD-ROM drive from its protective wrapper, and place it on an antistatic surface.
2. Record the drive model and serial numbers in your equipment log.
3. Set the new CD-ROM drive to IDE Master by changing the jumper settings at the back of the drive.

 **Note:**

Refer to the CD-ROM drive manufacturer's documentation for specific jumper settings.

4. Install the slide rails on the new drive.

Ensure that the first set of holes on the bracket are aligned with the screw holes closest to the front of the CD-ROM drive.

5. Slide the new CD-ROM drive into the drive bay and secure it to the front of the server with the screws you removed earlier.
6. Reconnect the CD-ROM drive's IDE cable to IDE0 (blue connector) on the motherboard. Ensure that the blue stripe on the cable at the motherboard connector end faces towards the back of the server.

 **Important:**

The server will not start if the cable is connected backwards.

For more information, see the [Cabling diagram](#) on page 105.

7. Reconnect the CD-ROM drive's power cable.

Result: The CD-ROM drive is installed.

8. Replace the upper fan holder foam. For instructions on replacing the upper fan holder foam, see [To replace the upper fan holder foam](#) on page 91.
9. Replace the side cover.
10. Reconnect the peripheral device and power cables.
11. Power up the server.
12. Test the CD-ROM drive.

Replacing the floppy disk drive

The floppy disk drive is preinstalled at the factory. However, if it becomes faulty, follow the procedure in this section to replace it.

 **Caution:**

Risk of electrical damage

Use only a floppy disk drive that is supplied by Avaya.




Figure 23: Floppy disk drive installation overview

To remove the floppy disk drive

! Important:

Avaya recommends that you use a magnetic screwdriver in this procedure. A nonmagnetic screwdriver can result in screws being lost between the chassis and plastic bezel.

! Caution:

Risk of data loss

Keep magnetic screwdrivers away from hard drives, floppy disks, and backup tapes to prevent data loss.

 **Caution:**

Risk of equipment damage

Use an ESD wrist strap to protect static-sensitive components.

1. Prepare the server for floppy disk drive replacement as follows:
 - a. Shut down the server, and then disconnect the power and peripheral device cables.
 - b. Remove the side cover.
 - c. Remove the upper fan holder foam.

For instructions, see [Preparing the server for hardware maintenance](#) on page 85.

 **Warning:**

Risk of personal injury or equipment damage


Failure to follow the procedures in [Preparing the server for hardware maintenance](#) on page 85 can result in electrical shock or equipment damage.

2. Disconnect the power and signal cables of the disk drive.
3. Open the front panel on the server.
4. Remove and save the two screws that secure the floppy disk drive to the front of the chassis.
5. Slide the assembly toward the back of the server to disengage it from the tabs that secure the carrier assembly to the server.
6. Remove the assembly from the chassis.
7. Remove the four screws that hold the bracket to the drive, and set them and the bracket aside.
8. Place the drive in an antistatic protective wrapper.
9. Continue with [To install a replacement floppy disk drive](#) on page 121.

To install a replacement floppy disk drive

1. Remove the new floppy disk drive from its protective wrapper, and place it component-side up on an antistatic surface.
2. Record the drive model and serial numbers in your equipment log.
3. Set any jumpers or switches according to the drive manufacturer's instructions.

4. Place the drive label-side up inside the carrier, and then attach the drive to the carrier with the four screws you removed earlier. See [Figure 24: Attach disk drive to carrier](#) on page 122.



G101774

Figure 24: Attach disk drive to carrier

Ensure that the carrier is aligned with the two screw holes closest to the front of the floppy disk drive. Tighten the screws firmly.

5. Install the drive carrier inside the server.

Slide the assembly toward the front of the system, and engage it with the bracket tabs on the side of the drive bay.

Note:

The bottom of the drive/bracket assembly must accept the tab that sticks out from the inside of the front panel. Ensure that the front of the drive fits flush in the front opening of the system. (See the [Figure 23: Floppy disk drive installation overview](#) on page 120.)

6. Secure the assembly to the server's front panel with the screws you removed earlier. Tighten the screws firmly.

7. Connect the floppy disk drive's signal cable to the drive.

 **Note:**

The connectors are usually keyed to allow you to easily reconnect them to the drive. If they are not keyed, insert both cables so that the red wires are closest to the center of the drive.

 **Caution:**

Risk of data loss

If the floppy disk drive contains a floppy disk and the signal cable is connected backwards, data loss can occur. The LED at the front of the drive will also remain lit after the server is powered up.

8. Connect the power cable of the floppy disk drive to the drive.

Result: The floppy disk drive is installed.

9. Replace the upper fan holder foam.

For instructions on replacing the upper fan holder foam, see [To replace the upper fan holder foam](#) on page 91.

10. Replace the side cover.
11. Reconnect the peripheral device and power cables.
12. Power up the server.
13. Test the floppy disk drive.

Chapter 10: RAID operations

In this chapter

[RAID overview](#) on page 125

[Verifying the RAID firmware](#) on page 126

[Configuring RAID using LSI Elite 1600 controller and Ctrl+M](#) on page 128

[Verifying consistency on the drives](#) on page 131

[RAID splitting](#) on page 132

[Task summary for configuring RAID](#) on page 136

[Task summary for RAID splitting](#) on page 137

RAID overview

Redundant Array of Independent Disks (RAID) is a technology that can combine two or more drives for fault tolerance and continued system performance. The Avaya CallPilot RAID controller is a PCI RAID SCSI card that provides high-performance disk mirroring. CallPilot uses RAID Level 1.

With Level 1 mirroring, two equal-capacity disk drives mirror one another. One disk drive serves as the backup copy of the other disk drive. If one disk drive fails, the other continues to run.

RAID configuring and splitting

Working with RAID involves the following:

- Verifying the RAID firmware version
- Upgrading or downgrading the RAID firmware
- Configuring RAID using the LSI Elite 1600 controller and the Ctrl+M menu at server boot-up

- Ensuring that your system is fully working and the RAID hardware is properly configured
- Performing full data backup
- Performing RAID splitting
- Performing an Avaya CallPilot software upgrade
- Performing RAID synching if upgrade successful
- Performing RAID synching if upgrade NOT successful

Verifying the RAID firmware

The minimum requirement for RAID firmware:

firmware: 111U

To verify the RAID firmware version

To determine what the current RAID firmware version is on the RAID LSI Elite 1600 controller, do the following:

1. Turn on the server and press Ctrl+M when prompted during system bootup.



Note:

The Ctrl+M utility can take up to 1 minute to launch with 111U firmware. The system may appear frozen. Do not reset.

2. Select Objects menu → Adapter → Other Adapter Information. Or
 - a. Launch the MegaRAID client using: Start → Programs → Power Console Plus → Launch Client.
 - b. From the MegaRAID Power Console Plus - Server Selection window, select Access Mode → Full Access to view or change configuration information and click OK.
 - c. From the MegaRAID console, choose Adapter → Properties.
3. Review the information on the screen. Ensure that Power Console Plus is version 5.00i or later. The LSI Elite 1600 controller firmware should be 111U.
4. If the firmware is not correct, perform a firmware update. For instructions, see [To upgrade or downgrade the RAID firmware](#) on page 127.

To upgrade or downgrade the RAID firmware

The firmware of the RAID card is upgraded through a flash process. The flash process is initiated by running the RAID card firmware update utility on the CallPilot CD-ROM.

 **Warning:**

Avaya strongly recommends that you not perform low level formatting. Performing low level formatting results in the drives becoming unusable.

 **Important:**

Perform this procedure only if the firmware version is not the version identified in this section.

1. Insert the CallPilot tower 703t Image CD-ROM 1 of 3 into the server CD-ROM drive.
2. Restart the server and observe the startup diagnostics.
3. When the processor diagnostics screen appears, press Esc.

Result: The following message appears at the bottom of the screen:

```
Entering boot selection menu ....
```

The system continues with the SCSI and RAID startup diagnostics, and when done, a menu appears.

4. Choose ATAPI CD-ROM, and press Enter.
Result: The Startup menu appears.
5. Choose Utilities (for example, BIOS, Firmware, and so on), and then press Enter.
Result: A menu appears.
6. Choose LSI Elite 1600 RAID card Firmware update, and press Enter.
7. Press Y for yes and then Enter to confirm that the 471gen.rom file is detected.
8. Respond to the remaining prompts to proceed with the update.

Result: The update proceeds. When it is finished, you are informed that the update completed successfully and you are asked to restart the server.

9. Remove the CD-ROM from the CD-ROM drive.
10. Press Ctrl+Alt+Delete to restart the server.

Configuring RAID using LSI Elite 1600 controller and Ctrl+M

The configuration of the RAID card is stored on both the card and on the hard drive, so typically you are not required to reconfigure RAID unless you are making a change to the RAID system (for example, if you replace the hard drives with higher-capacity hard drives).

 **Warning:**

Avaya strongly recommends that you not perform low level formatting. Performing low level formatting results in the drives becoming unusable.

 **Caution:**

Risk of data data loss

This procedure requires that the logical drive be initialized. When you initialize the logical drive, all data on the hard drives is erased.

Do not perform this procedure unless you are replacing the hard drives, or you are rebuilding the CallPilot system (that is, reinstalling the Windows operating system and CallPilot software).

To configure an LSI Elite 1600 RAID system

To configure RAID, do the following:

1. Turn on the server and press Ctrl+M when prompted during system bootup.

 **Note:**

The Ctrl+M utility can take up to 1 minute to launch with 111U firmware. The system may appear frozen. Do not reset.

2. From the Management menu, select Objects and press Enter.
3. From the Objects menu select Adapter and press Enter.
4. From the Adapter menu select Factory Default.
5. Select Yes to confirm the selection and press Enter.
6. Press Ctrl+Alt+Delete when prompted to restart system.
7. During bootup, press Ctrl+M to re-enter the RAID setup utility.
8. From the Management menu select Objects → Adapter, then ensure the Adapter 1 values are set as follows:

Flex RAID Power Fail: Enabled Fast Initialization: On Disk Spin up Timing: 1 Disk every 6 secs Cache Flush Timings: Every 4 seconds Rebuild Rate: 30% Alarm Control: Enabled Other Adapter Options:

- Emulation: Mass Storage
- Auto Rebuild: Disabled
- Initiator ID: 7
- Cluster Mode: Disabled
- Multiple PCI Delayed Transactions: Disabled
- Force Boot: Off
- Coercion Algorithm: GigaByte Way
- Cc Restoration: Enabled

 **Note:**

The Coercion Algorithm must be set properly. Once changed, it cannot be changed again. The only way to reset it is to reconfigure RAID from scratch and load the default configuration, then reboot.

9. Select Objects → Channel and press Enter.
10. From the Channel menu, ensure the values are set as follows: Termination State: Enabled
SCSI Transfer Rate: 160M
11. Select Configure menu → New Configuration. Click Yes to proceed.

Result: The system should display both SCSI channels, each having one drive. SCSI IDs should be 0 for each channel. All disk drives should be in READY state.

 **Note:**

Do not use the Load command on the Configure menu. This command is not for RAID operations.

12. Create the first logical drive by selecting Channel-1 ID 0 (A01-01), and pressing the Spacebar. The display will change to ONLIN A01-01. Select Channel-2 ID-0 (A01-02) and again press the Spacebar.
Result: After selection, the drives will blink.
13. Press Enter to End the Array.
Result: The blinking stops.
14. Press F10 to configure the logical drive.
15. Press the space bar to select Configuration Array.

Result: Span-1 appears in the box opened for the A01 logical drive.

16. Press F10 to configure the logical drives.
Result: The system prompts you for each of the logical drives to consecutively select:
RAID 1; Size: accept the size displayed Accept SPAN = NO
Change the last value to NOSPAN if required.
17. Highlight Accept and press Enter twice to accept these new values.
Result: The system prompts you to save the configuration.
18. Highlight YES and press Enter.
19. Press ESC twice to exit the submenus.
20. In the Management menu, choose the Initialize submenu.
21. Press F2 to select the logical drive.
22. Press F10 and consecutively select YES to initialize the drive pack.
23. When the initialization is complete, press any key to return to the Management menu.
24. Press ESC to exit the utility. Save the configuration when prompted.
25. Press Ctrl+Alt+Delete as indicated by the menu to reboot.

Replacing the LSI1600 or LSI320-2 card with LSI320-2

Use this procedure to replace a failed LSI1600 RAID card.

 **Warning:**

Avaya strongly recommends that you not perform low level formatting. Performing low level formatting results in the drives becoming unusable.

 **Important:**

If your replacement RAID card has been previously used and holds an existing configuration, the system will report a mismatch between the controller NVRAM and Drive MetaData. The steps below will correct the mismatch.

To replace the LSI1600 or LSI320-2 card with the LSI320-2 card

1. Power up the server and click Ctrl+M to enter the utility.
2. Select Objects → Adapter → Other Adapter to set the following:
 - a. Set Force Boot to On.
 - b. Set Auto-Rebuild to Disabled.

- c. Select Objects → Channel and ensure channel speed is 160M. ((Default for LSI320 is 320M).
 - d. Repeat for all channels.
3. Exit the utility and reboot the server.
4. Set the server to boot from CD.
5. Insert the RAID Update Utility CD and reboot the server.
Result: The DOS boot menu appears.
6. Select Update LSI320-2 Firmware.
Result: The system will prompt twice to confirm you are upgrading the firmware.
7. Answer Y to both questions.
Result: The system upgrades the firmware and asks you to reboot.
8. Allow the system to reboot to Windows 2003.
9. Insert the RAID Update Utility CD and unzip the RAIDUP.EXE file.
Result: A directory called RAIDUP is created on C:\ drive
10. Locate SCSI controllers → LSI Adapter in the RAIDUP directory. Double click on it, then select Driver.
Result: You are asked to choose the Upgrade Driver.
11. Point to the c:\raidup\Win2k3 folder.
12. The system asks you to reboot.
Result: The system reboots to Windows 2003.
13. Check the driver, firmware and Power Console configuration.
 - a. Open the MegaRAID Power Console from the Start → Programs menu.
 - b. Select Help About from the menu and verify the MegaRAID Power Console version is 5.00i.
 - c. Select Adapter → Properties and verify the firmware version is 1L37 and the board type is LSI320-2.
 - d. Exit the Power Console.
14. Right click on C:\WINNT\SYSTEM32\DRIVERS\mraid3xx.sys and select Properties → Version. Verify the Driver version is 6.45.

Verifying consistency on the drives

This optional consistency check on the logical drive of the RAID system ensures that the data on the drives is identical. If any errors are found, they are corrected automatically. Perform a consistency check before you split the RAID system pack. A good data backup on an offline

drive is important if you need to revert to the CallPilot system from an unsuccessful upgrade or update. The consistency check can take up to 2 hours to complete.

To perform a consistency check

1. In Windows, click Start → Programs → Power Console Plus → Launch Client.

Result: The MegaRAID Power Console Plus- Server Selection window appears.

2. Ensure that Access Mode → Full Access is selected, and click OK.

Result: The MegaRAID Power Console Plus window appears displaying the Logical View of the Physical Devices and the Logical Devices. The status bar at the bottom of the window indicates that RAID channels are being scanned. When scanning is done, the screen refreshes and displays the Physical and Logical Devices.

3. In the Logical Devices section, right-click the logical drive, and then choose Check Consistency from the pop-up menu.

Result: The Check Consistency status dialog appears.



Note:

The check can take up to 2 hours to complete. You are informed when it is finished. If any errors are found, a window with an error message is displayed.

4. Select Configuration → Exit to close the MegaRAID console.

Result: An end of session message appears.

5. Click OK.

RAID splitting

Ensure that your system is in full working order and the RAID hardware configuration is set up properly as described on [Configuring RAID using LSI Elite 1600 controller and Ctrl+M](#) on page 128.



Important:

The most important thing to verify is that the RAID channel 1 is connected to the first hard drive (top as facing the machine) and channel 2 is connected to the second drive (bottom). Do that by either opening the lid and following the cables or by removing one hard drive and observing which drive is marked dead by the system. If the drive matches the graphic location on the Windows MegaRAID console, proceed with the next step.

Full data backup

Important:

As an extra precaution, Avaya recommends that a full system backup be performed PRIOR to performing a RAID-split. For more information on system backups, refer to the CallPilot Manager online Help.

To split the RAID

Important:

Because the 703t has only one physical drive per channel, the RAID splitting can be done using the Windows MegaRAID console without risk of CallPilot database corruption.

1. To load the MegaRAID console, click Start → Programs → Power Console Plus → Launch Client.

Note:

Ensure that Access Mode → Full Access is selected.

2. Click OK.

Result: Result: the MegaRAID Power Console Plus window appears.

3. Ensure all drives are in ONLINE state (marked GREEN).
4. In the Physical Devices section, right-click the Channel-2 hard disk drive. Example: Channel-2 (0) A1-2-Onln.
5. Select Tools → Fail Drive from the pop-up menu.

Result: A message appears advising that marking the Online drive Failed results in changes.

6. Ignore the warning and click OK. The drive status will change to FAILED and the color of the icon will change to RED. Example: Channel-2 (0) A1-2-Failed.

Result: The audible alarm should start beeping.

Important:

The alarm can be silenced, but under no circumstances should it be disabled. Select Adapter → Alarm Control → Silence Alarm.

RAID operations

At this point, the RAID is split, and the drive marked FAILED is the backup drive and will no longer be written to. A release upgrade or PEP installation can now be completed without impact to the →backup' drive.




Figure 25: MegaRAID Power Console Plus drive status

Perform a CallPilot software upgrade

Let the system boot. The system will still run after Channel 2 of the RAID card was taken out of service and will boot to Windows. Perform the software upgrade.

To synchronize the RAID after a successful upgrade

To restore RAID to full service after completing a successful upgrade or update:

1. WITHOUT shutting down the server, from Windows, click Start → Programs → Power Console Plus → Launch Client.



Note:

Ensure that Access Mode → Full Access is selected.

2. Click OK.

Result: The MegaRAID Power Console Plus window appears.

3. In the Physical Devices section, right-click the Channel 2 hard disk drive that was marked FAILED.

Example: Channel-2 (0)A1-2-Failed.

4. From the right mouse pop-up menu, select Rebuild.

Result: When Rebuild is done, the drive status changes to ONLINE and the color of the icon should change to green. The alarm should stop beeping unless it was temporarily silenced.

 **Note:**

The process can take up to 1 hour. DO NOT shut down the machine before the rebuild is complete. If you do reboot or power down during this process, you need to do [To synchronize RAID after an unsuccessful upgrade](#) on page 135, then start again. You can monitor the rebuild by opening the Windows MegaRAID console.

To synchronize RAID after an unsuccessful upgrade

If the upgrade or update has failed, the system needs to be returned to the original configuration.

1. Restart the server and enter the Ctrl+M utility when prompted during system bootup.
2. From the Management menu select Objects and press Enter.
3. Select Objects → Physical Drive and press Enter.
4. Select FAIL Drive for the drive on Channel 1.

Result: The drive will show as FAIL.

5. Select the drive on Channel 2 (previously taken offline as the backup drive and marked 'Failed') and make it ONLINE. Ignore the warning message.

Result: At this point, the drive on the Channel 2 is ONLINE and the one on Channel 1 is marked FAILED.

6. Exit the utility and press Ctrl+Alt+Delete to reboot the server.

Result: The system will boot up to the original configuration before the software upgrade and an audible alarm will indicate the state CRITICAL for the drives. You can silence the alarm but DO NOT disable it.

7. Once the system is fully booted, open the Windows MegaRAID console and rebuild the FAIL drive on Channel 1 using the same process indicated in [To synchronize the RAID after a successful upgrade](#) on page 134. Reverting from a failed software upgrade is now complete. The audible alarm, if left on, should automatically stop.

Task summary for configuring RAID

 **Note:**

This summary should be used only after reviewing the more detailed procedures and warnings in this chapter.

What to do	How to do it
Verify the BIOS and firmware revisions	Firmware: 111U Use the Windows MegaRAID console and choose Adapter → Properties. Or turn on the server and press Ctrl+M. Select Objects menu → Adapter → Other Adapter Information.
Upgrade or downgrade firmware and BIOS	Use the CallPilot 5.0 tower 703t Image CD-ROM 1 of 3 and select Utilities, RAID 703t F/W upgrade.
Configure RAID using LSI 1600 controller using the Ctrl+M menu at server boot-up  Note: The Ctrl+M utility can take up to 1 minute to launch with 111U firmware. The system may appear frozen. Do not reset.	<ol style="list-style-type: none"> 1. Start the server and press Ctrl+M. Select Objects menu → Adapter → Factory Default, and select Yes to confirm the selection. Press Ctrl+Alt+Delete when prompted to restart system and re-enter Ctrl+M utility. 2. Select Objects → Adapter, then ensure the following values are set as following: Flex RAID Power Fail: Enabled Fast Initialization: On Disk Spin up Timing: 1 disk every 6 secs Cache Flush Timings: Every 4 seconds Rebuild Rate: 30% Alarm Control: Enabled Other Adapter Settings: <ul style="list-style-type: none"> • Emulation: Mass Storage • Auto Rebuild: Disabled • Initiator ID: 7 • Cluster Mode: Disabled • Multiple PCI Delayed Transactions: Disabled • Force Boot: Off • Coercion Algorithm: GigaByte Way • Cc Restoration: Enabled 3. Select Objects → Channel, then ensure that the following values are set as follows: Termination State: Enabled SCSI Transfer Rate: 160M

What to do	How to do it
	<p>4. In the Configure menu, select New Configuration. Press Yes to proceed. The system should display both SCSI channels, each having one drive. SCSI ID's should be 0 for each channel. All disk drives should be in READY state.</p> <p> Note: Do not use the Load command on the Configure menu. This command is not for RAID operations.</p> <p>5. Create the first logical drive by selecting Channel-1 ID 0 (A01-01), and pressing the Spacebar. The display will change to ONLIN A01-01. Select Channel-2 ID-0 (A01-02) and again press the Spacebar. After selection, the drives will blink, press Enter or F10 to create first logical drive.</p> <p>6. Press the Space bar to Select Configuration Array. Span-1 appears in the box opened for the A01 logical drive.</p> <p>7. Configure the logical drives by pressing F10. The system prompts for each of the logical drives to consecutively select RAID 1; Size: accept the size displayed; Advanced Menu Accept SPAN = NO Change the last value to NOSPAN if required. Accept these new values by pressing Enter. The system will prompt you to save the configuration. Highlight Yes and press Enter. Exit the submenu by pressing Esc.</p> <p>8. In the main menu enter the Initialize submenu. Select the logical drive by pressing F2. Press F10 and consecutively select YES to initialize the drive pack. When done, press any key to return to the main menu.</p> <p>9. Exit the utility by pressing Esc. Save the configuration when prompted. Press Ctrl+Alt+Delete as indicated by the menu to reboot.</p>

Task summary for RAID splitting

 **Note:**

This summary should be used only after reviewing the more detailed procedures and warnings in this chapter.

What to do	How to do it
Ensure that your system is fully working and the RAID hardware	The most important thing to verify is that the RAID channel 1 is connected to the first hard drive (top as facing the machine) and channel 2 is connected to the second drive (bottom). Open the lid and follow the cables or remove one hard drive and observe which drive is marked dead

What to do	How to do it
is properly configured.	by the system. If the drive matches the graphic location on the Windows MegaRAID console, proceed with the next step.
Full data backup	Do a full data backup before RAID splitting is performed as an extra precaution.
RAID splitting  Note: Because the 703t has only one physical drive per channel, the RAID splitting can be done using the Windows MegaRAID console without risk of CallPilot database corruption.	<ol style="list-style-type: none"> 1. Load the Windows MegaRAID console. Ensure all drives are in ONLINE state (GREEN). 2. Right click the Channel 2 first drive (i.e (0) A1-2-Onln). Select Tools → Fail Drive. A warning message will pop-up. Ignore it and press OK. The drive status will change to FAILED and the color of the icon should change to RED. The alarm should start beeping.  Note: The alarm can be silenced, but under no circumstances should it be disabled. Select Adapter → Alarm Control → Silence Alarm Technically the drive that is marked FAILED is now the Backup Drive.
Perform CallPilot software upgrade	Let the system boot. The system will still run after Channel 2 of the RAID card was taken out of service and will boot to Windows. Perform the software upgrade.
RAID synching for upgrade successful	WITHOUT shutting down the server, in the Physical Devices section of the MegaRAID console, right click the Channel 2 first drive (i.e Channel 2 (0) A1-2-Failed). From the right mouse pop-up menu select Rebuild. When Rebuild is done, the drive status will change to ONLINE and the color of the icon should change to green. The alarm should stop beeping unless it was temporarily silenced. The process can take up to one hour. DO NOT shut down the machine before the rebuild is complete. If you do reboot or power down during this process, you need to do 'RAID synching for upgrade NOT successful', then start again. You can monitor the rebuild by opening the Windows MegaRAID console.
RAID synching for upgrade NOT successful	If the software upgrade has failed, the system needs to be returned to the original configuration. <ol style="list-style-type: none"> 1. Restart the server and enter the Ctrl+M utility. 2. Select Objects → Physical Drive → FAIL Drive for the drive on Channel 1. The drive will show as FAIL after this step. 3. Select the drive on Channel 2 (previously taken offline or the Backup drive) and make it ONLINE. Ignore the warning message. At this point the drive on the Channel 2 is ONLINE and the one on Channel 1 is marked FAILED. 4. Exit the utility and reboot. The system will boot up to the original configuration before the software upgrade and an audible alarm will

What to do	How to do it
	<p>indicate the state CRITICAL for the drives. At this time, you can silence the alarm but DO NOT disable it.</p> <p>5. Once the system is fully operational, open the Windows MegaRAID console and rebuild the FAIL drive on Channel 1 using the same process indicated in "RAID synching for upgrade successful". Reverting to original from a failed software upgrade is now complete. The audible alarm, if left on, should automatically stop.</p>

Chapter 11: Replacing or adding voice processing boards

In this chapter

[DSP numbering and location](#) on page 141

[Replacing MPB96 boards](#) on page 142

DSP numbering and location

DSPs are the built-in voice processing components on MPB boards. DSPs are numbered to distinguish them in Avaya CallPilot® maintenance programs, such as the Maintenance page in CallPilot Manager. Each DSP supports up to eight multimedia channels.

DSP numbering on MPB96 boards

The MPB96 board has 12 embedded DSPs. If an embedded DSP is faulty, you must replace the entire MPB96 board.




Figure 26: MPB96 board

Replacing MPB96 boards

This section describes how to replace an MPB96 board.

You will need to replace an MPB96 board:

- if the board becomes faulty
- when the PCI firmware needs to be updated, and the board must be sent back to the factory

Caution:

Risk of electrical damage

- Wear an antistatic ESD wrist strap when handling cards or boards, or when working inside the server.
- Do not touch the components or gold-edge connectors of cards or boards.
- Place the board on an antistatic surface until you are ready to install it.

Requirements

- MPB96 board (NTRH40AA)
- DS30X cable (NTRH2014) [Figure 27: DS30X cable for MPB96 board](#) on page 143 shows the DS30X cable for the MPB96 board.




Figure 27: DS30X cable for MPB96 board

*** Note:**

The ferrites on this cable control EMC emission levels. Do not remove them.




Figure 28: MPB96 board installation

*** Note:**

For Meridian 1 and Avaya Communication Server 1000 systems, the MPB96 board is installed in slot 4.

To replace an MPB96 board

1. Prepare the server for MPB96 board replacement as follows:
 - a. Shut down the server, shut off the power, and then disconnect the following cables:
 - power cable
 - peripheral device cables

- DS30X cable(s) (Meridian 1 and Communication Server 1000 only)
- b. Place the server on its side.
- c. Remove the side cover.
- d. Remove the upper fan holder foam.

For instructions, see [Preparing the server for hardware maintenance](#) on page 85.

 **Warning:**

Risk of personal injury or equipment damage

Failure to follow the procedures in [Preparing the server for hardware maintenance](#) on page 85 can result in electrical shock or equipment damage.

2. Remove the faulty MPB96 board from its slot, and save the retaining screw.
3. Unpack the replacement MPB96 board.
4. Hold the MPB96 board by its top edge or upper corners, and then align it with the following:
 - end-plate opening in the chassis Ensure that the tapered foot of the board's retaining bracket fits into the slot in the expansion slot frame.
 - PCI connector
5. Press the new MPB96 board firmly into its slot.
6. Secure the board using the retaining screw that you removed earlier.
7. Replace the upper fan holder foam.

For instructions, see [To replace the upper fan holder foam](#) on page 91.

8. Replace the server cover.

 **Note:**

Be careful not to pinch any cabling when replacing the server cover.

9. Reconnect the peripheral device and power cables.
10. Reconnect the DS30X cable to the faceplate of the MPB96 board.

 **Note:**

Ensure that a single-point ground reference is available for all the power outlets serving the Avaya CallPilot server and its peripherals. Before the CallPilot server installation, a qualified electrician must implement the single-point ground reference requirement between the power outlets of the CallPilot server and the power outlets of the switch.

11. Power up the server and log on to Windows.



When the Windows New Hardware Found Wizard pops up, press the next button and select the presented Avaya MPB driver.

12. Run the Configuration Wizard to detect the new hardware.

For instructions, refer to the Installation and Configuration Task List (NN44200-306).

Result: The MPB96 board replacement is complete.

13. Test the multimedia channels to ensure that the new MPB96 board is functioning properly.

Refer to the Installation and Configuration Task List (NN44200-306).

Chapter 12: Working with DIMMs and the CPU

In this chapter

[Replacing or adding baseboard DIMMs](#) on page 147

[Replacing the CPU](#) on page 150

Replacing or adding baseboard DIMMs

The baseboard provides four slots that support DDR266 SDRAM DIMMs. The server ships with two DIMMs that provide a total of 512 Mbytes of memory. DIMMs must be installed in pairs, and can be expanded to 8 Gbytes of memory.

DIMM sizes and compatibility

Contact your Avaya sales representative or customer support representative for a list of Avaya-supplied DIMMs for the 703t server.



Important:

Use only DIMMs that are supplied by Avaya.




Figure 29: DIMM removal and installation

When installing DIMMs, ensure that the slots are populated in order, starting with the slot closest to the power connector:

- DIMM 1A (This is the slot closest to the power connector.)
- DIMM 1B
- DIMM 2A
- DIMM 2B

To remove baseboard DIMMs

1. Prepare the server for DIMM replacement as follows:
 - a. Shut down the server, and then disconnect the power and peripheral device cables.
 - b. Place the server on its side.
 - c. Remove the side cover.

For instructions, see [Preparing the server for hardware maintenance](#) on page 85.

 **Warning:**

Risk of personal injury or equipment damage

Failure to follow the procedures in [Preparing the server for hardware maintenance](#) on page 85 can result in electrical shock or equipment damage.

2. Gently push the plastic ejector levers of the DIMM socket out and down to eject a DIMM from its socket.

 **Caution:**

Risk of equipment damage

Use extreme care when removing a DIMM. Too much pressure can damage the socket slot. Apply only enough pressure on the plastic ejector levers to release the DIMM.

3. Hold the DIMM only by its edges; be careful not to touch its components or gold-edge connectors. Carefully lift it away from the socket, and store it in an antistatic package.
4. Repeat to remove other DIMMs as necessary.
5. If you are replacing a DIMM, continue with [To install baseboard DIMMs](#) on page 149.

To install baseboard DIMMs

 **Caution:**

Risk of equipment damage and data corruption

Use only Avaya-supplied DIMMs. A mixture of dissimilar metals (from the use of other DIMMs) can cause later memory failures, resulting in data corruption.

1. Prepare the server for DIMM installation as described in [Preparing the server for hardware maintenance](#) on page 85.

 **Warning:**

Risk of personal injury or equipment damage

Failure to follow the procedures in [Preparing the server for hardware maintenance](#) on page 85 can result in electrical shock or equipment damage.

2. Hold the DIMM only by its edges when you remove it from its antistatic package.
3. Compare the length of the gold-edge connectors on the DIMM with the socket, and align them accordingly.
4. Press the DIMM firmly down until it clicks into place inside the socket.

 **Caution:**

Risk of equipment damage and data corruption

Use extreme care when installing a DIMM. Too much pressure can damage the socket. DIMMs are keyed and can be inserted in only one way.

Result: The plastic ejector levers close automatically indicating correct installation.

Replacing the CPU

The 703t server motherboard provides two connectors for Xeon processor chips, but only one is populated for Avaya CallPilot®. For a single-CPU configuration, the CPU must be installed on the CPU1 connector. A processor terminator board is not required.

CPU replacement package contents

The CPU assembly package contains the following:

- 2.0 GHz AT 400 MHz FSB microprocessor with 512 kbytes of L2 cache memory

 **Note:**

A higher frequency microprocessor may be provided if the above mentioned frequency becomes obsolete.

- heat sink with guides and clips
- syringe containing heat sink grease
- heat sink housing
- fan

 **Warning:**

Risk of equipment damage

The microprocessor is extremely sensitive to electrostatic discharge (ESD) and requires careful handling to avoid static damage. To prevent ESD, perform the replacement at an ESD workstation or use an ESD wrist strap.

To remove the faulty CPU

1. Prepare the server for CPU replacement as follows:
 - a. Shut down the server, and then disconnect the power and peripheral device cables.
 - b. Place the server on its side.
 - c. Remove the side cover.
 - d. Remove the upper fan holder foam.

For instructions, see [Preparing the server for hardware maintenance](#) on page 85.

 **Warning:**

Risk of personal injury or equipment damage

Failure to follow the procedures in [Preparing the server for hardware maintenance](#) on page 85 can result in electrical shock or equipment damage.

2. Disconnect the processor fan cable, and then remove the processor fan.

For instructions, see [To remove the processor fan](#) on page 101.

3. Using both hands, remove the heat sink housing, as follows:
 - a. Grasp the bottom edge of one side of the heat sink housing, and pry the bottom tabs away from the heat sink.

 **Caution:**

Risk of equipment damage

Ensure that you do not bend the wings of the heat sink while removing the heat sink housing as this will cause damage to the heat sink.

- b. Repeat step [3.a](#) on page 151 for the other side.
- c. Lift the housing away from the heat sink.




Figure 30: CPU housing

4. Remove the clips that secure the heat sink to the motherboard, as shown in [Figure 31: Heat sink attached to motherboard](#) on page 153.




Figure 31: Heat sink attached to motherboard

⚠ Caution:

Risk of equipment damage

Ensure that you do not bend the wings of the heat sink while removing the clips as this will cause damage to the heat sink.

5. Remove the heat sink.
6. Remove the microprocessor as shown in [Figure 32: Remove microprocessor from heat sink](#) on page 154.




Figure 32: Remove microprocessor from heat sink

- a. Lift the lever that secures the microprocessor to the motherboard.
While applying gentle downward pressure, push the lever away from you (towards the top of the server), and then lift it all the way to the left.
 - b. Remove the microprocessor, and put it in an antistatic package.
7. Continue with [To install a new CPU](#) on page 154.

To install a new CPU

⚠ Caution:

Risk of electrical damage

Wear an antistatic ESD wrist strap during the entire CPU replacement process.

1. Remove the new microprocessor from its antistatic package.

⚠ Caution:

Risk of equipment damage

Do not touch the pins on the microprocessor. The pins are static-sensitive and bend easily.

2. Install the new microprocessor and heat sink as shown in [Figure 33: Install new CPU](#) on page 155. See also the description that follows on [2.a](#) on page 155.




Figure 33: Install new CPU

- a. Ensure that the microprocessor lever is open all the way to the left.
- b. Align the gold triangle on one corner of the microprocessor with the gold triangle on the socket.

 **Note:**

See the top left corner of the microprocessor in the photograph in step [6](#) on page 153 on [6](#) on page 153.

- c. Apply gentle downward pressure to the microprocessor to seat it in its socket.
 - d. Lower and secure the lever.
 - e. Apply all of the thermal grease in the syringe that was provided in the CPU assembly package to the metal square on the microprocessor.
 - f. Place the heat sink on top of the microprocessor, and then apply light pressure in a circular motion to spread the grease evenly over the entire metal square.
3. Install the heat sink clips as shown in [Figure 34: Install heat sink clips](#) on page 157. See also the description that follows.

 **Caution:**

Risk of equipment damage

Ensure that you do not bend the wings of the heat sink while installing the clips as this will cause damage to the heat sink.





Figure 34: Install heat sink clips

- a. Align the side tabs on the clip over the heat sink guide.
 - b. Align the center hole on the clip over the tab on the heat sink guide.
 - c. Slide the clip forward or back until the tab is in the small portion of the hole.
 - d. With both hands, apply even downward pressure on the ends of the clip until it snaps into place over the end tabs on the heat sink guides.
4. Use both hands to install the heat sink housing assembly as shown in [Figure 35: Install heat sink housing](#) on page 158. See also the description that follows on [4.a](#) on page 158.



G101788

Figure 35: Install heat sink housing

- a. Grasp the bottom edge of each side of the heat sink housing.
 - b. Spread the sides of the housing slightly, and then lower the housing over the heat sink.
 - c. Release the housing to engage the tabs around the edge of the heat sink's platform.
 - d. Apply pressure to the top of the housing and work with the bottom tabs until the housing snaps into place. When all four tabs are secured, the housing will not move.
5. Install the processor fan.
For instructions, see [Figure 18: install processor fan](#) on page 102.
 6. Replace the upper fan holder foam.
 7. Replace the server's side cover.

8. Reconnect all peripheral device cables and power cord.
9. Restart the server and ensure that Avaya CallPilot starts.

Chapter 13: Working with the Avaya CallPilot® server BIOS

In this chapter

[Overview](#) on page 161

[BIOS settings](#) on page 162

[Updating and configuring the BIOS](#) on page 166

[Recovering from corrupted CMOS and BIOS](#) on page 167

Overview

The BIOS of the server defines the server compatibility with expansion hardware. All systems configured by Avaya are shipped with at least the minimum vintage BIOS. However, new BIOS may be issued to support new hardware standards and options.

BIOS release

The following are tested and supported releases of BIOS and firmware for the server:

- Intel BIOS release: P16 Build 75 or P07 Build 64
 - firmware: BMC 1.18 FRU/SDR 5.5i
-

To determine the BIOS release

1. Start (or restart) the server.
2. Read the BIOS version on the display.

The BIOS version appears after the MAC address information.

You can also find the BIOS version in the BIOS configuration sections in the server menu. See [To configure the BIOS](#) on page 166 for instructions.

BIOS settings

This section identifies the 703t server BIOS settings:

- Main ([Main](#) on page 162)
- Advanced (see [Advanced](#) on page 163)
- Security (see [Security](#) on page 164)
- Server (see [Server](#) on page 164)
- Boot (see [Boot](#) on page 165)

See [To configure the BIOS](#) on page 166 for instructions on how to verify that the 703t server settings are set to the values given in the following sections.

Main

Table 17: Main BIOS settings

Options	Settings
System Time	Set for the current time.
System Date	Set for the current date.
Floppy A:	1.44/1.25/1.2 Mbytes, 3.5 inch
Hard Disk Pre-Delay	Disabled
Primary IDE Master	CD-ROM
Primary IDE Slave	None
Secondary IDE Master	None
Secondary IDE Slave	None
Processor Settings	<ul style="list-style-type: none">• Processor POST speed setting: 2 GHz (shown in grey)• Processor Retest: Disabled• Processor Hyperthreading: Enabled

Options	Settings
	<ul style="list-style-type: none"> • Processor 1 CPU ID: F24 (shown in grey) • Processor 1 CPU L2 Cache size: 512k ECC (shown in grey) • Processor 2 CPU ID: Not installed (shown in grey) • Processor 2 CPU L2 Cache size: (shown in grey)
Language	English (US)

Advanced

Table 18: Advanced BIOS settings

Options	Settings
PCI Configuration	<p>Use default values. Default values are generated by pressing F9 before you change CMOS values.</p> <ul style="list-style-type: none"> • USB: Enabled • NIC1: Enabled • NIC2: Enabled • Video: Enabled • SCSI: Enabled • Option ROM: Enabled (where applicable) • PCI slots ROM: Enabled
Integrated Peripheral Configuration	<ul style="list-style-type: none"> • COM1: 3f8/IRQ4 • COM2: 2f8/IRQ3 • Parallel Port: ECP/378/IRQ7/DMA Channel 3 • Floppy disk controller: Enabled • Legacy USB support: Auto • Front Panel USB: Disabled
Memory Configuration	<ul style="list-style-type: none"> • Extended memory test: Disabled • Bank 1: Installed • Bank 2: Not installed (shown in grey) • Memory Retest: Disabled

Options	Settings
Advanced Chipset Control	<ul style="list-style-type: none"> • Wake on Ring: Disabled • Wake on LAN: Disabled • Wake on PME: Disabled • Wake on RTC alarm: Disabled
Boot Time Diag Screen	Enabled
Reset Config Data	No
Num Lock	On
Sleep Button	Disabled

Security

Table 19: Security BIOS settings

Options	Settings
Use Password Is	Not Installed
Supervisor Password Is	Not Installed
Fixed Disk Boot Sector	None
Power Switch Inhibit	Disabled
NMI Control	Enabled

Server

Table 20: Server BIOS settings

Options	Settings
System Management	System Info (shown in grey)
Console Redirection	<ul style="list-style-type: none"> • BIOS redirection port: Disabled • ACPI redirection: Disabled • Baud Rate: 19.2K

Options	Settings
	<ul style="list-style-type: none"> • Flow Control: CTS/RTS • Terminal Type: VT100+
Event Log Configuration	<ul style="list-style-type: none"> • Clear All Events logs: No • Event Logging: Enabled • Critical Event Logging: Enabled
Fault Resilient Booting	<ul style="list-style-type: none"> • Late POST timeout: Disabled • Fault Resilient Booting: Stay on • Hard Disk OS Boot Timeout: Disabled • PXE OS boot timeout: Disabled
Assert NMI on PERR	Disabled
Assert NMI on SERR	Disabled
FRB-2 Policy	Disable BSP
AC Link	[Last State]
POST Error Pause	Enabled
Boot Monitoring	Disabled
Boot Monitoring Policy	Retry 3 times

Boot

Table 21: Boot BIOS settings

Options	Settings
BOOT Device Priority	<ul style="list-style-type: none"> • Removable Devices • Hard Drive • ATAPI CDROM • IBA 4.1.04 Slot 0118 • IBA GE Slot 0120
V1109	Disabled
Hard Disk Drives	Do Not Change
Removable Devices: ATAPI CDROM Drives	Do Not Change

Updating and configuring the BIOS

BIOS update availability

 **Important:**

The BIOS installed on the Avaya CallPilot server must be version P07 Build 64 or P16 Build 75. The BIOS versions cannot be updated, nor can P07 Build 64 be updated to P16 Build 75. A BIOS update can cause your system to crash.

To configure the BIOS

 **Note:**

Only options that need to be changed from their defaults are described below. As you perform this procedure, you should still validate that all BIOS settings conform to the values listed in [BIOS settings](#) on page 162.

1. During the server startup and while the startup diagnostics still appear on the screen, press F2 to display the Main menu screen.
2. Press BIOS Default (F9) to load the default BIOS settings.
Result: You are prompted to confirm the settings.
3. Choose Yes, and then press Enter.
Result: The Main menu reappears.
4. Use the right and left arrow keys to choose the Advanced screen.
Result: A list of configuration sections appears.
5. Configure the sections as follows:
 - Boot-up Diag Screen: Enabled
 - Num Lock: ON
 - Sleep Button: Disabled
6. Use the right and left arrow keys to choose the Server screen.
Result: A list of configuration sections appears.

7. Configure the sections as follows:
 - Assert NMI on PERR: Disabled
 - Assert NMI on SERR: Disabled
8. Use the right and left arrow keys to choose the Boot screen.
Result: A list of configuration sections appears.
9. Ensure the boot device order is defined as follows:
 - first: floppy drive
 - second: hard drive
 - third: CD-ROM drive

 **Note:**

The CallPilot operating system requires that the first startup be completed from the CD-ROM drive. To achieve this during the startup process, press Esc to display the boot menu, and then choose ATAPI CD-ROM to start the server temporarily from the CD-ROM.

 **Note:**

The hard drive boot option will not appear in the list if the RAID packs are not configured.

10. Use the right and left arrow keys to choose the Exit screen.
11. Choose the Exit Saving Changes option, and then press Enter.
Result: You are prompted to confirm.
12. Choose Yes to save the changes, and then press Enter.
Result: The server restarts.

Recovering from corrupted CMOS and BIOS

If the system functions abnormally (for example, it does not start up or it freezes during the startup process), the CMOS may be corrupted. To correct this, follow the procedure in "[To recover from a corrupted CMOS](#) on page 168" below.

To recover from a corrupted CMOS

1. Power down the server.
2. Remove the server cover and access the motherboard.
3. Move the CMOS Clear jumper (J1H1) to pins 2 and 3 (by default, the jumper is set to pins 1 and 2).


To determine the jumper location, see [Figure 36: Jumper locations and settings](#) on page 169.

4. Power up the server.

Result: A message appears stating that the CMOS has been cleared (reset to factory defaults).

5. Power down the server.
6. Move the CMOS Clear jumper (J1H1) back to pins 1 and 2.
7. Replace the server cover.
8. Power up the server.
9. Perform CMOS setup.

For instructions, see [To configure the BIOS](#) on page 166.



G101769

Figure 36: Jumper locations and settings

Chapter 14: 703t description reference

In this appendix

[Server features](#) on page 171

[Slot assignments](#) on page 176

[IRQ mapping table](#) on page 177

Server features


This section provides a general overview of the 703t server.

Table 22: Server dimensions

Height	chassis only: 420 mm (16.75 in.) with chassis feet: 440 mm (17.5 in.)
Width	chassis only: 215 mm (8.6 in.) with chassis feet: 320 mm (12.7 in.)
Depth (distance from front to back)	650 mm (26 in.)
Clearance	<ul style="list-style-type: none">• front: 250 mm (10 in.)• rear: 125 mm (5 in.)• side: 75 mm (3 in.) <p> Note: Additional side clearance is required for service.</p> <ul style="list-style-type: none">• top: 75 mm (3 in.)
Weight of fully loaded system with <ul style="list-style-type: none">• two SCSI hard drives• six populated boards• CD-ROM drive	approximately 22 kg (46 lb)

- floppy drive
- tape drive

Front panel features



G101769

Figure 37: 703t server front panel features

[Table 23: Front panel features](#) on page 172 describes the parts identified in [Figure 37: 703t server front panel features](#) on page 172.

Table 23: Front panel features

Part	Function
Reset button	Triggers a hardware (cold) reset. Do not use this button to perform a server restart. Restart the server as described in "Restarting the server" in <i>Installation and Configuration Task List</i> (NN44200-306).
Network controller LEDs (green)	Left: 10/100Base-T controller LED (NIC1 10/100 MB: ELAN for Meridian 1/Communication Server 1000 connection)

Part	Function
	Right: 10/100/1000Base-T controller LED (NIC2 1 GB: CLAN for Customer LAN connection)
Sleep mode button	Not used
Power button	Turns the server's power on or off.
Status LEDs	<p>Indicate when the server is powered up and the disk drives are active.</p> <ul style="list-style-type: none"> • Left: hard drive activity LED (not used) • Center: power/sleep LED (green) • Right: status LED (bi-color) indicates whether the server is functioning properly, or whether a hardware event has occurred.
USB connector	For future use
Floppy disk eject button	Ejects the floppy disk.
Floppy drive	Drive for 3-1/2 inch diskettes.
IDE CD-ROM drive (5.25 in.)	Enables you to use the Avaya CallPilot® software and documentation CD-ROMs.
CD drive eject button	Opens the CD-ROM drawer. Push the button again to close the drawer.
Backup tape drive	Allows backup of hard drive data.
Hard drive 1	10,000 rpm hard drive
Hard drive 2	10,000 rpm hard drive
Drive bay	Vacant
Drive bay	Vacant
Drive bay	Vacant
Air flow slot	Must remain empty for proper system cooling.

Rear panel diagram




Figure 38: 703t server rear panel features

*** Note:**

For more information, see [Slot assignments](#) on page 176.

Table 24: 703t server rear panel parts

Part	Color
AC power supply connector (450 W non hot-swap power supply)	Not applicable
USB connectors	Not applicable
PS/2 keyboard connector	Purple

Part	Color
PS/2 mouse connector	Green
COM1 serial port connector (9-pin)	Teal
Parallel port connector (25-pin)	Pink
Monitor connector (15-pin)	Blue
10/100/1000Base-T CLAN network connector for Customer LAN connection (NIC2 1 GB)	Not applicable
 Note: For more information, refer to the description of LAN connectivity in 703t Server Hardware Installation (NN44200-304).	
10/100Base-T ELAN network connector for Meridian 1/ Communication Server 1000 connection (NIC1 10/100 MB)	Not applicable
 Note: For more information, refer to the description of LAN connectivity in 703t Server Hardware Installation (NN44200-304).	
PCI slots (6)	Not applicable
<ul style="list-style-type: none"> • Four slots are 100 MHz 3.3 V 64-bit PCI slots. • Two slots are 33 MHz 5 V 32-bit PCI slots. 	
 Note: For more information, see Slot assignments on page 176.	
COM2 serial port connector slot (not installed)	Teal

Table 25: Environmental specifications

Environmental condition	Specification
Operating temperature	10°C to 35°C (50°F to 95°F) Maximum rate of change must not exceed 10°C (50°F) per hour.
Non-operating (storage) temperature	-40°C to 70°C (-40°F to 158°F)
Non-operating humidity	95%, non-condensing at 30°C (86°F)
Altitude	1829 m (6000 ft)
Electrostatic discharge	15 kV or more
Acoustic noise	50 dBA in a typical office ambient temperature (18°C to 25°C [64.4°F to 77°F])

Environmental condition	Specification
Operating shock	No errors with a half sine wave shock of 2G (with 1 millisecond duration)
Handling drop	Operational after a free fall from 450 mm to 600 mm (18 in. to 24 in.) (depending on weight)

Slot assignments

The slot assignment tables show:

- the physical location of boards inside the server, relative to other boards
- the order in which boards are installed (for example, board #1, 2, 3, and so on)
- how the boards are represented in CallPilot Manager applications (that is, on the Maintenance Administration page)
- the maximum capacity for each switch connectivity

 **Note:**

Your server may vary depending on what was ordered from Avaya; therefore, your server may not have all of the slots populated.

Slot definition and numbering

In [Table 26: Slot definition and numbering](#) on page 176, the term "slot" refers to the available slot openings in the chassis, not the PCI connectors inside the server.

The slots are numbered from the bottom of the server to the top. Slot 1 is the bottom slot in the chassis when the chassis is standing upright.

Table 26: Slot definition and numbering

Slot number	CallPilot-assigned board label ^a	Meridian 1 or Communication Server 1000
PCI slot 7 (full length)	Not used	Not used
PCI slot 6 (full length)	BRD06	RAID card
PCI slot 5 (full length)	BRD05	Not used
PCI slot 4 (full length)	BRD04	MPB96 board

Slot number	CallPilot-assigned board label ^a	Meridian 1 or Communication Server 1000
PCI slot 3 (full length)	BRD03	Not used
PCI slot 2 (full length)	BRD02	Not used
PCI slot 1 (full length)	BRD01	Not used

a. In CallPilot Manager applications, the Callpilot-assigned board label may appear. This label corresponds to the slot number. For example, BRD01 refers the board in slot 1.

IRQ mapping table

[Table 27: IRQ mapping](#) on page 177 lists the assignments for each Interrupt Request (IRQ). You do not need this information for installation, but it may be useful for troubleshooting.

Table 27: IRQ mapping

Interrupt	I/O APIC level	Slot or device
INTR	INT0	Processor interrupt
IRQ0	INT2	Timer (from PIIX4)
IRQ1	INT1	PS/2 keyboard controller
IRQ2	Not applicable	Internal/reserved
		 Note: IRQ2 is actually shared with IRQ9 as a cascade interrupt to support IRQs 8–15.
IRQ3	INT3	Onboard serial port B (COM2)
IRQ4	INT4	Onboard serial port A (COM1)
IRQ5	INT5	Available
IRQ6	INT6	Floppy disk drive controller
IRQ7	INT7	Parallel port 1(LPT1)
IRQ8	INT8	Real Time Clock
IRQ9	INT9	Available
IRQ10	INT10	Available
IRQ11	INT11	Available

Interrupt	I/O APIC level	Slot or device
IRQ12	INT12	PS/2 mouse
IRQ13	INT13	Internal/reserved
IRQ14	INT14	IDE controller
IRQ15	INT15	Available

Index

Numerics

703t server	
dimensions	171
environmental specifications	174
front panel, description	172
hard drive bays	172
IRQ assignments	177
LEDs	172
PCI slots	174
slot assignments	176
slot locations	174

A

Alarm Monitor, using	59, 60
alarms	
about	58, 59
investigating	60
alert icons, component states	65
application event log	
description	37
arp command	43, 44
parameters and descriptions	43
running from Windows	44
syntax	43

B

beep codes	28
interpretation	28
BIOS	
configuring	166
upgrading	
overview	161
vintage	161

C

cabling	
RAID system	
with CD-ROM and tape drive	105
call channels	
disabling	62
working with	73
CallPilot	

utilities	
Diagnostics Tool	75
PEP Maintenance	75, 77
Session Trace	75, 78
System Monitor	75
CallPilot Manager	
Alarm Monitor, using	59, 60
alarms	
about	58, 59
investigating	60
alert icons, component states	65
Channel Monitor, using	61, 73
Event Browser, using	60, 61
events	
about	58, 60
investigating	61
fault management	
alarm notification	58
event processing	58
Maintenance screen	
General section	62
Maintenance section	62
purpose	62
Multimedia Monitor, using	61, 72, 73
CallPilot services, Channel Monitor tab	81
CD-ROM	
cabling	105
Channel Monitor tab	80–82
CallPilot services	81
critical	81
DS30X links pane in	82
DSP pane in	82
Channel Monitor, using	61, 73
channels	
call, working with	73
disabling	62
multimedia, working with	72, 73
chassis	
accessing	86
chkdsk	
Windows	51, 52
chkdsk utility	47, 48
parameters and descriptions	47
running from Windows	48
syntax	47
commands	
Net Start	55

Net Stop	50	TCP/IP	36, 39–43, 45, 46
TSTSERIO	51–53	arp	43
commands, TCP/IP		ipconfig	40
arp	43	nbtstat	45
ipconfig	40	netstat	46
nbtstat	45	ping	41
netstat	46	tracert	42
ping	41	diagnostics tool	
tracert	42	CallPilot	75
compatibility		diagrams	
DIMMs	147	front panel	172
components		rear panel	174
CallPilot Manager maintenance activities	63	dimensions, 703t server	171
dependencies	58	DIMMs	
diagnostics that can be run	69	compatibility	147
diagnostics-eligible	69	motherboard	
list	62	installing	149
replacing	13	removing	147
states		sizes	147
Alert icons	65	sizes and compatibility	147
description	64	distributor	11
viewing	65	documentation	11, 14
configuring		map	14
BIOS	166		
cooling fan		E	
removing	93	environmental specifications, 703t server	174
replacing	96, 99, 101	error messages	28
Courtesy stop, description	66	POST	28
CPU servers		Event Browser, using	60, 61
BIOS settings	166	event log	
configuring the BIOS	166	system	37
critical services, CallPilot	81	event logs	
customer service	11	application	37
		security	37
D		types, description	37
diagnostic tools		viewing	37
Power-On Self Test (POST)	19	events	
RAID controller	19	about	58, 60
SCSI controller	19	investigating	61
TSTSERIO tests	51–53		
diagnostics		F	
integrated		failure to boot into service	
running	68, 70, 71	boot failure	19
troubleshooting failures	69	fan	
when to run	68	removing	93
last results		replacing	96, 99, 101
viewing	71	fault management	
POST	28	alarm notification	58
serial port		event processing	58
overview	49		
startup	19		

firmware	
vintage	161
Firmware revision	
verifying	126
firmware, flashing the	130
flashing the	127
front panel, description	172

G

General section, Maintenance screen	62
---	--------------------

H

hard drive bays	172
hardware	
motherboard DIMMs	
installing	149
removing	147
peripherals	
cables	86
RAID system	
cabling	105
SCSI bus	
cabling	105
SCSI drive	
installing	107
removing	109
hardware problems, detecting	59

I

IDE hard drive	
LED	25
installation	
cooling fan	96 , 99 , 101
motherboard DIMMs	149
SCSI drive	107
integrated diagnostics	
running	70 , 71
troubleshooting failures	69
when to run	68
ipconfig command	40
flags and descriptions	40
running from Windows	40
syntax	40
ipconfig default	40
IRQ assignments, 703t server	177

L

LEDs	
------	--

IDE drive	25
network	21
network controller	172
power status	23
SCSI device	22 , 24
system status	172
Legend/Help tab	83
logs	
event, viewing	37
types, viewing	37

M

maintenance	
activities by component	63
preparing for	14
Maintenance screen, CallPilot Manager	
General section	62
Maintenance section	62
purpose	62
mapping	166
PCI IRQs to I/O APIC	166
motherboard	
removing DIMMs	147
multimedia channels, working with	72 , 73
Multimedia Monitor, using	61 , 72 , 73

N

nbtstat command	45 , 46
parameters and descriptions	45
running from Windows	46
syntax	45
Net Start command	55
Net Stop command	50
netstat command	46 , 47
parameters and descriptions	46
running from Windows	47
syntax	46
network LED	21

P

parts, obtaining replacement	13
PCI slots	174
PEP Maintenance utility	75 , 77
peripherals	
cables	86
ping command	41
parameters and descriptions	41

running from Windows	41	diagnostics	19
syntax	41	SCSI device LED	22 , 24
power status LED	23	SCSI drive	
Power-On Self Test (POST)	19 , 28	installing	107
beep codes	28	removing	109
meaning	28	SCSI ID	113
countdown codes	28	security event log	
diagnostics	28	description	37
error codes	28	serial port	
error messages	28	diagnostics	49
interpreting messages	28	server	
message formats	28	dimensions	171
		environmental specifications	174
Q		fan	
quitting		removing	93
system	49	replacing	96 , 99 , 101
		front panel, description	172
R		hard drive bays	172
RAID	125 , 127	IRQ assignments	177
upgrading	127	LEDs	172
RAID configuring summary	136	mapping	166
RAID controller		mapping PCI IRQs to I/O APIC	166
diagnostics	19	PCI slots	174
RAID firmware		slot assignments	176
upgrading	130	slot locations	174
RAID splitting summary	137	servicing	
RAID system		fan	93 , 96 , 99 , 101
cabling	105	Session Trace utility	75 , 78
with CD-ROM and tape drive	105	settings	
configuring	128	BIOS	166
rear panel, description	174	shutting down	
Redundant Array of Independent Disks (RAID)	125	system	49
removing		sizes	
fan	93	DIMMs	147
motherboard DIMMs	147	slot assignments	176
SCSI drive	109	slot locations	174
replacement parts, obtaining	13	specifications, environmental	174
replacing		speed setting for CPU	166
fan	96 , 99 , 101	startup	
motherboard DIMMs	147 , 149	diagnostics	19
SCSI drive	107 , 109	Stop, description	67
reseller	11	system	
restarting system after TSTSERIO tests	54	restarting after TSTSERIO tests	54
		shutting down	49
S		system event log	
SCSI bus		description	37
cabling	105	System Info tab	82
SCSI controller		System Monitor	75 , 80 , 82 , 83
		Channel Monitor tab	80
		Legend/Help tab	83
		System Info tab	82

using	80
system utilities	
System Monitor	80

T

tape drive	
cabling	105
configuring	113
faulty, replacing	114
TCP/IP diagnostics	36 , 39–43 , 45 , 46
arp	43
ipconfig	40
nbtstat	45
netstat	46
ping	41
tracert	42
testing	
POST diagnostics	28
tracert command	42 , 43
parameters and descriptions	42
running from Windows	43
syntax	42
training	11
TSTSERIO command	51

U

upgrading	
BIOS	
overview	161
utilities	
chkdsk	47
Diagnostics Tool	75
PEP Maintenance	75 , 77
Session Trace	75 , 78
System Monitor	75 , 80

V

viewing	37
vintage	
BIOS	161
BIOS and SSU	161

W

Windows	
chkdsk utility	51 , 52
viewing	37

