



# **Avaya CallPilot® 201i Server Maintenance and Diagnostics**

5.0  
NN44200-705, 01.05  
December 2010

## Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

## Documentation disclaimer

"Documentation" means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya generally makes available to users of its products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

## Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

## Warranty

Avaya provides a limited warranty on its Hardware and Software ("Product(s)"). Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this Product while under warranty is available to Avaya customers and other parties through the Avaya Support Web site: <http://support.avaya.com>. Please note that if you acquired the Product(s) from an authorized Avaya reseller outside of the United States and Canada, the warranty is provided to you by said Avaya reseller and not by Avaya.

## Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO/](http://support.avaya.com/licenseinfo/) ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

## Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, or Hardware provided by Avaya. All content on this site, the documentation and the Product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

## Third-party components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: <http://support.avaya.com/Copyright>.

## Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation and Product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation and Product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners, and "Linux" is a registered trademark of Linus Torvalds.

## Downloading Documentation

For the most current versions of Documentation, see the Avaya Support Web site: <http://support.avaya.com>.

## Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your Product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: <http://support.avaya.com>.

## Japan VCCI statement

The following applies to server models 1006r, 1005r, 703t, 201i, and 1002rp:

この装置は、情報処理装置等電波障害自主規制協議会 (VCCI) の規定に基づくクラスA装置です。この装置を家庭環境で使用すると電波障害を引き起こすことがあります。この場合には使用者が適切な対策を取るようにより要求されることがあります。

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may occur, in which case, the user may be required to take corrective action.

# Contents

<b>Chapter 1: Customer service</b>	<b>9</b>
Getting technical documentation	9
Getting product training	9
Getting help from a distributor or reseller	9
Getting technical support from the Avaya Web site	10
<b>Chapter 2: About this guide</b>	<b>11</b>
In this chapter	11
Maintenance and diagnostics overview	11
Introduction	11
Who should read this guide	11
Resolving system problems	12
Preparing for hardware or software maintenance	12
Performing hardware maintenance	12
Rebuilding the CallPilot system	12
Resolving system problems	13
Introduction	13
Using this guide	13
Using the CallPilot Administrator's Guide	14
Using the CallPilot Troubleshooting Guide	14
Replacing hardware components	14
Introduction	14
Approved replacement parts	15
Preparing for maintenance activities	15
Reference documents	15
<b>Chapter 3: Troubleshooting your Avaya CallPilot® system</b>	<b>19</b>
In this chapter	19
Overview	19
Introduction	19
LEDs and HEX display on the 201i server faceplate	20
Startup sequence and diagnostic codes	20
Section A: LED and HEX displays	20
In this section	20
Status LEDs and HEX display location	21
Interpreting the power status LED	22
Introduction	22
Power status LED functions	22
Power status LED indications	22
Interpreting the MPC slot LEDs	23
Introduction	23
MPC slot LED functions	23
MPC slot LED indications	24
Interpreting the network and drive activity LEDs	24
Introduction	24
Network LED states	25
IDE drive LED states	25
SCSI device LED states	25

Interpreting the HEX display.....	26
Introduction.....	26
HEX display codes.....	26
Section B: Startup diagnostics.....	28
In this section.....	28
Startup diagnostic codes.....	28
Introduction.....	28
Critical startup diagnostic codes.....	29
Non-critical operating system and switch diagnostic codes.....	29
P:XX failure codes.....	31
Startup sequence description.....	31
Introduction.....	31
Troubleshooting startup problems.....	33
Introduction.....	33

**Chapter 4: Using the operating system online diagnostic tools.....35**

In this chapter.....	35
Overview.....	35
Introduction.....	35
Operating system Event Viewer.....	35
Operating system Diagnostics.....	36
TCP/IP diagnostics.....	36
Viewing event logs.....	36
Introduction.....	36
Types of event logs.....	37
Where to get more information.....	37
Using TCP/IP diagnostic tools.....	40
Introduction.....	40
The ipconfig command.....	40
Ipconfig default.....	40
Ipconfig command syntax.....	40
The ping command.....	41
Ping command syntax.....	41
The tracert command.....	42
How tracert works.....	42
Tracert syntax.....	43
Tracert parameters.....	43
The arp command.....	44
Arp command syntax.....	44
The nbtstat command.....	45
Nbtstat command syntax.....	45
The netstat command.....	46
Netstat command syntax.....	46

**Chapter 5: Using CallPilot Manager to monitor hardware.....49**

In this chapter.....	49
Understanding fault management.....	50
Introduction.....	50
Event processing.....	50
Alarm notification.....	50
Section A: Tools for isolating and fixing hardware problems.....	51
In this section.....	51

Overview.....	51
Introduction.....	51
Component dependencies.....	51
Detecting hardware problems.....	52
Alarm Monitor.....	52
Introduction.....	52
About alarms.....	53
See also.....	53
Event Browser.....	54
Introduction.....	54
About events.....	54
See also.....	55
Maintenance page.....	55
Introduction.....	55
More information.....	55
Channel and Multimedia Monitors.....	55
Introduction.....	55
Disabling call channels.....	56
Running diagnostics on call channels.....	56
Section B: Working with the Maintenance page.....	56
In this section.....	56
Introducing the Maintenance page.....	57
Introduction.....	57
What the Maintenance page provides.....	57
Maintenance activities for each component.....	58
Viewing component states.....	59
Introduction.....	59
Component states.....	59
Alert icons.....	60
Starting and stopping components.....	61
Introduction.....	61
Stop versus courtesy stop.....	61
Courtesy stop.....	62
Stop.....	62
Components that can be started and stopped.....	62
Running integrated diagnostics.....	64
Introduction.....	64
Before you begin.....	64
Components that have diagnostic tests available.....	64
Diagnostic tests available for each component.....	65
If a diagnostic test fails or cannot be run.....	65
Viewing the last diagnostic results.....	67
Introduction.....	67
Last diagnostic results.....	69
Section C: Working with the Multimedia and Channel Monitors.....	70
In this section.....	70
Working with the Multimedia Monitor.....	70
Introduction.....	70
Working with the Channel Monitor.....	71
Introduction.....	71

<b>Chapter 6: Using Avaya CallPilot® system utilities.....</b>	<b>75</b>
In this chapter.....	75
Overview.....	75
Introduction.....	75
Accessing the system utilities.....	76
Diagnostics Tool.....	76
Introduction.....	76
To access the Diagnostics Tool.....	76
To enable startup diagnostics.....	77
To disable startup diagnostics.....	77
PEP Maintenance utility.....	78
Introduction.....	78
To access the PEP Maintenance utility.....	78
Session Trace.....	79
Introduction.....	79
To access the session trace tool.....	79
To find a session.....	80
Session type information.....	82
System Monitor.....	85
Introduction.....	85
To access the System Monitor.....	85
About the Channel Monitor tab.....	85
CallPilot services.....	86
DSPs.....	87
DS30X links.....	87
About the System Info tab.....	88
About the Legend/Help tab.....	88
<b>Chapter 7: Performing hardware maintenance and mechanical assembly.....</b>	<b>91</b>
In this chapter.....	91
Overview.....	91
Introduction.....	91
Equipment required.....	92
Before you begin.....	92
Removing the server from the switch.....	92
Introduction.....	92
Equipment required.....	93
What is next?.....	93
Replacing the server.....	93
Introduction.....	93
201i server component diagram: exploded view.....	94
201i server component diagram: complete assembly.....	95
Legend.....	96
Replacing the IDE hard drive.....	97
Introduction.....	97
Equipment required.....	97
Before you begin.....	98
Hard drive assembly diagram.....	98
What is next?.....	108
Replacing the software feature key.....	108
Introduction.....	108

Equipment required.....	108
Before you begin.....	108
Replacing Multimedia Processing Cards.....	110
Introduction.....	110
Supported MPC-8 card versions.....	110
What the MPC-8 card looks like.....	110
Correct card insertion.....	111
Location of MPC slots.....	112
<b>Index.....</b>	<b>115</b>



# Chapter 1: Customer service

Visit the Avaya Web site to access the complete range of services and support that Avaya provides. Go to [www.avaya.com](http://www.avaya.com) or go to one of the pages listed in the following sections.

## Navigation

- [Getting technical documentation](#) on page 9
- [Getting product training](#) on page 9
- [Getting help from a distributor or reseller](#) on page 9
- [Getting technical support from the Avaya Web site](#) on page 10

---

## Getting technical documentation

To download and print selected technical publications and release notes directly from the Internet, go to [www.avaya.com/support](http://www.avaya.com/support).

---

## Getting product training

Ongoing product training is available. For more information or to register, you can access the Web site at [www.avaya.com/support](http://www.avaya.com/support). From this Web site, you can locate the Training contacts link on the left-hand navigation pane.

---

## Getting help from a distributor or reseller

If you purchased a service contract for your Avaya product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

---

## Getting technical support from the Avaya Web site

The easiest and most effective way to get technical support for Avaya products is from the Avaya Technical Support Web site at [www.avaya.com/support](http://www.avaya.com/support).

# Chapter 2: About this guide

---

## In this chapter

[Maintenance and diagnostics overview](#) on page 11

[Resolving system problems](#) on page 13

[Replacing hardware components](#) on page 14

---

## Maintenance and diagnostics overview

---

### Introduction

The maintenance and diagnostic activities discussed in this guide are divided into two groups of activities:

- troubleshooting and diagnostics (identifying the cause of and resolving system problems)
- performing hardware maintenance

For a list of Avaya CallPilot® documentation, see the document map on page [Reference documents](#) on page 15.

---

### Who should read this guide

This guide is for administrators, technicians, and engineers responsible for maintaining an Avaya CallPilot server. It is intended to act as a guide for:

- using system tools to identify the cause of system problems
- installing, replacing, or upgrading hardware components

This guide assumes that you have basic computing skills and are familiar with necessary safety procedures. For more information about safety, refer to *CallPilot Fundamentals* (NN44200-100).

---

## Resolving system problems

This guide describes how to use a variety of CallPilot resources for resolving system problems.

If you cannot resolve your problem with the resources described in this guide, you can also refer to the following documents:

- CallPilot Administrator's Guide (NN44200-601)
- CallPilot Troubleshooting Guide (NN44200-700)

 **Note:**

For more details, see [Resolving system problems](#) on page 13.

---

## Preparing for hardware or software maintenance

The CallPilot Installation and Configuration Task List (NN44200-306) explains how to restart, shut down, and power up the Avaya CallPilot server. You may be asked to perform one or more of these tasks while maintaining your server.

---

## Performing hardware maintenance

[Performing hardware maintenance and mechanical assembly](#) on page 91 explains how to replace hardware components. For more details, see [Replacing hardware components](#) on page 14.

---

## Rebuilding the CallPilot system

When you purchased your CallPilot server, it came preinstalled with the operating system and CallPilot server software. If your CallPilot server no longer functions because of a software problem, you may need to reinstall the CallPilot software or rebuild the system.

To locate instructions for these tasks, refer to the CallPilot Software Administration and Maintenance Guide (NN44200-600).

---

## Resolving system problems

---

### Introduction

Chapters 2 to 5 in this guide describe how to use a variety of CallPilot resources for resolving system problems.

If you cannot resolve your problem with the resources described in this guide, you can also refer to the following documents:

- CallPilot Administrator's Guide (NN44200-601)
- CallPilot Troubleshooting Guide (NN44200-700)

---

### Using this guide

This guide provides instructions for using the resources provided by your 201i server, as follows:

To	See
interpret the LEDs on the 201i server	<a href="#">Troubleshooting your Avaya CallPilot® system</a> on page 19
interpret startup sequence and diagnostic codes	<a href="#">Troubleshooting your Avaya CallPilot® system</a> on page 19
use the operating system diagnostic tools, including Event Viewer and TCP/IP diagnostic tools	<a href="#">Using the operating system online diagnostic tools</a> on page 35
use the Event Browser, Alarm Monitor, and Maintenance page in CallPilot Manager	<a href="#">Using CallPilot Manager to monitor hardware</a> on page 49
use the following CallPilot system utilities: <ul style="list-style-type: none"> <li>• Diagnostics Tool</li> <li>• System Monitor</li> </ul>	<a href="#">Using Avaya CallPilot® system utilities</a> on page 75

---

## Using the CallPilot Administrator's Guide

The CallPilot Administrator's Guide (NTP NN44200-601) provides valuable information for monitoring system performance. The CallPilot Administrator's Guide describes how to:

- view and filter server events
- monitor the CallPilot server performance, disk space, and database
- monitor and manage CallPilot channels
- troubleshoot CallPilot call service and system operation problems

---

## Using the CallPilot Troubleshooting Guide

The CallPilot Troubleshooting Guide (NN44200-700) describes symptoms that can appear on all CallPilot server platforms, and ways to resolve them.

Use the CallPilot Troubleshooting Guide to resolve the following types of problems:

- server boot cycle failures
- peripheral device problems
- monitor display problems
- server-to-network connection problems
- remote access connection problems
- CallPilot application problems

---

## Replacing hardware components

---

### Introduction

This guide describes how to replace or install hardware components as follows:

To replace or install	See
the 201i server (in the event of a complete system failure)	<a href="#">Replacing the server</a> on page 93
the hard drive	<a href="#">Replacing the IDE hard drive</a> on page 97
the software feature key (dongle)	<a href="#">Replacing the software feature key</a> on page 108
MPC-8 cards	<a href="#">Replacing Multimedia Processing Cards</a> on page 110

---

## Approved replacement parts

Before replacing any parts on your server, refer to the Avaya\* product catalog for the part codes.



### Caution:

Risk of system damage

The use of parts that are not approved by Avaya can cause serious system problems or void your Avaya warranty.

---

## Preparing for maintenance activities

Before you proceed with hardware maintenance activities, review the CallPilot Installation and Configuration Task List (NN44200-306) for the following information:

- required tools and equipment
- recommended safety precautions for electrostatic discharge, handling cards, and handling your server
- instructions for shutting down your 201i server or for taking it out of service

---

## Reference documents

**Table 1: Call Pilot Customer Documentation Map**

Fundamentals
--------------

Fundamentals Guide (NN44200-100)

Library Listing (NN44200-117)

#### Planning and Engineering

Planning and Engineering Guide (NN44200-200)

Network Planning Guide (NN44200-201)

Converging the Data Network with VoIP Guide (NN43001-260)

Solution Integration Guide for Communication Server 1000/Call Pilot/Contact Center/Telephony Manager (NN49000-300)

#### Installation and Configuration

Upgrade and Platform Migration Guide (NN44200-400)

High Availability: Installation and Configuration (NN44200-311)

Geographic Redundancy Application Guide (NN44200-322)

Installation and Configuration Task List Guide (NN44200-306)

Quickstart Guide (NN44200-313)

Installer Roadmap (NN44200-314)

#### Server Installation Guides

201i Server Hardware Installation Guide (NN44200-301)

202i Server Hardware Installation Guide (NN44200-317)

202i Installer Roadmap (NN44200-319)

703t Server Hardware Installation Guide (NN44200-304)

1002rp Server Hardware Installation Guide (NN44200-300)

1002rp System Evaluation (NN44200-318)

1005r Server Hardware Installation Guide (NN44200-308)

1005r System Evaluation (NN44200-316)

1006r Server Hardware Installation Guide (NN44200-320)

600r Server Hardware Installation Guide (NN44200-307)

600r System Evaluation (NN44200-315)

#### Configuration and Testing Guides

Meridian 1 and CallPilot Server Configuration Guide (NN44200-302)

T1/SMDI and CallPilot Server Configuration Guide (NN44200-303)

Communication Server 1000 System and CallPilot Server Configuration Guide (NN44200-312)

#### Unified Messaging Software Installation

Desktop Messaging and My CallPilot Installation and Administration Guide (NN44200-305)

Administration

- Administrator Guide (NN44200-601)
- Software Administration and Maintenance Guide (NN44200-600)
- Meridian Mail to CallPilot Migration Utility Guide (NN44200-502)
- Application Builder Guide (NN44200-102)
- Reporter Guide (NN44200-603)

Maintenance

- Troubleshooting Reference Guide (NN44200-700)
- Preventative Maintenance Guide (NN44200-505)
- Server Maintenance and Diagnostics
  - 201i Server Maintenance and Diagnostics Guide (NN44200-705)
  - 202i Server Maintenance and Diagnostics Guide (NN44200-708)
  - 703t Server Maintenance and Diagnostics Guide (NN44200-702)
  - 1002rp Server Maintenance and Diagnostics Guide (NN44200-701)
  - 1005r Server Maintenance and Diagnostics Guide (NN44200-704)
  - 1006r Server Maintenance and Diagnostics Guide (NN44200-709)
  - 600r Server Maintenance and Diagnostics Guide (NN44200-703)
  - Contact Center Manager Communication Server 1000/Meridian 1 & Voice Processing Guide (297-2183-931)

End User Information

End User Cards

- Unified Messaging Quick Reference Card (NN44200-111)
- Unified Messaging Wallet Card (NN44200-112)
- A-Style Command Comparison Card (NN44200-113)
- S-Style Command Comparison Card (NN44200-114)
- Menu Interface Quick Reference Card (NN44200-115)
- Alternate Command Interface Quick Reference Card (NN44200-116)
- Multimedia Messaging User Guide (NN44200-106)
- Speech Activated Messaging User Guide (NN44200-107)
- Desktop Messaging User Guide for Microsoft Outlook (NN44200-103)
- Desktop Messaging User Guide for Lotus Notes (NN44200-104)

## About this guide

Desktop Messaging User Guide for Novell Groupwise (NN44200-105)

Desktop Messaging User Guide for Internet Clients (NN44200-108)

Desktop Messaging User Guide for My CallPilot (NN44200-109)

Voice Forms Transcriber User Guide (NN44200-110)

# Chapter 3: Troubleshooting your Avaya CallPilot® system

---

## In this chapter

[Overview](#) on page 19

[Section A: LED and HEX displays](#) on page 20

[Status LEDs and HEX display location](#) on page 21

[Interpreting the power status LED](#) on page 22

[Interpreting the MPC slot LEDs](#) on page 23

[Interpreting the network and drive activity LEDs](#) on page 24

[Interpreting the HEX display](#) on page 26

[Section B: Startup diagnostics](#) on page 28

[Startup diagnostic codes](#) on page 28

[Startup sequence description](#) on page 31

[Troubleshooting startup problems](#) on page 33

---

## Overview

---

## Introduction

This guide provides instructions for using the resources provided by your 201i system. Use these resources to determine the cause of system problems, and then resolve them.

---

## LEDs and HEX display on the 201i server faceplate

The LEDs indicate when:

- the 201i server, MPC-8 card, or SCSI drive is in use
- it is safe to remove the server from the switch, or the MPC-8 card from the server
- network activity is occurring

The HEX display displays messages that appear during startup or normal 201i server operation.

For more information, see [Section A: LED and HEX displays](#) on page 20.

---

## Startup sequence and diagnostic codes

To help you determine if the 201i server started successfully (or if it failed), watch the startup sequence and the diagnostic codes that appear. The entire sequence occurs when you do one of the following:

- Lock the 201i server against the switch backplane. When locked against the backplane, the 201i server begins receiving power.
- Restart the operating system.
- Press Reset on the 201i server faceplate to perform a hardware restart.

For more information, see [Section B: Startup diagnostics](#) on page 28.

---

## Section A: LED and HEX displays

---

### In this section

[Status LEDs and HEX display location](#) on page 21

[Interpreting the power status LED](#) on page 22


[Interpreting the MPC slot LEDs](#) on page 23

[Interpreting the network and drive activity LEDs](#) on page 24

[Interpreting the HEX display](#) on page 26

## Status LEDs and HEX display location

The following diagram shows the location of the status LEDs and HEX display on the 201i server's faceplate.



G101439

---

## Interpreting the power status LED

---

### Introduction

The power status LED is located on the 201i server faceplate, directly under the keyboard connector. The LED indicates whether it is safe to remove the server from the switch (which results in a server power down).



**Caution:**

Risk of equipment damage or data loss

Do not remove the 201i server during normal operation or certain phases of the startup sequence, as this can damage the operating system files on the hard disk.

To determine if it is safe to remove the 201i server from the switch, see [Power status LED indications](#) on page 22.

---

### Power status LED functions

The LED indicates two server states:

- The 201i server is in use.
- It is safe to remove the 201i server from the switch.

---

### Power status LED indications

IF the power status LED is	THEN
on	the server is powered on. It is safe to remove it from the switch.

 **Note:**  
When the LED is lit, the HEX display may display one of the following: T:XX, F:XX, HOST, or DOWN.

---

IF the power status LED is	THEN
off	<p data-bbox="641 283 690 336"> <b>Caution:</b></p> <p data-bbox="649 346 1351 430">Risk of equipment damage or data loss It is not safe to remove the server from the switch. The server is in one of the following states:</p> <ul data-bbox="657 441 1351 535" style="list-style-type: none"> <li data-bbox="657 441 1351 472">• The server is in the operating system startup sequence.</li> <li data-bbox="657 483 1351 535">• The server has completed the startup sequence and is running.</li> </ul> <p data-bbox="690 556 738 609"> <b>Note:</b></p> <p data-bbox="706 619 1351 745">You must courtesy down Avaya CallPilot, and then shut down the operating system before you can remove the 201i server from the switch. For instructions, see "Powering down the server" in the CallPilot Installation and Configuration Task List. (NN44200-306)</p>

---

## Interpreting the MPC slot LEDs

---

### Introduction

There is an LED for each MPC slot on the 201i server.

---

### MPC slot LED functions

The LEDs indicate two possible MPC slot states:

- The MPC is in use.
- It is safe to remove the MPC from the server.

---

## MPC slot LED indications

IF the MPC slot LED	THEN
is off	the MPC is not receiving power. It is safe to remove the MPC from the server.
is on	the MPC is in use. It is not safe to remove the MPC from the server.
was off, then came on	the MPC was recognized by the 201i software and subsequently powered up.
was on, then went off	the MPC was successfully disabled using the Maintenance page in CallPilot Manager. It is safe to remove the MPC from the server.

---

## Interpreting the network and drive activity LEDs

---

### Introduction

The 201i server provides four LEDs to indicate ELAN Subnet, Avaya server subnet, SCSI device, and IDE hard drive activity. They are labeled as follows:

LED label	Description
E	ELAN subnet
C	Avaya server subnet
I	IDE hard drive
S	SCSI device (CD-ROM or tape drive)

---

## Network LED states

IF the E or C LEDs are	THEN
off	a valid hardware connection with the network has not been established. Ensure that the cable is connected to the respective network switch or hub. If the cable is connected, ensure that the cable is not damaged.
on	a valid hardware connection with the network has been established.   <b>Note:</b> Before the 201i server can receive or transmit data, you must configure valid IP settings on the 201i server by running the Configuration Wizard. For instructions, refer to the CallPilot Manager online Help.
blinking rapidly	activity is occurring on the network.   <b>Note:</b> This does not mean that the 201i server is actually transmitting or receiving packets.

---

## IDE drive LED states

IF the I LED is	THEN
off	the IDE hard drive is idle.
on	the IDE hard drive is being accessed.

---

## SCSI device LED states

IF the S LED is	THEN
off	the SCSI device is idle, or the driver is not loaded.

IF the S LED is	THEN
blinking	the SCSI device is being accessed.
lit solid	the software driver has loaded, but the SCSI device is not connected.

## Interpreting the HEX display

### Introduction

This section describes the codes that can appear on the HEX display during startup or normal 201i server operation.



**Note:**

For a description of the codes that appear during startup diagnostics, see [Startup diagnostic codes](#) on page 28. For a description of the startup sequence, see [Startup sequence description](#) on page 31.

### HEX display codes

During startup and normal 201i server operation, the HEX display on the server faceplate displays one of the codes in the following table:

HEX display output	Description
<b>Startup codes</b>	
T:XX	The 8051 controller is starting and running diagnostics. These diagnostics are performed during a cold restart (when the server is powered up, or if you press Reset on the 201i server's faceplate). For more details, see <a href="#">Startup diagnostic codes</a> on page 28.
F:XX	At least one diagnostic failed. The displayed error code represents the first failed diagnostic. For more details, see <a href="#">Startup diagnostic codes</a> on page 28.
P:XX	An Extended POST error has occurred, where XX represents a two-character code. If the error is a

HEX display output	Description
<b>Startup codes</b>	
	<p>critical error, the start cycle may halt. If the error is a non-critical error, the error code is logged in the operating system event log after the operating system startup completes and the CallPilot 8051 device driver starts.</p> <p> <b>Important:</b> POST Terminal errors that result in a system halt do not appear on the HEX display. If you cannot use the HEX display to determine the cause of a system halt, contact your Avaya technical support representative.</p>
HOST	This code appears during the startup sequence and means that BIOS diagnostics have started. HOST also appears on the HEX display when the server has been started to ROM-DOS.
NT	The operating system start sequence has started.
OK	The operating system start sequence was successful.
<b>CallPilot and 201i server operation codes</b>	
BOOT	CallPilot is starting and is not yet fully operational.
PASS	CallPilot is fully operational and ready to accept calls.
WARN	CallPilot is ready to accept calls. However, some services failed the start sequence. Review the event log for further information.
FAIL	CallPilot failed the start sequence and cannot accept calls. Review the event log for further information.
MIN	A minor alarm has occurred. Review the event log for further information.
MAJ	A major alarm has occurred. Review the event log for further information.
CRI	A critical alarm has occurred. Review the event log for further information.
???	<p>An alarm of unknown severity occurred. This error should not occur on a properly installed system. The severity of this event is treated as higher-than-critical.</p> <p> <b>Note:</b> If you observe "???" or anything else on the display, contact your Avaya technical support representative.</p>

HEX display output	Description
<b>Startup codes</b>	
DOWN	<p>The operating system has been shut down. When the power status LED is on, it is safe to remove the 201i server from the switch.</p> <p>If you perform a cold restart by pressing Reset on the 201i server faceplate, or by removing and then reinserting the 201i server in the switch, the start sequence starts at stage 1, described on 1.</p> <p>If you perform a warm restart by selecting Restart on the operating system shutdown menu, the start sequence begins at stage 9, described on 9. However, the HEX display behaves as follows:</p> <ul style="list-style-type: none"><li>• The DOWN message remains displayed until the operating system start sequence begins.</li><li>• The DOWN message does not scroll.</li></ul>

---

## Section B: Startup diagnostics

---

### In this section

[Startup diagnostic codes](#) on page 28

[Startup sequence description](#) on page 31

[Troubleshooting startup problems](#) on page 33

---

## Startup diagnostic codes

---

### Introduction

HEX display diagnostic codes are divided into the following two categories:

- critical startup diagnostics
- non-critical operating system and switch diagnostics

---

## Critical startup diagnostic codes

All critical startup diagnostics must pass before the 201i can proceed with the start sequence. If a critical diagnostic fails, the start sequence indefinitely halts, an error code displays, and a continuous beep is heard.

The following table shows the critical startup diagnostic codes with their corresponding failure codes. Failure of these diagnostics means that there has been a server failure. The start cycle is halted.

 **Note:**

When a test is successfully completed, the next test code appears.

Test code	Test description	Failure code
T:01	Internal RAM self-test	F:01
T:02	ALU self-test	F:02
T:03	Address mode self-test	F:03
T:04	Boot ROM self-test	F:04
T:05	Timer self-test	F:05
T:06	Watchdog self-test	F:06
T:07	EEPROM self-test	F:07
T:08	End of system controller self-tests The power status LED blinks three times.	not applicable
HOST	Start of BIOS diagnostics The monitor displays the BIOS start screen. If a critical error occurs, the start cycle is halted. Examples of critical errors are memory failure or another type of error resulting in no display on the monitor.	HOST continues to scroll across the HEX display

---



---

## Non-critical operating system and switch diagnostic codes

If a noncritical operating and switch diagnostic test fails, the HEX display stops at the failed test. The remaining diagnostics are not performed. The start sequence continues, but server functionality can be compromised.

The following table shows the noncritical operating system and switch diagnostic codes with their corresponding failure codes.

**\* Note:**

While the test is in progress, the following codes may appear for a short period. If these messages display temporarily (that is, no longer than one second), a problem does not exist.

Status code	Operation description	Failure code
HOST	Continuation of BIOS diagnostics The monitor displays the BIOS start screen. If a noncritical error occurs, the server continues the start sequence.	P:XX
NT	The operating system start sequence started  <b>* Note:</b> If the CallPilot server software is not installed, the HEX display remains at NT. (This can occur if you are performing a system rebuild.) During CallPilot software installation, the 8051 device driver is copied to the operating system, at which point the HEX display shows CDLN.	P:XX  <b>* Note:</b> For a description, see <a href="#">P:XX failure codes</a> on page 31.
CDLN	8051 device driver on the operating system has started; beginning of Cardlan interface communication (DS30x interface initialization) The system controller communicates with the switch, indicating that two cards are installed, and waits for switch acknowledgement.	CDLN Neither DS30x interface was initialized (both failed).
C:01	Initialization of the first DS30x interface	C:01 Initialization of the first DS30x interface failed. The second DS30x interface is OK.
C:02	Initialization of the second DS30x interface	C:02 Initialization of the second DS30x interface failed. The first DS30x interface is OK.
OK	Switch acknowledgement complete The operating system startup is complete, and CallPilot Fault Management takes over.	CRI, FAIL, MAJ, MIN, or WARN

---

## P:XX failure codes

P:XX indicates a BIOS diagnostic error, where XX represents a two-character code. If the error is a critical error, the start cycle may halt. If the error is a noncritical error, the error code is reported in the operating system system event log after the operating system start sequence completes and the CallPilot 8051 device driver starts.

 **Note:**

If CallPilot is not installed, no event is logged.

 **Important:**

POST Terminal errors that result in a system halt do not appear on the HEX display. If you cannot use the HEX display to determine the cause of a system halt, contact your Avaya technical support representative.

---

## Startup sequence description

---

### Introduction

The following table describes the startup sequence and the diagnostic stages that occur. The entire sequence occurs when you do one of the following:

- You lock the 201i against the switch backplane, and the 201i powers up.
- You press Reset on the 201i server faceplate to perform a hardware restart.

 **Note:**

If you restart the operating system by clicking the Shut Down and Restart options, the start sequence starts at stage 9. However, the HEX display behaves as follows:

- The DOWN message remains displayed until the operating system start sequence begins.
- The DOWN message does not scroll.

Stage	Description	HEX display	Status LED
1	Internal RAM self-test	T:01	ON

Stage	Description	HEX display	Status LED
	This is the start of critical startup diagnostics for the 8051 system controller. If any of the tests fail, the startup cycle is halted. Approximate duration: less than 1 second		
2	ALU self-test Approximate duration: less than 1 second	T:02	ON
3	Address mode self-test Approximate duration: less than 1 second	T:03	ON
4	Boot ROM self-test Approximate duration: less than 1 second	T:04	ON
5	Timer self-test Approximate duration: less than 1 second	T:05	ON
6	Watchdog self-test Approximate duration: less than 1 second	T:06	ON
7	EEPROM self-test This is a noncritical diagnostic. If it fails, this is a noncritical error, and the start cycle continues. Approximate duration: less than 1 second	T:07	ON
8	End of system controller self-tests. No errors were found. Approximate duration: less than 3 seconds	T:08	blinks three times
9	Beginning of BIOS diagnostics   <b>Note:</b> The BIOS splash screen appears, and HOST scrolls across the HEX display. Approximate duration: 7 seconds	HOST	ON
10	Beginning of the operating system start sequence The monitor displays the operating system logon prompt. You are prompted for an operating system user name and password. If the system needs to be configured, a pop-up box for Maintenance Configuration Detection Information may appear to remind you. If the Maintenance Configuration Detection Information box appears, click OK unless you want a reminder to configure the server.	NT	OFF
11	Completion of operating system start sequence. The 8051 system controller is running normally.	OK	OFF

Stage	Description	HEX display	Status LED
12	The 201i Avaya CallPilot software loads. OK means that CallPilot has loaded. CallPilot Fault Management takes over. If FAIL, WARN, CRI, MAJ, or MIN appears instead of OK, a fault has occurred. Use the system and CallPilot Manager event logs and Alarm Monitor to determine what happened. Approximate duration: 5 minutes	One of the following, as applicable: <ul style="list-style-type: none"> <li>• BOOT</li> <li>• PASS</li> <li>• FAIL</li> <li>• WARN</li> <li>• CRI</li> <li>• MAJ</li> <li>• MIN</li> </ul>	OFF

## Troubleshooting startup problems

### Introduction

This section suggests tasks you can perform to determine why the 201i server fails the startup cycle.

#### To determine why the 201i server failed the 8051 startup

1. Make a note of any diagnostic codes.
2. Try restarting the server by pressing Reset on the 201i server's faceplate.
3. During the restart sequence, view the diagnostic codes on the HEX display for failures.

For a description, see [Startup sequence description](#) on page 31.



**Note:**

Allow 5 minutes for the start cycle to complete.

4. Refer to the CallPilot Troubleshooting Guide for other suggestions.
5. If you still cannot find the cause of the failure, call your Avaya technical support representative.

### To determine why the 201i server failed to start CallPilot

1. Make a note of any diagnostic codes.
2. Try restarting the server by pressing Reset on the 201i server's faceplate.
3. During the start sequence, view the diagnostic codes on the HEX display for failures.

For a description, see [Startup sequence description](#) on page 31.

 **Note:**

Allow 5 minutes for the start cycle to complete.

4. View the event logs.

For instructions, see [Viewing event logs](#) on page 36.

5. Refer to the CallPilot Troubleshooting Guide for other suggestions.
6. If you still cannot find the cause of the failure, call your Avaya technical support representative.

# Chapter 4: Using the operating system online diagnostic tools

---

## In this chapter

[Overview](#) on page 35

[Viewing event logs](#) on page 36

[Using TCP/IP diagnostic tools](#) on page 40

---

## Overview

---

## Introduction

This section describes how to access the runtime online diagnostic tools provided by the operating system server software. Use these tools when a serious problem prevents the use of the Avaya CallPilot® diagnostic tools that are available in Avaya CallPilot Manager.



**Caution:**

Risk of software corruption

Do not run any utilities that are not documented in this guide.

---

## Operating system Event Viewer

The operating system Event Viewer provides event logs to help you diagnose and debug system problems.

---

## Operating system Diagnostics

The operating system Diagnostics window allows you to view details about the system and network components.

---

## TCP/IP diagnostics

this chapter describes the following TCP/IP diagnostic tools:

- ipconfig
- ping
- tracert
- arp
- nbtstat
- netstat

These utilities help you to verify network connectivity. They help you to thoroughly test the network interface and isolate any configuration problems. Network connectivity is essential to Avaya CallPilot operation.

---

## Viewing event logs

---

## Introduction

When the server startup cycle is complete, and if the CallPilot server has been configured (refer to the CallPilot <switch model> and CallPilot Server Configuration guide for your switch and server), the HEX display should show PASS, and messages in dialog boxes on the monitor indicate that CallPilot is ready to accept calls.

If the hex display shows FAIL, CRI, MAJ, MIN, or FAIL or one or more error messages appears on the monitor, an event (such as a warning, error, or information display) has occurred. To determine what happened, you can use the following:

- operating system Event Viewer on the 201i server (see [To use the operating system Event Viewer](#) on page 37)
- CallPilot Event Browser or Alarm Monitor in CallPilot Manager

For more information, do one of the following:

- See [Alarm Monitor](#) on page 52.
- Refer to the CallPilot Administrator's Guide (NN44200-601).

 **Note:**

The Event Browser and Alarm Monitor include online Help for events, which may help you to resolve the problem. If you cannot log on to the CallPilot system using a Web browser due to server problems, then use the operating system Event Viewer.

---

## Types of event logs

Three types of event logs are available from the operating system Event Viewer, as follows:

Log type	Description
System	Logs events by the operating system components, including Routing and Remote Access Server (RRAS) or other operating system services.
Security	Logs security events, such as logons, logoffs, illegal access, and so on. This option is available only to users with Administrative access.
Applications	Logs events by application, such as database file errors, and so on.

---

## Where to get more information


For more information about using the operating system Event Viewer, click Help → Contents in the Event Viewer window. See also [To use the operating system Event Viewer](#) on page 37.

### To use the operating system Event Viewer

1. Click Start → Programs → Administrative Tools → Event Viewer.


Using the operating system online diagnostic tools

Result: The Event Viewer window appears.




2. To view a log, click the name of the log in the left frame of the window.

The illustration shows an example of the Application log.



An example of a System log appears in the following illustration.

**Note:**

The Security log available only to administrators is not shown.

- Look for error codes flagged that have occurred since the last startup. Each error is date-and-time stamped.



major or critical errors



warnings



information

- To determine the cause of the error, select and double-click the error.

Result: A description of the error appears in an Event Detail dialog box. An example of an error description is shown in the Event Detail dialog box in the Application log illustration on [2](#) on page 38.

- Use the error description to help determine how to resolve errors.

**Note:**

If the error persists or does not suggest a solution, contact your Avaya support representative.

- Click Close.

Result: The event log reappears.

- Click Log → Exit.

Result: The Event Viewer closes.

---

## Using TCP/IP diagnostic tools

---

### Introduction

This section describes the following TCP/IP diagnostic tools available for the network adapter. These tools are useful for diagnosing LAN communication problems. The first three tools are the most useful:

- ipconfig ([The ipconfig command](#) on page 40)
- ping ([The ping command](#) on page 41)
- tracert ([The tracert command](#) on page 42)
- arp ([The arp command](#) on page 44)
- nbtstat ([The nbtstat command](#) on page 45)
- netstat ([The netstat command](#) on page 46)

These utilities help you to verify network connectivity. Network connectivity is essential to CallPilot operation. These utilities help you to thoroughly test the network interface and isolate any configuration problems.

---

### The ipconfig command

The ipconfig command displays IP configuration information.

---

### Ipconfig default

If you run the command without flags, it displays the IP address, subnet mask, and default gateway for each adapter bound to TCP/IP.

---

### Ipconfig command syntax

```
ipconfig /[ ]
```

The following flags are available for the ipconfig command:

Flag	Description
/?	Displays Help information.
/all	Displays full configuration information.
/release	Releases the IP address for the specified adapter.
/renew	Renews the IP address for the specified adapter.

### To run the ipconfig command from the operating system

1. Click Start → Programs → Accessories → Command Prompt to display the command prompt window.

Result: The Command Prompt window appears.

2. At the prompt, type ipconfig <with appropriate parameters>.

Example: ipconfig /all

3. Press Enter.

Result: The system runs the ipconfig utility.

4. Type Exit to exit the Command Prompt window.

---

## The ping command

The ping command sends an echo request to a specified host. Use this command to verify network connectivity to the remote device.

---

## Ping command syntax

The ping command uses the following syntax:

```
ping [-t] [-a] [-n count] [-l size] [-f] [-i TTL] [-v TOS] [-r count]
[-s count] [[-j host-list] | [-k host-list]] [-w timeout]
destination-list
```

Parameter	Description
-t	Pings the specified host until interrupted.
-a	Resolves addresses to host names.
-n count	Specifies the number of echo requests to send.

Parameter	Description
-l size	Sends buffer size.
-f	Set Don't Fragment flag in packet.
-i TTL	Time To Live
-v TOS	Type Of Service
-r count	Record route for count hops
-s count	Time stamp for count hops
-j host-list	Loose source route along host list
-k host-list	Strict source route along host list
-w timeout	Time-out in milliseconds to wait for each reply

### To run the ping command from the operating system

1. Click Start → Programs → Accessories → Command Prompt to display the command prompt window.  
Result: The Command Prompt window appears.
2. At the prompt, type ping <destination IP address> (for example, ping 200.286.32.0), or ping <computer name>.
3. Press Enter.  
Result: The system displays the ping results.
4. Type Exit to exit the Command Prompt window.

---

## The tracert command

This utility determines the route taken to a destination.

---

## How tracert works

The tracert utility follows several steps to complete its task:

- Tracert sends Internet Control Message Protocol (ICMP) echo packets with varying Time-To-Live (TTL) values to the destination.
- Each router along the path must decrement the TTL on a packet by at least 1 before forwarding it, so the TTL is effectively a hop count.

- When the TTL on a packet reaches 0, the router sends back an ICMP Time Exceeded message to the source system.
- Tracert determines the route by sending the first echo packet with a TTL of 1, and incrementing the TTL by 1 on each subsequent transmission until the target responds, or the maximum TTL is reached.
- Tracert then examines the ICMP Time Exceeded messages sent back by intermediate routers.

---

## Tracert syntax

```
tracert [-d] [-h maximum_hops] [-j host_list] [-w timeout]
[target_name]
```

---

## Tracert parameters

The tracert command uses the following parameters:

Parameter	Description
-d	Specifies not to resolve addresses to hostnames.
-h maximum_hops	Specifies the maximum number of hops to search for the target.
-j host-list	Specifies a loose source route along the host list.
-w timeout	Waits the number of milliseconds specified by the timeout for each reply.
target_name	The name of the target host.

### To run the tracert command from the operating system

1. Click Start → Programs → Accessories → Command Prompt to display the command prompt window.

Result: The Command Prompt window appears.

2. At the prompt, type the following command:

```
tracert [-d] [-h maximum_hops] [j host_list] [-w timeout]
[target name]
```

Example: tracert 200.286.0.32 210 200.236.0.04

3. Press Enter.

Result: The system runs the tracer utility.

4. Type Exit to exit the Command Prompt window.

---

## The arp command

The arp command displays and modifies the IP-to-physical address translation tables used by Address Resolution Protocol (arp).

---

### Arp command syntax

The arp command uses the following syntax:

```
arp -s inet_addr eth_addr [if_addr]
```

```
arp -d inet_addr [if_addr]
```

```
arp -a [inet_addr] [-N if_addr]
```

Parameter	Description
-a	Displays current arp entries by interrogating the current protocol data. If inet_addr is specified, the IP and physical addresses for only the specified computer appear. If more than one network interface uses arp, entries for each arp table appear.
-g	Same as -a.
inet_addr	Specifies an Internet address.
if_addr	Specifies the Internet address of the interface whose address translation table should be modified. If not present, the first applicable interface is used.
eth_addr	Specifies a physical address.
-N if_addr	Displays the arp entries for the network interface specified by if_addr.
-d	Deletes the host specified by inet_addr.
-s	Adds the host and associates the Internet address inet_addr with the Physical address eth_addr. The physical address is given as six hexadecimal bytes separated by hyphens. The entry is permanent.

### To run the arp command from the operating system

1. Click Start → Programs → Accessories → Command Prompt to display the command prompt window.

Result: The Command Prompt window appears.

2. At the prompt, type arp with the required parameters (for example, arp -g 200.286.0.32).
3. Press Enter.

Result: The system runs the arp command.

4. Type Exit to exit the Command Prompt window.

---

## The nbtstat command

The nbtstat command displays protocol statistics and current TCP/IP connections using NBT.

---

### Nbtstat command syntax

The nbtstat command uses the following syntax:

```
nbtstat [-a remotename] [-A IP address] [-c] [-n] [-R] [-r] [-S] [-s]
[interval]
```

Parameter	Description
-a remotename	Lists the remote computer's name table using its name.
-A IP address	Lists the remote computer's name table using its IP address.
-c	Lists the contents of the NetBIOS name cache giving the IP address of each name.
-n	Lists local NetBIOS names. Registered indicates that the name is registered by broadcast (Bnode) or WINS (other node types).
-R	Reloads the LMHOSTS file after purging all names from the NetBIOS name cache.
-r	Lists name resolution statistics for Windows networking name resolution. On a computer configured to use WINS, this option returns the number of names resolved and registered through broadcast or through WINS.
-S	Displays both client and server sessions, listing the remote hosts by IP address only.
-s	Displays both client and server sessions, and attempts to convert the remote host IP address to a name using the HOSTS file.

Parameter	Description
interval	Displays selected statistics, pausing interval seconds between each display. Press Ctrl+C to stop displaying statistics. Without this parameter, nbtstat prints the current configuration information once.

### To run the nbtstat command from the operating system

1. Click Start → Programs → Accessories → Command Prompt to display the command prompt window.

Result: The Command Prompt window appears.

2. At the prompt, type nbtstat with the required parameters.
3. Press Enter.

Result: The system runs the nbtstat utility.

4. Type Exit to exit the Command Prompt window.

---

## The netstat command

The netstat command displays current TCP/IP network connections and protocol statistics.

---

## Netstat command syntax

The netstat command uses the following syntax:

```
netstat [-a] [-e] [-n] [-s] [-p proto] [-r] [interval]
```

Parameter	Description
-a	Displays all connections and listening ports.
-e	Displays Ethernet statistics. This can be combined with the -s option.
-n	Displays addresses and port numbers in numerical form.
-s	Displays per-protocol statistics.
-p proto	Shows connections for the protocol specified by proto. Proto can be tcp or udp. If used with the -s option, proto can be tcp, udp, or ip.
-r	Displays the contents of the routing table.

Parameter	Description
interval	Redisplays selected statistics, pausing between each display. Press Ctrl+C to stop redisplaying.

### To run the netstat command from the operating system

1. Click Start → Programs → Accessories → Command Prompt to display the command prompt window.

Result: The Command Prompt window appears.

2. At the prompt, type netstat with the required parameters.
3. Press Enter.

Result: The system runs the netstat utility.

4. Type Exit to exit the Command Prompt window.



# Chapter 5: Using CallPilot Manager to monitor hardware

---

## In this chapter

[Understanding fault management](#) on page 50

[Section A: Tools for isolating and fixing hardware problems](#) on page 51

[Overview](#) on page 51

[Alarm Monitor](#) on page 52

[Event Browser](#) on page 54

[Maintenance page](#) on page 55

[Channel and Multimedia Monitors](#) on page 55

[Section B: Working with the Maintenance page](#) on page 56

[Introducing the Maintenance page](#) on page 57

[Viewing component states](#) on page 59

[Starting and stopping components](#) on page 61

[Running integrated diagnostics](#) on page 64

[Viewing the last diagnostic results](#) on page 67

[Section C: Working with the Multimedia and Channel Monitors](#) on page 70

[Working with the Multimedia Monitor](#) on page 70

[Working with the Channel Monitor](#) on page 71

---

## Understanding fault management

---

### Introduction

Fault management is a term that describes how the Avaya CallPilot® server detects and notifies you of potential or real hardware problems (faults).

The server processes events to detect hardware problems and raises alarms to notify you when these problems occur.

---

### Event processing

An event is any change in system configuration or operational state. An event is also any action taken by the system that requires user notification. Events can be as insignificant as a user logon attempt or as serious as a faulty MPC-8 card switching to disabled status.

All events are reported to the fault management server, a subsystem within the Avaya CallPilot server. The fault management server enables the server to listen and respond to its clients. The interaction is called event processing and is the means by which the server detects hardware faults.

---

### Alarm notification

Alarms are warnings generated by events. Alarms communicate the same information as events. However, alarms are reported in the Alarm Monitor instead of the Event Browser, and are managed differently than events.

When an alarm appears in the Alarm Monitor, you must investigate the problem, isolate it, and then fix the cause of the problem. When you fix the problem, the alarm is cleared from the Alarm Monitor.

---

## Section A: Tools for isolating and fixing hardware problems

---

### In this section

[Overview](#) on page 51

[Alarm Monitor](#) on page 52

[Event Browser](#) on page 54

[Maintenance page](#) on page 55

[Channel and Multimedia Monitors](#) on page 55

---

## Overview

---

## Introduction

This section provides guidelines on how to use the CallPilot Manager tools to detect, isolate, and fix potential or real hardware problems.

---

## Component dependencies

The status of some components is dependent on the operational status of other components. If a component fails or is stopped, the dependent components go out of service.

 **Note:**

Based on the CallPilot server type, and the type of switch connected to CallPilot, some of these components may not appear on your system.

Component	Dependent components
Motherboard (IPE server)	All MPCs, and all multimedia and call channels associated with the IPE server.
Time Switch	All multimedia and call channels associated with the same MPB as the timeswitch.
MPCs	All multimedia (DSP) channels on the MPC-8 card.
DS30X	All DS30X channels associated with the DS30X link.

---

## Detecting hardware problems

Typically, you first become aware of a hardware problem when an alarm is raised. All hardware faults produce an alarm (or series of alarms, depending on the problem) in the Alarm Monitor.

Other indications of a hardware problem include the following:

- user complaints
- call processing difficulties, such as busy signals, static, dropped calls, connection problems, and cross talk (hearing other conversations)
- system administrator logon difficulties
- alert icons on the Maintenance page

---

## Alarm Monitor

---

### Introduction

Use the Alarm Monitor to investigate one or more raised alarms.

---

## About alarms

Alarms are warnings generated by events. Alarms communicate the same information as events. However, alarms are reported in the Alarm Monitor instead of the Event Browser, and are managed differently than events:

- Alarms appear in the Alarm Monitor only for Minor, Major, and Critical events (not Information events). All events can be reported in the Event Browser (depending on filtering criteria defined in the Event Browser).
- The first time an event occurs, it generates an alarm that appears in the Alarm Monitor. If the same event continues to occur, a new alarm is not generated. Instead, the time and date assigned to the original generated alarm is updated.
- Alarms can be cleared from the Alarm Monitor, but the event that generated the alarm is not cleared from the event log or the Event Browser.

Each alarm in the Alarm Monitor has Help text that often provides a solution to the problem. If the solution is not apparent, use the Event Browser or the Maintenance page to further investigate the problem.

### To investigate using the Alarm Monitor

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click System → Alarm Monitor.  
Result: The Alarm Monitor page appears.
3. Click the Event Code for the first critical or major alarm.  
Result: A description of the event appears in a new Web browser window.
4. Review the description and recovery action.
5. Repeat steps [3](#) on page 53 and [4](#) on page 53 to view more alarms, if necessary.
6. If the solution to the problem is not apparent, obtain the return code of the first event and continue the investigation by using the Event Browser (see [Event Browser](#) on page 54).

---

## See also

For detailed information on how to use the Alarm Monitor, refer to the CallPilot Administrator's Guide (NN44200-601), or the CallPilot Manager online Help.

---

## Event Browser

---

### Introduction

Use the Event Browser to investigate a series of events that occurred around the time an alarm was raised. The event listing can help you determine the root cause of a problem.

---

### About events

The Event Browser displays events that have been recorded in the server log. Each event identifies the time the event occurred, the object that generated the event, and the cause of the event.

Events are classified as Information, Minor, Major, or Critical. By default, the Event Browser displays only the latest 100 critical events.

#### To investigate using the Event Browser

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click System → Event Browser.  
Result: The Event Browser page appears.
3. Click an event that appears to be related to the problem, or an event that occurred near the time the alarm was raised.  
Result: A description of the event appears in a new Web browser window.
4. View the description and recovery action.
5. Repeat steps [3](#) on page 54 and [4](#) on page 54 to view more events, if necessary.
6. If the solution to the problem is not apparent, contact your Avaya technical support representative.

---

## See also

For detailed information on how to use the Event Browser (for example, how to set preferences), refer to the CallPilot Administrator's Guide (NN44200-601) or the CallPilot Manager online Help.

---

## Maintenance page

---

### Introduction

Use the Maintenance page to get status information for any suspect components.

If you suspect or discover a problem with hardware such as an MPC-8 card, or the DS30X link, you can use the Diagnostic section on the Maintenance page. You can run a new diagnostic for the component, or review the results of the last diagnostic that was run.

---

### More information

For information on all aspects of the Maintenance page, see [Section B: Working with the Maintenance page](#) on page 56, or the CallPilot Manager online Help.

---

## Channel and Multimedia Monitors

---

### Introduction

The Channel Monitor shows the status of call channels. The call channels are the connections between the server and the switch that carry the call signals to CallPilot.

The Multimedia Monitor shows the status of multimedia channels. The multimedia channels are the DSP ports that process the calls. They are the voice, fax, and speech recognition channels.

---

## Disabling call channels

If you must take the CallPilot system out of service to perform software or hardware maintenance, Avaya recommends that you disable all call channels first. There are two ways to disable the call channels:

- Courtesy stop the channels (preferred method).

When you courtesy stop call channels, CallPilot waits until the channels are no longer active before disabling them, instead of suddenly terminating active calls.

- Stop the channels.

When you stop channels, you suddenly disable them and terminate all active calls.

For information about using the Channel and Multimedia Monitors, see [Section C: Working with the Multimedia and Channel Monitors](#) on page 70.

---

## Running diagnostics on call channels

If you must run diagnostics for one or more channels, use the Diagnostics section on the Maintenance page. For more information, see [Section B: Working with the Maintenance page](#) on page 56.

---

## Section B: Working with the Maintenance page

---

### In this section

[Introducing the Maintenance page](#) on page 57

[Viewing component states](#) on page 59

[Starting and stopping components](#) on page 61

[Running integrated diagnostics](#) on page 64

[Viewing the last diagnostic results](#) on page 67

---

## Introducing the Maintenance page

---

### Introduction

Use the Maintenance page in CallPilot Manager to do the following:

- Obtain general information about components.
- View component states.
- Start and stop components.
- Run integrated diagnostic tests.
- View the results of the last diagnostic test run against a component.

---

### What the Maintenance page provides

The Maintenance page identifies the server platform and switch connectivity type. It also provides a tree that, when expanded, lists the physical and logical hardware components down the left side of the page. To list the server hardware components, click the plus sign (+) at the top of the tree. To list the subcomponents for each component, click the plus sign (+) beside the component.

 **Note:**

The components that are listed on the Maintenance page are based on the CallPilot server type and the switch that is connected to CallPilot.

When you click a component, the page refreshes to show the details about that component. Details are divided into the sections described in the following table.

Section	Description
General	<p>This section shows general technical information about the selected component. This information typically includes the following details:</p> <ul style="list-style-type: none"> <li>• the name, class, type, series, or version of a component</li> <li>• various capabilities of a component (for example, whether a component is removable)</li> </ul>

---

Section	Description
	<p> <b>Note:</b> This section does not appear for all components.</p>
Maintenance	<p>This section shows the state of the selected component. Use this section to start and stop a component before running a diagnostic test.</p> <p>This section appears only for components on which you are allowed to perform maintenance administration.</p> <p>For more information about working with component states, see the following sections:</p> <ul style="list-style-type: none"> <li>• <a href="#">Viewing component states</a> on page 59</li> <li>• <a href="#">Starting and stopping components</a> on page 61</li> </ul>
Diagnostics	<p>Use the Diagnostics section to run one or more diagnostic tests, or to view the results of the last diagnostic tests that were run on the selected component.</p> <p>This section appears only for components on which you are allowed to run diagnostics.</p> <p>For more information about running diagnostics, see the following sections:</p> <ul style="list-style-type: none"> <li>• <a href="#">Running integrated diagnostics</a> on page 64</li> <li>• <a href="#">Viewing the last diagnostic results</a> on page 67</li> </ul>

## Maintenance activities for each component

The following table identifies the maintenance activities you can perform for each component that is listed in the component tree.

Component	Start, stop?	Courtesy stop?	Diagnostics available?	Replaceable?
Motherboard	Yes	No	Yes	Yes (IPE server)
Media Bus	Yes	No	Yes	No
MPB board	Yes	No	Yes	Yes
Time Switch	No	No	No	No
MPCs (embedded on MPB boards or on MPC-8 cards) (embedded on the IPE	Yes	No	Yes	embedded: No MPC-8 cards: Yes

Component	Start, stop?	Courtesy stop?	Diagnostics available?	Replaceable?
server or on MPC-8 cards)				
Multimedia channels	Yes	Yes	Yes	No
Call channels	Yes	Yes	No	No
DS30X link	Yes	No	No	No

 **Note:**

The MGate card and DS30X cable are replaceable. If you are having problems with the DS30X link, determine if either one or both of those items is causing the problem and needs to be replaced.

---

## Viewing component states

---

### Introduction

View the state of a component to determine the general condition of the component, including whether the component is disabled or off duty. The state of a component is shown in the Maintenance section of the Maintenance page.

---

### Component states

You can determine the state of a component by looking at the State box in the Maintenance section.

State	Description
Active	The component is working and currently involved in processing a call.
Disabled	The diagnostic failed.
Idle	The component is working but not currently involved in processing a call.
InTest	A diagnostic is running on the resource or device.

State	Description
Loading	The component has been started, which takes it out of the Off Duty state. This state occurs quickly and is immediately followed by Idle.
No resources	The hardware required for the component to operate is not installed or is not operating properly.
Not Configured	The device is not configured in CallPilot. For example, a DSP is not being used because it was not allocated in the Configuration Wizard.
Off Duty	The component has been stopped.
Remote Off Duty	The component has been taken out of service at the switch.
Shutting Down	The component is in the process of stopping. This state occurs quickly and is immediately followed by Off Duty.
Uninitiated	The call processing component has not initialized the resource.

## Alert icons


If one of the following icons appears next to a component in the tree, then the component or one of its subcomponents is experiencing a problem:

Icon	Description
	A problem exists with a subcomponent of the selected component. Expand the tree to locate the subcomponent with the problem.
	A problem exists with the selected component.

### To view the state of a hardware component

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click Maintenance → Maintenance Admin.  
Result: The Maintenance page appears.
3. Click the plus sign (+) beside the CallPilot server to expand the component tree.
4. Continue clicking the plus sign (+) until the component with which you want to work is visible.
5. Click the hardware component with which you want to work.  
Result: The Maintenance page refreshes to show details about the component.
6. Scroll down to the Maintenance section.

The following illustration shows the Maintenance section for an MPC-8 card:



7. View the state of the selected component in the State box.

---

## Starting and stopping components

---

### Introduction

When you stop a component, you take it out of service and prevent it from operating. You must stop a component before you can replace it (if the component is replaceable) or run a diagnostic test on it.

To bring an out-of-service component back into service, you must start it.

Start and stop components from the Maintenance section on the Maintenance page.

#### Important:

Avaya recommends that, if possible, you courtesy stop a component. Courtesy stop is available only at the individual channel level.

To courtesy down CallPilot, use the following:

- Multimedia Monitor: to courtesy stop a range of multimedia channels
- Channel Monitor: to courtesy stop a range of call (DS30X, also known as DS0) channels

For instructions, see [Section C: Working with the Multimedia and Channel Monitors](#) on page 70.

---

### Stop versus courtesy stop

The following two methods of taking a component out of service allow you to choose how active calls are affected:

---

## Courtesy stop

A courtesy stop takes the component out of service only after the component has finished processing the active call.

- If the component is currently processing a call, the call is not dropped; the component remains active until the call is finished.
- If the component is not currently in use, it is taken out of service immediately.

Courtesy stop is preferred over a regular stop.

---

## Stop

A stop takes the component out of service immediately, regardless of whether the component is currently processing calls. All active calls are dropped. Typically, you perform a stop only when severe problems that are affecting a large number of incoming calls occur or if your organization determines a special need for it.

---

## Components that can be started and stopped

Only the following components can be started and stopped:

 **Note:**

If you want to start or stop more than one or two multimedia (DSP) or call (DS30X) channels, use the Multimedia Monitor or Channel Monitor. For instructions, see [Section C: Working with the Multimedia and Channel Monitors](#) on page 70.


Component	Effect of stopping
Motherboard (IPE server)	Takes all call processing resources on the selected board out of service.
Time Switch	You cannot perform maintenance administration on the timeswitch.
MPCs (embedded on the IPE server or on MPC-8 cards)	Takes the selected MPC out of service.
Multimedia channels	Takes the selected DSP out of service.
Channels	Takes the selected DS30X channel out of service.

Component	Effect of stopping
DS30X link	Takes the selected DS30X link out of service.

### To start or stop a component

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click Maintenance → Maintenance Admin.  
Result: The Maintenance page appears.
3. Click the plus sign (+) beside the CallPilot server to expand the component tree.
4. Continue clicking the plus sign (+) until the component with which you want to work is visible.
5. Click the hardware component that you want to start or stop.  
Result: The Maintenance page refreshes to show details about the component.
6. Scroll down to the Maintenance section.

The following illustration shows the Maintenance section for an MPC-8 card.



7. Click Courtesy Stop, Stop, or Start, as required.

Button	Description
Start	If the selected component is out of service, click this button to put it into service.
Courtesy Stop	Click this button to take the selected component out of service. CallPilot waits for the call to be completed before disabling the component.  <div style="text-align: center;">  <b>Important:</b>                      If you are courtesy stopping all components (that is, you are taking the entire system down), ensure that you inform all administrators, desktop messaging users, and Web messaging users so that they can log off their sessions before you proceed.                      The system asks you to confirm the Courtesy stop. If you click OK, the component is put out of service after all calls are finished.                 </div>
Stop	Click this button to take the selected component out of service immediately. All calls that are in progress are disconnected immediately.

Button	Description
	<p> <b>Important:</b></p> <p>If you are stopping all components (that is, you are taking the entire system down), ensure that you inform all administrators, desktop messaging users, and Web messaging users so that they can log off their sessions before you proceed.</p>

---

## Running integrated diagnostics

---

### Introduction

You should run diagnostic tests from the Diagnostics section on the Maintenance page in the following circumstances:

- You want to ensure that a component is operating properly after installing or reinstalling it.
- The CallPilot server has trouble processing incoming calls, and you hope that diagnostic results can tell you why.

Problems include static, dropped calls, and cross talk (hearing another conversation).

---

### Before you begin

 **Important:**

Take the component out of service before you run the diagnostic test. See [Starting and stopping components](#) on page 61.

---

### Components that have diagnostic tests available

The following table identifies the components on which you can run diagnostics.

Component	Diagnostics available?	Replaceable?
Motherboard	Yes	Yes (IPE server)

Component	Diagnostics available?	Replaceable?
Time Switch	No	No
MPCs (embedded on the IPE server or on MPC-8 cards)	Yes	Embedded: No MPC-8 cards: Yes
Media channels	No	No
Call channels	No	No
DS30X link	No	No

---

## Diagnostic tests available for each component

The diagnostic tests that are available for each component are listed in the Diagnostic section of the Maintenance page. To view the list of diagnostic tests for a particular component, click the component in the component tree.

---

## If a diagnostic test fails or cannot be run

If a warning message appears, the diagnostic test cannot be run because a prerequisite condition has not been met. If a diagnostic test fails, a message appears in a new browser window (see the example on page [9](#) on page 67).

In both cases, check the Alarm Monitor to determine the reason and the appropriate action to take. (See [Section A: Tools for isolating and fixing hardware problems](#) on page 51.)

If the Alarm Monitor and Event Browser do not provide a solution to a hardware problem, you may need to replace or service a component. If the problem is with a component that is not replaceable because it is not a physical entity (such as the Time Switch), you must either replace its parent component or contact your Avaya technical support representative, depending on the component.

### Important:

Avaya recommends that you courtesy stop rather than stop a component if possible. For instructions, see [Starting and stopping components](#) on page 61

### To run a diagnostic test

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click Maintenance → Maintenance Admin.

Result: The Maintenance page appears.

3. Click the plus sign (+) beside the CallPilot server to expand the component tree.
4. Continue clicking the plus sign (+) until the component with which you want to work is visible.
5. Click the hardware component for which you want to run diagnostics.

Result: The Maintenance page refreshes to show details about the component.


6. Scroll down to the Maintenance section, and ensure that the component is out of service.

 **Note:**

For instructions on taking the component out of service, see [To start or stop a component](#) on page 63.

7. Scroll down to the Diagnostics section.

Result: The following illustration shows the Diagnostics section for an MPC-8 card (removable MPC.):



8. Check the check box for each diagnostic that you want to run.

 **Note:**

If you want to run all of the diagnostics, check the Diagnostic Description check box at the top of the list.

9. Click Run.

Result: A new Web browser window opens to display the progress and results of the diagnostics.

 **Note:**

The Diagnostic Results box in the Diagnostics section displays diagnostic results when you click Get Last Result.

---

## Viewing the last diagnostic results

---


### Introduction

You can review the results of previously run diagnostics by clicking the Get Last Results button for a component.

#### To view the last diagnostics result


1.  **Important:**  
Avaya recommends that you courtesy stop rather than stop a component if possible. For instructions, see [Starting and stopping components](#) on page 61.  
Run CallPilot Manager and log in.
2. In CallPilot Manager, click Maintenance → Maintenance Admin.  
Result: The Maintenance page appears.
3. Click the plus sign (+) beside the CallPilot server to expand the component tree.
4. Continue clicking the plus sign (+) until the component with which you want to work is visible.
5. Click the hardware component for which you want to run diagnostics.  
Result: The Maintenance page refreshes to show details about the component.
6. Scroll down to the Diagnostics section.  
Result: The following figure shows the Diagnostics section for an MPC-8 card (removable MPC).

## Using CallPilot Manager to monitor hardware



7. Check the check box for each diagnostic for which you want to review results.
8. Click Get Last Result.

Result: The results appear in the Diagnostic Results box.



## Last diagnostic results

The results of the last diagnostic test display the following information in the Diagnostic Results box:

- diagnostic title
- diagnostic result: pass or fail
- the date and time the test was completed

---

## Section C: Working with the Multimedia and Channel Monitors

---

### In this section

[Working with the Multimedia Monitor](#) on page 70

[Working with the Channel Monitor](#) on page 71

---

## Working with the Multimedia Monitor

---

### Introduction

The Multimedia Monitor shows the status of multimedia channels. The multimedia channels are the DSP ports that process the calls. They are the voice, fax, and speech recognition channels.

#### To view or work with multimedia channel states

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click Maintenance → Multimedia Monitor.

Result: The Multimedia Monitor page appears, showing the channels associated with each DSP.



**Note:**

For an explanation of the channel states, refer to the CallPilot Manager online Help.

3. Do one of the following:

IF you want to stop or start	THEN
all of the channels associated with a DSP	check the check box to the left of the DSP that you want to stop or start. Repeat this step for each DSP.

---

IF you want to stop or start	THEN
only one or several channels that are associated with a DSP	check the check box for each channel that you want to stop or start.

4. Click Courtesy Stop, Stop, or Start as required.

**Result:** If you clicked Courtesy Stop or Stop, you are asked to confirm the Courtesy Stop or Stop. Click OK.

The selected channels change to off-duty or on-duty status, according to the action you chose.

 **Note:**

If the buttons are not available, wait a few seconds for the page to refresh.

---

## Working with the Channel Monitor

---


### Introduction

The Channel Monitor shows the status of call channels. The call channels are the connections between the server and the switch that carry the call signals to CallPilot.

#### To view or work with call channel states

1. Run CallPilot Manager and log in.
2. In CallPilot Manager, click Maintenance → Channel Monitor.

**Result:** The Channel Monitor page appears, showing the DS30X (also known as DS0) channels associated with each DS30X link.



**Note:**

For an explanation of the channel states, refer to the CallPilot Manager online Help.

3. Do one of the following:

IF you want to stop or start	THEN
all of the channels associated with a DS30X link	check the check box to the left of the DS30X link that you want to stop or start. Repeat this step for each DS30X link.
only one or several channels that are associated with a DS30X link	check the check box for each channel that you want to stop or start.

4. Click Courtesy Stop, Stop, or Start, as required.

**Result:** If you clicked Courtesy Stop or Stop, you are asked to confirm the Courtesy Stop or Stop. Click OK.

The selected channels change to off-duty or on-duty status, according to the action you chose.



**Note:**

If the buttons are not available, wait a few seconds for the page to refresh.



# Chapter 6: Using Avaya CallPilot® system utilities

---

## In this chapter

[Overview](#) on page 75

[Diagnostics Tool](#) on page 76

[PEP Maintenance utility](#) on page 78

[Session Trace](#) on page 79

[System Monitor](#) on page 85

---

## Overview

---

## Introduction

The following table lists the CallPilot system utilities:

Utility	Description
Diagnostics Tool	Allows CallPilot startup diagnostics to be enabled or disabled (turned on or off).
PEP Maintenance	Displays a list of installed PEPs and enables PEP uninstall.
Session Trace	Provides detailed information about the activity in a user's mailbox and the state of the message waiting indicator (MWI).
System Monitor	Displays the following information: <ul style="list-style-type: none"><li>• the status of all CallPilot channels</li><li>• the status of all CallPilot services</li></ul>

Utility	Description
	<p data-bbox="553 264 672 310"> <b>Note:</b></p> <p data-bbox="565 321 1336 380">This status is more accurate than the status the operating system provides in the Services control panel.</p> <ul data-bbox="518 394 1351 453" style="list-style-type: none"><li>• particulars about the CallPilot System, such as names, keycodes, serial numbers, IP addresses, and system numbers</li></ul>

---

## Accessing the system utilities

All CallPilot utilities are accessible from the CallPilot server in the Start → Programs → CallPilot → System Utilities menu.

---

## Diagnostics Tool

---

### Introduction

The Diagnostics Tool allows you to enable or disable Avaya CallPilot startup diagnostics.

CallPilot startup diagnostics automatically identify hardware problems that may exist when the system and its services are started (DSP, TimeSwitch, MediaBus).

When you disable startup diagnostics, you can save time during system maintenance operations where restarts or Call Processing services restarts are required.

There are three recommended steps:


- Use the Diagnostics Tool to turn off CallPilot startup diagnostics.
- Perform system maintenance.
- Use the Diagnostics Tool to turn on CallPilot startup diagnostics.

---

### To access the Diagnostics Tool

On the Windows desktop, click Start → Programs → CallPilot → System Utilities → Diagnostic Tool.

Result: The Diagnostics Tool window appears.



---

## To enable startup diagnostics

From the Diagnostics Tool window, select Configuration → Maintenance Startup Diag → Enable.

---

## To disable startup diagnostics

**!** Important:

Avaya recommends that you leave the startup diagnostics turned on.

When you disable CallPilot startup diagnostics, you prevent CallPilot from automatically identifying hardware problems that may exist when the system and its services are started (DSP, TimeSwitch, MediaBus).

On the Diagnostics Tool window, select Configuration → Maintenance Startup Diag → Disable.

---

## PEP Maintenance utility

---

### Introduction

The PEP Maintenance utility displays a list of all installed PEPs on the server and enables you to uninstall PEPS.

For information on installing or uninstalling PEPs, refer to the CallPilot Software Administration and Maintenance guide.

---

### To access the PEP Maintenance utility

From the Windows desktop, click Start → Programs → CallPilot → System Utilities → PEP Maintenance Utility.

Result: The DMI Viewer window appears.

#### To view a list of all installed PEPs

1. Click the component for which you want to display the PEP list.
2. Click Show PEPs.

Result: A list of all installed PEPs appears in the left pane.

3. If you want to review the readme file associated with a PEP, click the PEP, and then click Read.

Result: The readme file opens in Notepad.

---

# Session Trace

---

## Introduction

The Session Trace tool displays detailed information about the activity in a user's mailbox and the state of the message waiting indicator (MWI). The session information includes

- voice messaging
- call answering
- express messaging activity (messages composed and sent, or left in a mailbox)
- the number of messages played or unplayed at the beginning, middle, and end of a session
- the number of deleted read messages
- the number of deleted unread messages
- messages and personal distribution lists restored into a mailbox
- the last change to the MWI (turned on or off, or untouched)

This session information allows an administrator or technician to study the state of a user's mailbox and the MWI, and to use that information to follow up on any user complaints. For example, a user might complain that the MWI was on, but no voice messages were in the mailbox when the user logged on. The session information might tell the administrator why the MWI was turned on.

 **Warning:**


The Session Trace Tool is a resource intensive tool. It is strongly recommended to use this utility during off-peak hours. If the CP database or OMs are large, it may require a significant amount of time to perform this activity. To minimize the search time, OM data should be collected for no more than 1–2 days.

---

## To access the session trace tool


From the Windows desktop, click Start → Programs → CallPilot → System Utilities → Session Trace Tool.

Result: The MCE Session Trace window appears.



## To find a session

1. From the Session Type drop-down menu, choose the type of session.



To display a list of all session types, select All Session Types.

2. Enter as much information in the search criteria boxes to identify the session you want to view.

To display a list of all users for the selected Session Type, leave the search criteria boxes blank.

3. Click Search to initiate the search.
  - a. If you did not enter any user information, a list of users matching the Session Type appears at the bottom of the window.
 

To select a user from the list, double-click the user name to display session type information.
  - b. If you selected All Session Types for a user, the session type information appears to the right of the window.

4. Double-click the session type to display the session information.

Result: The Session Type information appears at the bottom of the window.

## Session type information

The screenshot shows the 'MCE Session Trace' application window. On the left, there are search filters: Session Type (All Session Types), Last Name (Clint), First Name (Bill), Mailbox Number (8050), Called DN, and Calling DN. Below these are date and time filters for Start Date & Time (5/2/99 11:23:15 AM) and End Date & Time (5/2/00 11:23:15 AM), along with a 'Search' button and 'Last Search Time' (11:26:30 AM). The main area contains a table of session records:

Session Type	Start Time	End Time
Logon OK	15:37:14 Apr 28	15:38:40 Apr 28
MWI Off	15:38:41 Apr 28	15:38:41 Apr 28
Logon OK	15:39:40 Apr 28	15:40:09 Apr 28
MWI Off	15:40:10 Apr 28	15:40:10 Apr 28
Call Answering	15:42:30 Apr 28	15:42:40 Apr 28
MWI On	15:42:40 Apr 28	15:42:40 Apr 28
Logon OK	15:42:47 Apr 28	15:43:56 Apr 28
MWI Off	15:43:11 Apr 28	15:43:11 Apr 28
MWI Off	15:43:57 Apr 28	15:43:57 Apr 28
Call Answering	15:46:48 Apr 28	15:46:53 Apr 28
MWI On	16:56:24 Apr 28	16:56:24 Apr 28
MWI On	01:30:13 Apr 29	01:30:13 Apr 29
Expired Messages	03:30:09 Apr 29	03:30:09 Apr 29

Below the table, the details for the selected 'Call Answering' session are shown:

Session Type: Call Answering  
 Start Time: 15:42:30 Apr 28  
 End Time: 15:42:40 Apr 28  
 Session Length: 10 seconds  
 Called DN: 8050  
 Calling DN: 8051  
 Call Origination: Inbound  
 Message Length: 1 second  
 Message Disposition: Message left

At the bottom left, it says '43 records found' and at the bottom right, there is a 'NUM' button.

Figure 1: Call Answering session type information




Figure 2: Expired messages session type information




Figure 3: Express Messaging session type information




Figure 4: Logon OK session type information




Figure 5: Selective Restore session type information

---

# System Monitor

---

## Introduction

The System Monitor consists of three tabs, as described in the following table:

Tab	Description
Channel Monitor	Shows the status of all CallPilot services, multimedia channels (DSP channels), and call channels (DS30X channels).
System Info	Displays details about the CallPilot System, such as features purchased, keycode, serial number, and CallPilot server IP addresses.
Legend/Help	Provides a description of icons and terminology displayed in the System Monitor window.

System Monitor is a non-destructive tool that does not alter the behavior of any CallPilot components.

---

## To access the System Monitor


On the Windows desktop, click Start → Programs → CallPilot → System Utilities → System Monitor.

Result: The CallPilot System Monitor window appears. By default, the Channel Monitor tab appears on top. Click the other tabs to view the information on those tabs.

---

## About the Channel Monitor tab

The following illustration shows the Channel Monitor tab, followed by a description of its contents



## CallPilot services

The Service Name pane shows the status of services from a CallPilot perspective. The status shown in the operating system Services control panel may state that a service is running, but it may not actually be fully running or in service from a CallPilot perspective. Refer to the System Monitor tool Channel Monitor tab for the true status.

The services listed under Service Name should be either running or in full service when CallPilot is functioning optimally. If any CallPilot services are stopped, investigate the cause of this. Call Avaya technical support for assistance.

**\* Note:**

While any stopped services should be investigated, some services are not critical. CallPilot may continue to handle call processing even with some services stopped.

The critical services that are needed for basic CallPilot call answering are listed in the following table. For your reference, the equivalent names as they appear in the Windows Control Panel are also listed.

CallPilot SystemMonitor	Windows Control Panelequivalent
CTMS Service	CTMS Server
Telephony (TAPI)	Telephony Service

CallPilot SystemMonitor	Windows Control Panelequivalent
MCE SLEE	CallPilot SLEE Service
MCE Notification	CallPilot MWI Service
MAS Notification	CallPilot Notification Service
MAS CCR	CallPilot Call Channel Router
MAS BCR	CallPilot Blue Call Router
SQL Anywhere	Adaptive Server Anywhere - %ComputerName %_SQLANY
MAS MltmediaCache	CallPilot Multimedia Cache
MAS MltmediaVol1	CallPilot Multimedia Volume 1
MAS MltmediaVol102(TRP only)	CallPilot Multimedia Volume 102 (TRP only)
MAS MltmediaVol103 (TRP only)	CallPilot Multimedia Volume 103 (TRP only)
MAS Rsrc. Pckg. 1	CallPilot Resource Package1

---

## DSPs

In the DSP pane, each DSP is represented in a separate row. Each box in the row is one DSP channel or multimedia channel. Click the Legend/Help tab to view descriptions of the multimedia channel icons.

For 201i servers, DSPs reside on the motherboard and on MPC-8 cards.

DSPs are distributed as follows:

- The 201i server contains one embedded DSP with up to four MPC-8 cards.
- Each MPC-8 card contains a single DSP.

---


## DS30X links

In the DS30X link pane, each DS30 row represents a separate DS30X link (also referred to as a DS30 link). Each box in the row represents one DS30X channel.

For the 201i server, the DS30X link to the switch is supported by the connection of the server to the switch backplane.

## About the System Info tab

The following illustration shows the System Info tab, followed by a description of its contents.




The numbered items provide information about the features purchased. Information about the underlying operating system, including the server IP addresses, is provided in the top right corner.

PEP information and configured Service DNs are listed in the bottom part of the window.

## About the Legend/Help tab

The following illustration shows the Legend/Help tab. Consult this tab for descriptions of the icons found in the Channel Monitor tab





# Chapter 7: Performing hardware maintenance and mechanical assembly

---

## In this chapter

[Overview](#) on page 91

[Removing the server from the switch](#) on page 92

[Replacing the server](#) on page 93

[Replacing the IDE hard drive](#) on page 97

[Replacing the software feature key](#) on page 108

---

## Overview

---

## Introduction

Before you can begin component replacement, you must do the following:

- Gather the tools you need.
- Remove the 201i server from the switch.
- Become familiar with component layout on the 201i server.

## Equipment required

You need the following tools, based on the component you are replacing:

- antistatic wrist strap or antistatic mat
- Phillips No. 1 and No. 2 screwdrivers
- tweezers

---

## Before you begin

Shut down the server software. Then remove the server from the switch and place it on a static-resistant surface, with the component side facing up.

If you need to replace the entire 201i server, review [Replacing the server](#) on page 93. Then review the procedures for installing the server and conducting diagnostic tests.

---

## Removing the server from the switch

---

## Introduction

You must remove the server from the switch before you replace the following components:

- hard drive
- software feature key (dongle)

 **Note:**

You can replace an MPC-8 card without powering down the 201i server.

---

## Equipment required

The following equipment is required for this procedure:

- antistatic mat
- antistatic wrist strap

### To remove the server from the switch

1. Power down the server by unseating it from the back plane. Wait 15 seconds to complete powering down, then remove the server.

For instructions, refer to the CallPilot Installation and Configuration Task List (NN44200-306).

2. Turn off the monitor.
3. Disconnect the monitor, keyboard, and mouse.
4. Power down the peripheral SCSI devices, and disconnect the SCSI cable.
5. Open the lock latches at the top and bottom of the server.
6. Grip the faceplate, and then unseat the server from the switch. Wait 15 seconds, then remove the server.
7. Place the server on a clean, static-resistant surface.

---

## What is next?

Replace and upgrade components, as required.

---

## Replacing the server

---

## Introduction

Replace the server only if you are instructed to do so. For activities that are not supported as field procedures, you must return the server to Avaya for service.

This section summarizes the procedure for replacing the server. References are made to specific component replacement procedures where applicable.

## To replace the server


1. If the installed server is functional, perform a complete backup of the hard disk as a precautionary measure.
2. Use the Maintenance screen in CallPilot Manager to take the installed MPC-8 cards out of service (see [Starting and stopping components](#) on page 61).
3. Remove the MPC-8 cards from the faceplate of the server (see [Replacing Multimedia Processing Cards](#) on page 110).
4. Shut down the installed server (refer to "Starting up and shutting down the Avaya CallPilot® server" in the CallPilot Installation and Configuration Task List).
5. Power down the server by unseating it from the back plane. Wait 15 seconds to complete powering down, then remove the server.
6. Disconnect all peripherals from the server.
7. Remove the server from the switch (see [Removing the server from the switch](#) on page 92).
8. Remove the software feature key (dongle) from the defective server, and then install it in the replacement server (see [Replacing the software feature key](#) on page 108).
9. Remove the hard drive from the defective server, and then install it in the replacement server (see [To remove the IDE hard drive](#) on page 99).
10. Install the replacement server on the switch, and then reconnect the peripherals.
11. Install the MPC-8 cards removed from the defective server (see [To install an MPC-8 card](#) on page 113).
12. Boot the server to the operating system.
13. Run the Configuration Wizard to configure the new hardware.

For instructions, refer to the CallPilot <switch model> and Avaya CallPilot Server Configuration guide for your switch and server.

---


## 201i server component diagram: exploded view

The following diagram identifies component locations on the 201i server.



## 201i server component diagram: complete assembly

The following diagram shows the 201i server when it is completely assembled.



G101544

## Legend

Item	Description
1	Heat sink
2	Hard drive power cable
3	Hard drive data cable
4	Secondary backplane connector pin
5	Secondary backplane connector
6	3.5" IDE hard drive

Item	Description
7	Hard drive mounting bracket
8	Software feature key (dongle)
9	Faceplate
10	Monitor connector
11	Mouse connector
12	Keyboard connector

---

## Replacing the IDE hard drive

---

### Introduction

The hard drive rests lengthwise along the backplane side of the server. The hard drive bracket is secured in place by five screws: two on the backplane edge, two through the motherboard, and one through the bottom edge of the stiffener.

 **Note:**

The 3.5 inch hard drive is no longer available. A 2.5 inch drive must be ordered as a replacement. If you are replacing a 3.5 inch hard drive with a new 2.5 inch hard drive, you must have the NTRH9107E5 hard drive replacement kit. The kit description and assembly instructions are described later in this section. The 2.5 inch hard drive is ordered separately. See the Avaya price book for particulars.

---

### Equipment required

The following equipment is required for this procedure:

- antistatic wrist strap
- Phillips No. 1 screwdriver

## Before you begin

Before you replace the hard drive, review the following:

- [Removing the server from the switch](#) on page 92
- the [201i server component diagram: exploded view](#) on page 94


---

## Hard drive assembly diagram

The following diagram shows the hard drive in its assembled state.

 **Note:**

The following four diagrams depict the 3.5 inch hard drive assembly. The 2.5 inch drive assembly is slightly different, but the removal instructions for the assembly are the same.




G101433

### To remove the IDE hard drive


1. Do the following:
  - a. Remove the two screws on the back of the motherboard.
  - b. Remove the screw at the bottom of the stiffener cage.
  - c. Remove the two screws on the hard drive stiffener cage (along the backplane edge of the server).

See the following diagram.




2. Do the following:

- a. Dislodge the power cable from its connector and lift it away from the motherboard.
- b. Slide one hand as far as you can beneath the hard drive so that it is securely supported and you can touch the data cable connector on the motherboard.



G101447

3. Use the pull tabs to gently remove the data cable connector from the motherboard.  
See the following diagram.




G101448

4. Lift the hard drive assembly away from the motherboard.
5. Do the following:

IF you are	THEN
replacing a 3.5 inch hard drive	Go to <a href="#">To replace a 3.5 inch drive with a 2.5 inch hard drive</a> on page 103. You do not need to remove the drive from the assembly.
replacing a 2.5 inch hard drive	continue with step 6

6. Disconnect the black hard drive adaptor from the hard drive
7. Detach the hard drive by removing the four screws on the bottom of the hard drive assembly.



8. Fasten the new drive to the hard drive assembly bracket using the four screws from the replacement kit.
9. Connect the black hard drive adaptor to the hard drive.
10. With the drive on top, and the cable facing the top of the server, mount the drive assembly. The slot in the drive assembly goes over the PCI connector on the motherboard.
11. Fasten the two screws on the back of the motherboard.
12. Fasten the screw on the stiffening cage.


13. Fasten the two screws on the hard drive stiffener cage (along the backplane edge of the server).
14. Connect the data cable from the drive to the motherboard connector

**⚠ Caution:**

Risk of equipment damage

Ensure the pins on the data connector on the motherboard line up correctly with the data cable connector.

15. Connect the drive power connector to the motherboard power connector.




**To replace a 3.5 inch drive with a 2.5 inch hard drive**

1. Inspect the NTRH0107E5 replacement kit for the following parts:

Item No.	Quantity	Description
1	1	Power coupler, large to small
2	1	2.5 inch disk drive. This item is ordered separately. Check the Avaya price book for ordering procedures.
3	4	Screws (for mounting the hard drive on the bracket)
4	1	Small drive bracket
5	1	Tie wrap
6	1	2.5 inch hard drive adaptor

7	1	Flat flexible cable
8	2	Screws. These screws are shorter than the four screws in item 3

2. Place the 2.5 inch hard drive in the palm of your hand with the screw holes facing upwards
3. Place the hard drive bracket over the hard drive with the data connector facing the notched end of the bracket.
4. Insert the four screws, listed as kit item 3, in the mounting holes, and tighten them



**Figure 6: Hard drive mounted on bracket**


5. Attach the black cable adaptor to the IDE connector on the hard drive. The power cable pins go to the left side of the connector as you are facing it. Ensure the left-most pins are connected. Four pins remain unconnected on the right side of the connector.
6. Attach the flat flexible cable to the black connector. The red stripe on the ribbon cable goes to the end of the connector opposite from the power pins
7. Turn the drive assembly over with the hard drive facing up.

**\* Note:**

The diagram below shows the bottom of the bracket assembly and hard drive.

8. Loop the red and black power wires under the hard drive adaptor and mount the power coupler between the two tabs on the bracket.

9. connect the original power cable to the adaptor, and fasten the connectors to the bracket with the tie wrap. The tie wrap goes through the rectangular hole and between the two inner power wires.



**Figure 7: Bottom view of hard drive assembly**

10. With the drive on top, and the cable facing the top of the server, mount the drive assembly. The slot in the drive assembly goes over the PCI connector on the motherboard.

**\* Note:**

The PCI connector on the motherboard is reserved for future use

11. Fasten the two screws on the back of the motherboard. These screws are from the original assembly.
12. Fasten the screw on the stiffening cage. This screw is from the original assembly
13. Fasten the two screws on the hard drive stiffener cage along the backplane edge of the server. These screws are item number 8 in the replacement kit
14. Connect the flat flexible data cable from the drive to the motherboard connector

**⚠ Caution:**

Risk of equipment damage

## Performing hardware maintenance and mechanical assembly

Ensure the pins on the data connector on the motherboard line up correctly with the data cable connector.

15. Connect the drive power connector to the motherboard power connector.




Figure 8: Mounting the drive assembly on the motherboard




Figure 9: Hard drive assembly mounted on Motherboard

## What is next?

Review the procedures for installing the server and conducting diagnostic tests.

---

## Replacing the software feature key

---

### Introduction

The software feature key (dongle) stores the unique serial number of the server. If the 201i server must be replaced, use this procedure to move the software feature key from the faulty server to the replacement server.

---

### Equipment required

The following equipment is required for this procedure:

- flat blade screwdriver
  - tweezers
- 

### Before you begin

Before you replace the hard drive, review the following:

- [Removing the server from the switch](#) on page 92
- the [201i server component diagram: exploded view](#) on page 94

#### To replace the software feature key

1. Use the flat blade of the screwdriver to lift the clip that secures the software feature key to the motherboard.


**⚠ Caution:**

Risk of equipment damage

Ensure that you do not bend the clip so that it can no longer apply downward pressure.

2. Use the tweezers to pull the software feature key out of the socket.
3. Insert the software feature key into the socket on the replacement server, lip side up.

When the software feature key (dongle) is correctly installed, it is firmly seated in its socket. See the following diagram.



G101539

---

## Replacing Multimedia Processing Cards

---

### Introduction

The Avaya MPC-8 card supports multimedia telephony services on the 201i server.



**Note:**

The 201i server motherboard contains one built-in MPC. This MPC is known as MPC 1.

---


### Supported MPC-8 card versions

The 201i server supports MPC-8 cards, Release 14 or later.

---

### What the MPC-8 card looks like

The following diagram shows the MPC-8 card.



G101540

---

## Correct card insertion

Four specially designed card slots for the MPC-8 are located on the 201i server faceplate. The MPC-8 card is keyed so that it fits only one way into the slot on the 201i server faceplate. If the card is inserted incorrectly, the card does not go all the way into the slot.


 **Caution:**

Risk of equipment damage

If you force the card into the slot incorrectly, this can result in damage to the MPC-8 card and the 201i server.

## Location of MPC slots

There is an ejector button, slot, and LED for each MPC. The following diagram shows where they are located on the 201i server.



G101440

The following table describes each LED status.

Status	Description
Off	The MPC is not receiving power. It is safe to remove the card.
On	The MPC is in use. In this case, it is not safe to remove the card.
Off, then on	The MPC has been recognized by the 201i server software and has been powered up.
On, then off	The MPC has been successfully powered down. It is safe to remove the card.

## To remove an MPC

 **Important:**

You can replace an MPC-8 card without powering down the 201i server. You must, however, disable the MPC-8 card using the CallPilot Manager software (as described in this procedure) before you remove it from the server.

 **Important:**

This procedure assumes that the 201i server is locked into position on the IPE shelf. If it is not, perform steps 3 and 4 only.

In CallPilot Manager, courtesy stop the channels associated with the MPC-8 card.

For instructions, see [Starting and stopping components](#) on page 61.

1. Ensure that the MPC's LED on the 201i server faceplate is not lit, which indicates that the MPC is no longer receiving power and can be removed safely.

 **Caution:**

Risk of equipment damage

If you remove an MPC while it is receiving power, this can damage the MPC or the 201i server.

2. Firmly press the MPC ejector button to dislodge the MPC from its slot.

Refer to Location of MPC slots.

 **Caution:**


Risk of equipment damage

Be ready to grab the MPC card as it ejects so that it does not fall to the floor.

3. Pull the MPC out of its slot.

## To install an MPC-8 card

1. Ensure that the MPC-8 card label is facing one of the following ways:  
facing to the right if the 201i server is inserted into the IPE shelf (see the following diagram)



facing up if the 201i server is lying horizontally on a flat surface

2. Insert the card into the slot, and gently push it until it is firmly in place and the ejector button pops back out.
3. Ensure that the MPC's LED lights up green.
4. Run the Configuration Wizard to detect and initialize the new hardware.

For instructions on running the Configuration Wizard, refer to the CallPilot <switch model> and CallPilot Server Configuration guide for your switch and server.

**\* Note:**

You do not need to change any data in the Configuration Wizard. However, you must apply the configuration changes as instructed on the last screen of the Configuration Wizard.

5. Start the MPC-8 card and its channels.

Result: For instructions, see [Starting and stopping components](#) on page 61.

## Index

---

### Numerics

- 201i server
  - startup failure
    - 8051, what to do .....[33](#)
    - CallPilot, what to do .....[33](#)

---

### A

- Alarm Monitor, using .....[52](#), [53](#)
- alarms
  - about .....[50](#), [53](#)
  - investigating .....[53](#)
- alert icons, component states .....[60](#)
- application event log
  - description .....[37](#)
- arp command .....[44](#)
  - parameters and descriptions .....[44](#)
  - running from the operating system .....[44](#)
  - syntax .....[44](#)

---

### C

- call channels
  - diagnostics, running .....[56](#)
  - disabling .....[56](#)
  - working with .....[71](#)
- CallPilot
  - software, reinstalling .....[12](#)
  - utilities
    - Diagnostics Tool .....[75](#)
    - PEP Maintenance .....[75](#), [78](#)
    - Session Trace .....[75](#), [79](#)
    - System Monitor .....[75](#)
- CallPilot Manager
  - Alarm Monitor, using .....[52](#), [53](#)
  - alarms
    - about .....[50](#), [53](#)
    - investigating .....[53](#)
  - alert icons, component states .....[60](#)
  - Channel Monitor, using .....[55](#), [71](#)
  - Event Browser, using .....[54](#), [55](#)
  - events
    - about .....[50](#), [54](#)
    - investigating .....[54](#)
  - fault management

- alarm notification .....[50](#)
- event processing .....[50](#)
- Maintenance page
  - Diagnostics section .....[57](#)
  - General section .....[57](#)
  - Maintenance section .....[57](#)
  - purpose .....[57](#)
  - using .....[55](#)
  - Multimedia Monitor, using .....[55](#), [70](#)
- CallPilot services, Channel Monitor tab .....[86](#)
- Channel Monitor tab .....[85](#)–[87](#)
  - CallPilot services .....[86](#)
    - critical .....[86](#)
  - DS30X links pane in .....[87](#)
  - DSP pane in .....[87](#)
- Channel Monitor, using .....[55](#), [71](#)
- channels
  - call, working with .....[71](#)
  - diagnostics, running .....[56](#)
  - disabling .....[56](#)
  - multimedia, working with .....[70](#)
- commands, TCP/IP
  - arp .....[44](#)
  - ipconfig .....[40](#)
  - nbstat .....[45](#)
  - netstat .....[46](#)
  - ping .....[41](#)
  - tracert .....[42](#)
- components
  - CallPilot Manager maintenance activities .....[58](#)
  - dependencies .....[51](#)
  - diagnostics that can be run .....[65](#)
  - diagnostics-eligible .....[64](#)
  - list .....[57](#)
  - replacing .....[14](#), [15](#)
  - start, about .....[61](#), [62](#)
  - starting .....[62](#)
  - states
    - Alert icons .....[60](#)
    - description .....[59](#)
    - viewing .....[60](#)
  - stop, about .....[61](#), [62](#)
  - stopping .....[62](#)
- Courtesy stop, description .....[62](#)
- CRI (fault status), what to do .....[31](#)
- critical services, CallPilot .....[86](#)
- critical startup diagnostics .....[29](#)

customer service .....	9	failure codes, diagnostics .....	31
<hr/>		<hr/>	
<b>D</b>		fault management	
diagnostics		alarm notification .....	50
critical startup .....	29	event processing .....	50
failure codes .....	31	<hr/>	
integrated		<b>G</b>	
running .....	64, 65	General section, Maintenance page .....	57
troubleshooting failures .....	65	<hr/>	
when to run .....	64	<b>H</b>	
last results		hardware maintenance	
description .....	69	components, replacing .....	14
viewing .....	67	performing .....	12
noncritical OS and switch .....	29	preparing for .....	12
startup .....	20	hardware problems, detecting .....	52
TCP/IP .....	36, 40–42, 44–46	HEX display	
arp .....	44	codes .....	26, 28
ipconfig .....	40	location on 201i server .....	21
nbtstat .....	45	purpose .....	20
netstat .....	46	<hr/>	
ping .....	41	<b>I</b>	
tracert .....	42	IDE hard drive	
Diagnosics section, Maintenance page .....	57	LED .....	25
diagnostics tool		integrated diagnostics	
CallPilot .....	75, 76	running .....	65
diagrams		troubleshooting failures .....	65
201i server		when to run .....	64
HEX display, location .....	21	ipconfig command .....	40
LEDs, location .....	21	flags and descriptions .....	40
display, HEX		running from the operating system .....	40
codes .....	26, 28	syntax .....	40
location .....	21	ipconfig default .....	40
distributor .....	9	<hr/>	
documentation .....	9	<b>L</b>	
<hr/>		LEDs	
<b>E</b>		IDE drive .....	25
Event Browser, using .....	54, 55	location on 201i server .....	21
event log		MPC slot .....	23, 24
system .....	37	network .....	25
event logs		power status .....	22
application .....	37	purpose .....	20
security .....	37	SCSI device .....	25
types, description .....	37	Legend/Help tab .....	88
viewing .....	37	logs	
events		event, viewing .....	37
about .....	50, 54	types, viewing .....	37
investigating .....	54	<hr/>	
<hr/>		<b>F</b>	
FAIL (fault status), what to do .....	31		

---

**M**

maintenance	
activities by component .....	<a href="#">58</a>
preparing for .....	<a href="#">12, 15</a>
Maintenance page, CallPilot Manager	
Diagnostics section .....	<a href="#">57</a>
General section .....	<a href="#">57</a>
Maintenance section .....	<a href="#">57</a>
purpose .....	<a href="#">57</a>
using .....	<a href="#">55</a>
MAJ (fault status), what to do .....	<a href="#">31</a>
MIN (fault status), what to do .....	<a href="#">31</a>
MPC slots	
LEDs .....	<a href="#">23, 24</a>
multimedia channels, working with .....	<a href="#">70</a>
Multimedia Monitor, using .....	<a href="#">55, 70</a>

---

**N**

nbtstat command .....	<a href="#">45</a>
parameters and descriptions .....	<a href="#">45</a>
running from the operating system .....	<a href="#">45</a>
syntax .....	<a href="#">45</a>
netstat command .....	<a href="#">46</a>
parameters and descriptions .....	<a href="#">46</a>
running from the operating system .....	<a href="#">46</a>
syntax .....	<a href="#">46</a>
network LED .....	<a href="#">25</a>
noncritical OS and switch diagnostics .....	<a href="#">29</a>

---

**O**

operating system	
reinstalling .....	<a href="#">12</a>
system event log, viewing .....	<a href="#">37</a>
OS and switch diagnostics, noncritical .....	<a href="#">29</a>

---

**P**

parts, obtaining replacement .....	<a href="#">15</a>
PEP Maintenance utility .....	<a href="#">75, 78</a>
ping command .....	<a href="#">41</a>
parameters and descriptions .....	<a href="#">41</a>
running from the operating system .....	<a href="#">41</a>
syntax .....	<a href="#">41</a>
power status LED .....	<a href="#">22</a>

---

**R**

replacement parts, obtaining .....	<a href="#">15</a>
------------------------------------	--------------------

reseller .....	<a href="#">9</a>
resources, troubleshooting .....	<a href="#">14</a>

---

**S**

SCSI device LED .....	<a href="#">25</a>
security event log	
description .....	<a href="#">37</a>
server, 201i	
startup failure	
8051, what to do .....	<a href="#">33</a>
CallPilot, what to do .....	<a href="#">33</a>
Session Trace utility .....	<a href="#">75, 79</a>
software	
maintenance, preparing for .....	<a href="#">12</a>
reinstalling .....	<a href="#">12</a>
startup	
diagnostics .....	<a href="#">20, 29</a>
critical .....	<a href="#">29</a>
noncritical .....	<a href="#">29</a>
failure	
8051, what to do .....	<a href="#">33</a>
CallPilot, what to do .....	<a href="#">33</a>
sequence, description .....	<a href="#">31</a>
Stop, description .....	<a href="#">62</a>
system	
event log, viewing .....	<a href="#">37</a>
problems, resolving .....	<a href="#">12, 13</a>
rebuild, performing .....	<a href="#">12</a>
system event log	
description .....	<a href="#">37</a>
System Info tab .....	<a href="#">88</a>
System Monitor .....	<a href="#">75, 85, 88</a>
Channel Monitor tab .....	<a href="#">85</a>
Legend/Help tab .....	<a href="#">88</a>
System Info tab .....	<a href="#">88</a>
using .....	<a href="#">85</a>
system utilities	
Diagnostics Tool .....	<a href="#">76</a>
System Monitor .....	<a href="#">85</a>

---

**T**

TCP/IP diagnostics .....	<a href="#">36, 40–42, 44–46</a>
arp .....	<a href="#">44</a>
ipconfig .....	<a href="#">40</a>
nbtstat .....	<a href="#">45</a>
netstat .....	<a href="#">46</a>
ping .....	<a href="#">41</a>
tracert .....	<a href="#">42</a>
tracert command .....	<a href="#">42, 43</a>

parameters and descriptions .....	<a href="#">43</a>	Diagnostics Tool .....	<a href="#">75</a> , <a href="#">76</a>
running from the operating system .....	<a href="#">43</a>	PEP Maintenance .....	<a href="#">75</a> , <a href="#">78</a>
syntax .....	<a href="#">43</a>	Session Trace .....	<a href="#">75</a> , <a href="#">79</a>
training .....	<a href="#">9</a>	System Monitor .....	<a href="#">75</a> , <a href="#">85</a>
troubleshooting			
overview .....	<a href="#">12</a> , <a href="#">13</a>		
resources .....	<a href="#">13</a> , <a href="#">14</a>		
in this guide .....	<a href="#">13</a>		

---

## U

utilities

## W

WARN (fault status), what to do .....	<a href="#">31</a>
---------------------------------------	--------------------